





# SERVICE PARTS MANUAL



## ELECTRIC & DCS VEHICLES

MANUAL: 28287-G01

MODEL YEAR: 1996

ISSUED: 07/20/95

REVISED: 03/29/96

# **SERVICE PARTS MANUAL**

## **TXT ELECTRIC VEHICLES**

MODEL YEAR: 1996

## **VEHICLES**

TXT FLEET

TXT FLEET DCS

TXT FREEDOM

TXT FREEDOM DCS

TXT 4 CADDY

**CUSTOMER SERVICE DEPARTMENT PHONE 1-800-227-7029 FAX 1-800-752-6175**  
E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA, GEORGIA 30903-0388, 1-800-241-5855

## **LIMITED WARRANTY**

# **WARRANTY**

**TO OBTAIN A COPY OF THE LIMITED WARRANTY THAT IS APPLICABLE TO YOUR VEHICLE, CALL OR WRITE YOUR LOCAL DISTRIBUTOR, BRANCH OR E-Z-GO WARRANTY DEPARTMENT.**

**THE USE OF NON E-Z-GO PARTS MAY VOID YOUR WARRANTY.**

**OVERFILLING OF BATTERIES MAY VOID YOUR WARRANTY.**

# GENERAL INDEX

## SECTIONS .....Page No.

How to use the **E-Z-GO** Service Manual .....vii

### Illustrated Parts Breakdown:

#### Illustration .....Page No.

ACCELERATOR LINKAGE .....A-1

- Accelerator Pedal
- Accelerator Rod

BATTERY CHARGERS, POWERWISE™ ..... C-1

BODY AND ASSOCIATED PARTS ..... D-1

- Body, Front Cowl
- Footrest
- Floorboard
- Rocker Panel
- Seat Frames
- Splash Panel
- Valance Panel
- Front Shield

BRAKE LINKAGE.....E-1

DIRECTION SELECTORS.....I-1

ELECTRICAL SYSTEM.....K-1

FRONT SUSPENSION ..... Q-1

- Front Axle Assembly
- Leaf Springs and Idler Assembly
- Hub and Spindle Assemblies
- Tie Rod Assembly

HORN AND LIGHTING .....S-1

- Headlamp
- Rear Lamp Assembly
- State of Charge Meter
- Turn Signal Assembly
- Wire Harness

MOTORS.....T-1

REAR AXLE ..... U-1

REAR SUSPENSION.....W-1

SEATING AND BAGRACK.....Y-1

SOLID STATE SPEED CONTROLS .....Z-1

- Control Rod
- Mounting Assembly
- Solenoid
- Speed Control Cover

# GENERAL INDEX

## Illustrated Parts Breakdown:

<b>Illustration</b>	<b>Page No.</b>
STEERING.....	BB-1
• Rack and Rod Assembly	
• Steering Wheel	
• Tie Rod Assembly	
WHEEL BRAKE, BENDIX.....	CC-1
• Brake Assembly	
• Brake Drum Assembly	
• Brake Shoe Set	
WHEEL BRAKE, NON- BENDIX.....	CC-3
• Brake Assembly	
• Brake Drum Assembly	
• Brake Shoe Set	
WHEELS AND TIRES.....	DD-1
• Tread Styles	
• Tire and Wheel Assembly	
• Valve Stem	
• Wheel Rim	

## SPECIAL TOOLS

Special Tools Listing .....	Appendix - A
-----------------------------	--------------

## ACCESSORIES

Accessory Listing .....	Appendix - B
-------------------------	--------------

## ACCESSORIES

Accessory Installations .....	Appendix - C
Divot Repair Kit (Sand Bottle)	
Side Basket	
Center Basket	
Sun Top With Bagrack	
Sun Top Without Bagrack	
Wheel Covers	

# GENERAL INDEX

Windshield  
Ashtray  
Rear View Mirror  
Hour Meter

## Illustrated Parts Breakdown:

**Illustration** ..... **Page No.**

Four Bag Attachment  
TXT Convertible Carrier  
TXT to 4-Caddy Conversion  
4-Caddy Conversion Windshield  
4-Caddy Conversion Sun Top  
4-Caddy to Convertible Carrier Conversion  
Permanent Tow Bar

## WIRING DIAGRAMS AND SCHEMATICS

Electric Vehicles ..... Appendix - D



# HOW TO USE THE E-Z-GO SERVICE PARTS MANUAL

This manual is divided into several sections:

- GENERAL INFORMATION
- ILLUSTRATED PARTS BREAKDOWN FOR TXT ELECTRIC POWERED GOLF CARS
- APPENDIX A

The first section, GENERAL INFORMATION, contains the following information:

- WARRANTY INFORMATION
- GENERAL INDEX
- HOW TO USE THE E-Z-GO SERVICE PARTS MANUAL

The second section, ILLUSTRATED PARTS BREAKDOWN (IPB) FOR THE TXT ELECTRIC POWERED GOLF CARS, contains illustrations and parts lists for all systems of your vehicle.

The third section, SERVICE ACCESSORIES AND SPECIAL TOOLS, contains a listing of E-Z-GO service accessories and special tools and that may be purchased from the company to aid in the servicing of the vehicle.

## USE OF THE MANUAL

To use this manual, consult the GENERAL INDEX to locate the information or illustration required.


E-Z-GO manuals are revised annually to coincide with the model year change. The manual will cover all models and model years stated on the cover page. Sections that remain unchanged have the last date they were revised in the lower inside margin. New components that are interchangeable with the previous year are automatically revised and the issue date is changed.

Introduction of some revisions varies due to supply of components; therefore, it is possible that various combinations of components may be found that are not directly reflected by each illustration. Consult the illustration that best suits your situation and then contact the Service Parts Department. It is important that the serial number of your vehicle and its model number be supplied to Service Parts when ordering any replacement components.

Locate the serial number plate (see Body and Associated Parts located in the IPB section of this manual for its location) and note the complete number shown on the plate.

All relevant systems are listed in the General Index and has an alphabetical prefix. The illustration always appears first and is followed by its related parts list. Additional illustrations and parts lists with the same prefix indicate significant changes that have taken place since the last issue.

# HOW TO USE THE E-Z-GO SERVICE PARTS MANUAL



## 1. WHEN THE PART NUMBER IS NOT KNOWN

- Determine the function and application of the part required. Turn to the General Index and select the most appropriate title.
- Turn to the page number indicated and locate the desired part on the illustration.
- From the illustration, obtain the item number assigned to the desired part. Refer to the accompanying description for specific information regarding the part.

## 2. IF YOU KNOW THE PART NUMBER

- Locate the part number or description in the appropriate column on the parts list page.

**NOTE:** It is suggested that you confirm that the part selected is correct by verifying it with the pictorial representation on the illustrated page.

Should an asterisk (\*) appear in the part number column on the parts list page, read upwards until a part number is found. The part number is the lowest assembly sold by E-Z-GO and the asterisk (\*) indicates that the part depicted is not available for sale by E-Z-GO.


**NOTE:** Descriptions are indented under the assembly that they are used on. That assembly is, in turn listed under the assembly that it is used on. This process is repeated until the highest final assembly is reached.


**To facilitate the maintenance and repair of the vehicle, a Technician's Repair and Service Manual (P/N 28292-G01) is available from the E-Z-GO Service Parts Department.**



# ILLUSTRATED PARTS BREAKDOWN

- 1 - INCLUDES ITEMS 3 - 32, 34, 36 - 40
- 2 - INCLUDES ITEMS 3 - 29, 32 - 40
- 20 - INCLUDES ITEMS 21 - 24
- 21 - INCLUDES ITEMS 22, 23





# ACCELERATOR LINKAGE

Electric Vehicle

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
1	25870-G03		PEDAL BOX ASSEMBLY (INCLUDES ITEMS 3 - 32, 34, 36 - 40) .....	1
2	25870-G05		PEDAL BOX ASSEMBLY, DCS MODEL ONLY (INCLUDES ITEMS 3 - 29, 32 - 40) .....	1
3	00550-G2		NUT, LOCK, 1/4 - 28 .....	1
4	00532-G4		NUT, LOCK, 5/16 - 24 .....	1
5	00684-G6		SCREW, #8 - 32 X 3/4 LG. ....	4
6	00982-G01		SCREW, #4 - 14 X 5/8 LG. ....	2
7				
8	00983-G01		NUT, SELF THREADING .....	2
9	00984-G01		SCREW, #8 - 10 X 1/2 LG. ....	4
10	00486-G2		SETSCREW, #8 - 32 X 1/8 LG. ....	1
11	00986-G01		PUSHNUT, 19/64 I.D. ....	1
12	10385-G4		YOKE, CLEVIS (ADJUSTABLE) .....	1
13	10386-G3		PIN, CLEVIS, 5/16 x 15/16 LG. ....	1
14				
15	10387-G3		PIN, COTTER, 3/32 x 3/4 LG. ....	1
16	17677-G1		RETAINER, SPRING .....	1
17	17677-G2		RETAINER, SPRING .....	1
18				
19	17979-G1		BUSHING, ACCELERATOR ROD .....	1
20	25799-G01		ACCELERATOR PEDAL ASSEMBLY (INCLUDES ITEMS 21 - 24) .....	1
21	27844-G01		ACCELERATOR PEDAL PAD KIT (INCLUDES ITEMS 22, 23) .....	1
22	15766-G1		RIVET, OVAL, 3/8 X 15/32 LG. ....	6
23	27512-G01		PAD, ACCELERATOR PEDAL .....	1
24	*		PEDAL, ACCELERATOR .....	1
25				
26	25853-G01		PEDALBOX AND COVER (SEAL AND BEARING) .....	1
27				
28	25854-G01		INDUCTIVE THROTTLE SENSOR .....	1
29	25859-G01		ACCELERATOR ROD .....	1

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.


When ordering parts, please specify the model and serial number of the product.


\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.


ITEM	PART NO.	1	2	3	4	5	DESCRIPTION	QTY.
30	25861-G01						SWITCH, MICRO.....	1
31	25879-G03						WIRING HARNESS, PEDAL BOX ASSEMBLY.....	1
32	26551-G01						PLUNGER.....	1
33	25861-G02						SWITCH, MICRO (DCS MODEL ONLY).....	1
34	26969-G01						CAM, PLUNGER.....	1
35	25879-G04						WIRING HARNESS, PEDAL BOX ASSEMBLY (DCS MODEL ONLY).....	1
36	70116-G01						BRACKET, PEDAL.....	1
37	70134-G01						PIN, PEDAL PIVOT.....	1
38	17255-G1						WASHER, TEFLON, 1/32 X 5/8.....	1
39	73046-G01						SPRING, COMPRESSION.....	1
40	17838-G1						BUSHING.....	3
41								
42	00715-G2						BOLT, 5/16 - 18 X 5/8 LG. ....	4
43	70135-G01						COVER, PEDAL PIVOT.....	1









TRANSFORMER LEG  
INSTALLATION





POWER INPUT BOARD  
INSTALLATION



CONTROL BOARD  
CONNECTIONS



GROUNDING  
DETAIL



THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1	2	3	4	5	DESCRIPTION	QTY.
1	28115-G01	CHARGER ASSEMBLY (COMPLETE) INCLUDES ITEMS 2 - 58.....					1	
2	00372-G3	SCREW, #8 - 32 X 3/8 LG. ....					1	
3	00372-G4	SCREW, #8 - 32 X 1/2 LG. ....					4	
4								
5	00378-G4	SCREW, #10 - 24 X 1/2 LG. ....					2	
6	00414-G5	SCREW, 1/4 - 20 X 5/8 LG. ....					3	
7	00513-G6	SCREW, #8 - 18 X 1 3/4 LG. ....					2	
8	00526-G1	NUT, #8 - 32.....					5	
9								
10	00526-G3	NUT, #10 - 24.....					2	
11	*	NUT, #10 - 32.....					3	
12								
13	00559-G3	WASHER, #6 .....					3	
14	00559-G4	WASHER, #8 .....					12	
15								
16								
17	00565-G4	WASHER, LOCK, #8 .....					5	
18	00565-G5	WASHER, LOCK, #10 .....					4	
19								
20	00614-G4	SCREW, #8 - 18 X 1/2 LG. ....					6	
21	00771-G6	WASHER, NYLON, SPECIAL.....					1	
22	00969-G01	SCREW, #8 - 32 X 3/8 LG. ....					3	
23	00984-G01	SCREW, #8 - 10 X 1/2 LG. ....					2	
24								
25	*	WASHER, BRASS, #10 .....					4	
26	01005-G01	SCREW, #6 - 19 X 5/16 LG. ....					3	
27	11027-G2	NUT, LOCK, 1/4 - 20.....					3	
28	11572-G3	NUT, PLASTIC EXPANSION .....					2	
29	13557-G2	STRAIN RELIEF, AC.....					1	
30	13557-G3	STRAIN RELIEF, DC .....					1	


THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.


\* Indicates a component that is not available as an individual part.


G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1	2	3	4	5	DESCRIPTION	QTY.
31								
32	19388-G4						CORD, AC .....	1
33	22589-G2						WASHER, SHOULDER .....	1
34								
35	25977-G32						WIRE, 4" .....	1
36	26979-G01						BRACKET, CAPACITOR .....	1
37	27877-G01						SUPPORT, SPACER .....	4
38	28091-G01						LABEL, FRONT .....	1
39								
40	*						COVER .....	1
41	*						CHASSIS .....	1
42	28102-G01						HANDLE .....	1
43	28103-G01						TRANSFORMER .....	1
44	28104-G01						HEAT SINK .....	1
45	28105-G01						AMMETER .....	1
46	28106-G01						FUSE, 50 AMP .....	1
47	28109-G01						CAPACITOR .....	1
48								
49	28110-G01						CLIP, ELECTRICAL .....	1
50	28111-G01						SUPPORT, CONTROL BOARD .....	3
51	28112-G01						DIODE .....	1
52								
53	28126-G01						BOARD, CONTROL .....	1
54	28126-G03						BOARD, POWER INPUT .....	1
55	28136-G01						TOP LABEL, VENTILATION .....	1
56	28136-G02						TOP LABEL, CORD CONDITION .....	1
57	17618-G1						CLAMP, NYLON .....	2
58	28137-G**						DC PLUG (COMPLETE) .....	1




1 - INCLUDES ITEMS 2 - 58







**TRANSFORMER LEG  
INSTALLATION**





**POWER INPUT BOARD  
INSTALLATION**



**CONTROL BOARD  
CONNECTIONS**



**GROUNDING  
DETAIL**



THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
1	28115-G02		CHARGER ASSEMBLY (COMPLETE) INCLUDES ITEMS 2 - 58.....	1
2	00372-G3		SCREW, #8 - 32 X 3/8 LG. ....	1
3	00372-G4		SCREW, #8 - 32 X 1/2 LG. ....	4
4				
5	00378-G4		SCREW, #10 - 24 X 1/2 LG. ....	2
6	00414-G5		SCREW, 1/4 - 20 X 5/8 LG. ....	3
7	00513-G6		SCREW, #8 - 18 X 1 3/4 LG. ....	2
8	00526-G1		NUT, #8 - 32.....	5
9				
10	00526-G3		NUT, #10 - 24.....	2
11	00528-G4		NUT, #10 - 32.....	3
12				
13	00559-G3		WASHER, #6 .....	3
14	00559-G4		WASHER, #8 .....	12
15				
16				
17	00565-G4		WASHER, LOCK, #8 .....	5
18	00565-G5		WASHER, LOCK, #10 .....	4
19				
20	00614-G4		SCREW, #8 - 18 X 1/2 LG. ....	6
21	00771-G6		WASHER, NYLON, SPECIAL.....	1
22	00969-G01		SCREW, #8 - 32 X 3/8 LG. ....	3
23	00984-G01		SCREW, #8 - 10 X 1/2 LG. ....	2
24				
25	01003-G01		WASHER, BRASS, #10 .....	4
26	01005-G01		SCREW, #6 - 19 X 5/16 LG. ....	3
27	11027-G2		NUT, LOCK, 1/4 - 20.....	3
28	11572-G3		NUT, PLASTIC EXPANSION .....	2
29	13557-G2		STRAIN RELIEF, AC.....	1
30	13557-G3		STRAIN RELIEF, DC .....	1

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.


When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.


G\*\* Indicates consult Customer Service Department for additional information.


ITEM	PART NO.	1	2	3	4	5	DESCRIPTION	QTY.
31								
32	19388-G4						CORD, AC .....	1
33	22589-G2						WASHER, SHOULDER.....	1
34								
35	25977-G32						WIRE, 4" .....	1
36	26979-G01						BRACKET, CAPACITOR .....	1
37	27877-G01						SUPPORT, SPACER .....	4
38	28091-G02						LABEL, FRONT .....	1
39								
40	*						COVER.....	1
41	*						CHASSIS.....	1
42	28102-G01						HANDLE .....	1
43	28103-G01						TRANSFORMER .....	1
44	28104-G01						HEAT SINK .....	1
45	28105-G01						AMMETER.....	1
46	28106-G01						FUSE, 50 AMP.....	1
47	28109-G01						CAPACITOR.....	1
48								
49	28110-G01						CLIP, ELECTRICAL.....	1
50	28111-G01						SUPPORT, CONTROL BOARD.....	3
51	28112-G01						DIODE .....	1
52								
53	28126-G02						BOARD, CONTROL .....	1
54	28126-G04						BOARD, POWER INPUT.....	1
55	28136-G01						TOP LABEL, VENTILATION .....	1
56	28136-G02						TOP LABEL, CORD CONDITION .....	1
57	17618-G1						CLAMP, NYLON .....	2
58	28137-G**						DC PLUG (COMPLETE).....	1


1 - INCLUDES ITEMS 2 - 5  
 10 - INCLUDES ITEMS 11 - 14




ITEMS 102 - 115 ARE FOR USE ON 4 CADDY MODELS ONLY









THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
1	71151-G01		INSTRUMENT PANEL ASSEMBLY (INCLUDES ITEMS 2 - 5).....	1
2	71153-G01		BALL DEFLECTOR, PASSENGER SIDE.....	1
3	71154-G01		BALL DEFLECTOR, DRIVER'S SIDE.....	1
4	00614-G5		SCREW, #8 - 18 X 5/8 LG.....	6
5	71158-G01		INSERT, 4 CUP INSTRUMENT PANEL.....	1
6				
7				
8	27647-G01		LABEL, SAFETY.....	1
9				
10	71143-G01		SPLASH PANEL ASSEMBLY (INCLUDES ITEMS 11 - 14).....	1
11	*		PANEL.....	1
12	*		BRACKET, STAY.....	2
13	*		BRACKET, PANEL.....	1
14	*		RIVET, 5/32 X 9/16 LG.....	9
15				
16				
17	00740-G4		SCREW, #10-32 X 1/2 LG.....	4
18	00921-G8		NUT, #10 - 32.....	4
19	16816-G2		FASTENER, RATCHET.....	1
20				
21	70047-G01		UPPER FLOORPAN.....	1
22	14601-G11		RIVET, 5/32 X 9/16 LG.....	10
23				
24	70451-G01		LOWER FLOORPAN.....	1
25	70452-G01		COVER, SWITCH ACCESS.....	1
26	14601-G11		RIVET, 3/16 X 9/16 LG.....	6
27				
28	70048-G01		FLOORMAT.....	1
29	71115-G01		TRIM, VINYL.....	2
30	14601-G13		RIVET, 5/32 X 9/16 LG.....	10

# BODY AND ASSOCIATED PARTS

# Electric Vehicle

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
31				
32	71051-G**		COWL.....	1
33	14601-G13		RIVET, 5/32 X 9/16 LG.....	2
34				
35	19817-G2		NAMEPLATE, E-Z-GO, GOLD .....	1
36	12064-G3		PUSHNUT, 3/16 .....	2
37				
38	71055-G01		RIVET, 3/16 X 3/8 LG.....	7
39	10570-G11		RIVET, 3/16 X 3/4 LG.....	2
40	71056-G01		BOLT, 5/16 - 18 X 5/8 LG. ....	4
41	00570-G2		WASHER, 5/16.....	4
42	00438-G6		BOLT, 5/16 - 18 X 3/4 LG. (WITH TOP).....	2
43	00571-G2		WASHER, 5/16 (WITH TOP).....	2
44				
45	70244-G02		PANEL, SPLASH.....	2
46				
47				
48				
49				
50	71551-G05		FENDER LINER, EXTENDED (PASSENGER SIDE) .....	1
51	71552-G05		FENDER LINER, EXTENDED (DRIVER'S SIDE).....	1
52	16816-G2		RATCHET FASTENER.....	12
53	16816-G2		RATCHET FASTENER.....	8
54				
55				
56				
57	70318-G02		SEAT FRAME.....	1
58	70046-G01		BATTERY RACK .....	1
59	00715-G2		BOLT, 5/16 - 18 X 13/16 LG. ....	5
60	00438-G6		BOLT, 5/16 - 18 X 3/4 LG. ....	2

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
61	11098-G6		NUT, LOCK, 5/16 - 18 .....	2
62	00559-G8		WASHER, 5/16.....	2
63				
64	71301-G**		REAR BODY (WITHOUT TAILLIGHTS) .....	1
65	71310-G**		REAR BODY (WITH TAILLIGHTS).....	1
66	71315-G01		SCUFFGUARD, BAGWELL, FRONT .....	1
67	71761-G01		BAGWELL, INSERT .....	1
68				
69	71314-G01		SCUFFGUARD, BAGWELL, SIDE, PASSENGER SIDE.....	1
70	71314-G02		SCUFFGUARD, BAGWELL, SIDE, DRIVER'S SIDE.....	1
71	16816-G1		RATCHET FASTENER.....	26
72				
73	75126-G01		SCUFFGUARD, FENDER, DRIVER'S SIDE.....	1
74	75126-G02		SCUFFGUARD, FENDER, PASSENGER SIDE .....	1
75	16816-G2		RATCHET FASTENER.....	8
76				
77	71353-G**		ACCESS PANEL .....	1
78	71002-G01		SCREW, #8 X 5/8 LG.....	5
79	71364-G02		CLIP, "J" .....	1
80	10570-G12		RIVET, 1/4 X 1/2 LG.....	4
81	10570-G10		RIVET, 5/32".....	6
82	18436-G1		RIVET, DRIVE, PLASTIC, 1/4 X 3/4 LG.....	2
83	71609-G01		PLATE, HINGE.....	2
84	10570-G11		RIVET, 3/16 X 3/4 LG.....	4
85	00571-G2		WASHER, 5/16.....	4
86	71456-G01		BUMPER, REAR, NOTCHED (4 CADDY).....	1
87	71451-G01		BUMPER, REAR.....	1
88	71398-G01		BOLT, 1/4 - 20 X 1 1/4 LG. ....	4
89	71455-G01		PLUG, COVER, BUMPER .....	4
90	71055-G01		RIVET, 3/16 .....	2

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1	2	3	4	5	DESCRIPTION	QTY.
91								
92								
93	71501-G01						ROCKER PANEL, PASSENGER SIDE .....	1
94	71502-G01						ROCKER PANEL, DRIVER'S SIDE .....	1
95	71507-G01						SILL PLATE, ROCKER PANEL, PASSENGER SIDE.....	1
96	71507-G02						SILL PLATE, ROCKER PANEL, DRIVER'S SIDE.....	1
97	16705-G1						SCREW, STAINLESS STEEL, 1/4 - 20 X 1 LG.....	4
98	23726-G4						SPACER.....	4
99	00891-G2						NUT, LOCK, 1/4 - 20 .....	4
100								
101								
102	74126-G01						FRAME SUPPORT, VERTICAL, PASSENGER SIDE .....	1
103	74126-G02						FRAME SUPPORT, VERTICAL, DRIVER'S SIDE .....	1
104	00426-G8						BOLT, 3/8-16 X 1 LG. ....	2
105	00560-G1						WASHER, 3/8.....	10
106	11098-G5						NUT, LOCK, 3/8 - 16 .....	10
107	00427-G4						BOLT, 3/8 - 16 X 1 1/2 LG. ....	2
108	00769-G2						BOLT, CARRIAGE, 3/8 - 16 X 1 1/4 LG.....	2
109	74149-G01						PANEL, VALANCE .....	1
110	16816-G2						RIVET, PLASTIC .....	4
111	19853-G1						PLUG, END.....	2
112	70361-G01						FOOT REST ASSEMBLY (INCLUDES ITEMS 113 - 116) .....	1
113	74129-G01						REFLECTOR.....	1
114	74132-G01						LABEL, WARNING .....	1
115	70362-G01						MAT, FLOOR.....	1
116	70350-G01						FOOT REST .....	1
117	*						PLATE, SERIAL NUMBER.....	1
118	*						PLATE, EC .....	1
119								
120								

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.


When ordering parts, please specify the model and serial number of the product.


\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
121	00114-G6		SCREW, 1/4 - 14 X 3/4 LG.....	4
122	16816-G2		FASTENER .....	2
123				
124	27166-G02		FRONT SHIELD.....	1
125	71015-G01		BRACE, FRONT SHIELD.....	2
126	16469-G7		WASHER, 1/4.....	2
127				
128	23676-G1		DECAL, FREEDOM .....	AR
129	75178-G01		DECAL, 4 CADDY .....	AR
130	73162-G01		DECAL, DCS.....	AR
131				
132	23726-G7		SPACER.....	1
133	15058-G4		RIVET.....	2
134	23726-G6		SPACER.....	1

- 1 - INCLUDES ITEMS 2 - 27
- 4 - INCLUDES ITEMS 5 - 7
- 40 - INCLUDES ITEMS 42 - 52
- 55 - INCLUDES ITEMS 56 - 59
- 77 - INCLUDES ITEMS 78 - 89







THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
1	70263-G01		BRAKE PEDAL ASSEMBLY (INCLUDES ITEMS 2 - 27) VEHICLES WITH BRAKE LIGHTS .....	1
2	*		PEDAL, BRAKE.....	1
3	*		PEDAL, PARK BRAKE .....	1
4	70274-G01		BRAKE/PARK BRAKE PEDAL PAD KIT (INCLUDES ITEMS 5 - 7).....	1
5	*		PAD, BRAKE PEDAL .....	1
6	*		PAD, PARK BRAKE .....	1
7	15766-G1		RIVET, 3/8 x 15/32 LG. ....	9
8				
9	*		PLATE, BRAKE PEDAL.....	1
10	15932-G2		PIN, PARK BRAKE PEDAL .....	1
11	11737-G1		SPRING, TORSION, PARK BRAKE .....	2
12	12064-G1		PUSHNUT, 5/16.....	1
13	00737-G8		SCREW, #10 - 24 X 1 LG. ....	4
14	00739-G1		NUT, RUBBER, #10 - 24.....	2
15	22362-G3		STANDOFF, BRAKE PEDAL .....	2
16	27137-G01		SPRING, CONICAL.....	2
17	11098-G7		NUT, LOCK, #10 - 24.....	2
18	10606-G8		SWITCH, MICRO.....	1
19	00645-G2		SCREW, #6 - 32 X 1 1/4 LG. ....	2
20	00559-G3		WASHER, #6 .....	2
21	00565-G3		WASHER, LOCK, #6 .....	2
22	00525-G5		NUT, #6 - 32.....	2
23	*		SCREW, BRASS .....	2
24	00567-G3		WASHER, LOCK, #6 .....	6
25	14628-G1		TAB, FASTON, 5/16 X 5/16 LG. ....	2
26				
27	17618-G1		NYLON CLAMP .....	3
28				
29				

**BRAKE LINKAGE****Electric Vehicle**

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
30	70096-G01		BOLT, SHOULDER, 3/8 - 16 X 3 LG. ....	1
31	11079-G1		BUSHING, FLANGED .....	2
32	70138-G01		SPRING, TORSION .....	1
33	11098-G5		NUT, 3/8 - 16 .....	1
34	00643-G1		WASHER, 3/8.....	1
35	11027-G2		NUT, LOCK, 1/4 - 20 .....	2
36	70080-G01		CATCH BRACKET, PARK BRAKE .....	1
37	00414-G6		BOLT, 1/4 - 20 X 3/4 LG. ....	2
38				
39				
40	70272-G04		COMPENSATOR ASSEMBLY (INCLUDES ITEMS 42 - 54).....	1
41				
42	25882-G04		ROD, LINK.....	1
43	00532-G4		NUT, 5/16 - 24.....	2
44	11098-G9		NUT, LOCK, 5/16 - 24 .....	1
45				
46	*		YOKE, BRAKE.....	1
47	15121-G1		WASHER, 3/8 .....	2
48	23061-G2		TUBE .....	1
49	23463-G1		SPRING, COMPRESSION .....	1
50				
51	17979-G1		BUSHING, ACCELERATOR ROD .....	1
52				
53				
54	00963-G01		NUT, SPHERICAL, 5/16 - 24 .....	1
55	70273-G03		EQUALIZER AND BRAKE CABLE ASSEMBLY (INCLUDES ITEMS 56 - 59).....	1
56	28082-G01		BRACKET, EQUALIZER .....	1
57	*		CABLE, BRAKE, PASSENGER SIDE .....	1
58	*		CABLE, BRAKE DRIVER'S SIDE.....	1

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
59	28083-G01		BUMPER, BRAKE COMPENSATOR .....	2
60				
61	12305-G1		RING, RETAINING .....	4
62				
63	10097-G6		BEARING, FLANGED .....	2
64	25103-G1		CAM, KICK-OFF .....	1
65				
66	14134-G4		SPACER.....	1
67	00491-G4		SETSCREW, 1/4 - 20 X 1/2 LG.....	2
68				
69				
70				
71				
72	11027-G1		NUT, LOCK, 5/16 - 18 .....	1
73	70113-G01		ADJUSTABLE BUMPER.....	1
74	10386-G3		PIN, CLEVIS, 5/16 X 15/16 LG. ....	3
75	10387-G3		PIN, COTTER, 3/32 X 3/4 LG. ....	5
76	12416-G1		NYLON CLAMP .....	2
77	70264-G01		BRAKE PEDAL ASSEMBLY (INCLUDES ITEMS 78 - 88) VEHICLES WITHOUT BRAKE LIGHTS .....	1
78	11737-G1		SPRING, TORSION PARK BRAKE.....	2
79	12064-G1		PUSHNUT, 5/16.....	1
80				
81	15932-G2		PIN, PARK BRAKE .....	1
82	*		BRAKE PEDAL.....	1
83				
84	70274-G01		BRAKE/PARK BRAKE PEDAL PAD KIT (INCLUDES ITEMS 85 - 87).....	1
85	*		PAD, BRAKE PEDAL .....	1
86	*		PAD, PARK BRAKE PEDAL.....	1
87	15766-G1		RIVET, 3/8 X 15/32 LG.....	9

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.


\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.



ITEM	PART NO.	1	2	3	4	5	DESCRIPTION	QTY.
88	70265-G01						PARK BRAKE PEDAL .....	1
89	70098-G01						PIVOT, KICK OFF CAM .....	1
90								
91	10387-G3						PIN, COTTER, 3/32 X 3/4 LG. ....	2
92	00559-G8						WASHER, 5/16.....	2
93	20835-G1						WASHER, TEFLON.....	2
94								
95	17838-G1						BEARING .....	2
96	70097-G01						LINK, PARK BRAKE KICK-OFF .....	1



## NON DCS MODELS (EARLY PRODUCTION)



DCS MODELS  
(EARLY PRODUCTION)



THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
1	73036-G01		DIRECTION SELECTOR ASSEMBLY (INCLUDES ITEMS 2 - 46).....	1
2	00138-G4		SCREW, #6 - 32 X 1/2 LG. ....	3
3	00139-G8		SCREW, #6 - 32 X 2 LG. ....	4
4	00414-G8		BOLT, 1/4 - 20 X 1 LG.....	2
5				
6	00525-G5		NUT, #6 - 32.....	8
7	00532-G1		NUT, 1/4 - 20.....	2
8				
9				
10	00559-G7		WASHER, 1/4.....	4
11	00560-G1		WASHER, 3/8.....	1
12				
13	00565-G3		WASHER, LOCK, #6.....	8
14	00565-G7		WASHER, LOCK, 1/4.....	2
15				
16				
17	00567-G3		WASHER, LOCK, #6.....	4
18				
19	10606-G2		MICRO SWITCH, MS2 AND MS4.....	2
20				
21				
22	11098-G9		NUT, LOCK, 5/16 - 24.....	1
23	12806-G1		SPACER.....	4
24				
25	12835-G1		CAM.....	1
26				
27	*		SCREW.....	4
28	14390-G1		NUT, LOCK, 3/8 - 24.....	2
29	14628-G1		TAB, FASTON, 5/16 X 5/16.....	4
30				

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
31	14651-G1		CONTACT BOARD ASSEMBLY (INCLUDES ITEMS 32 - 34) .....	1
32	24940-G1		STOP.....	2
33	00565-G7		WASHER, LOCK, 1/4.....	2
34	00414-G6		BOLT, 1/4 - 20 X 3/4 LG. ....	2
35				
36	15461-G1		BRACKET, MOUNTING SUPPORT .....	1
37	15944-G3		BALL, BALL JOINT .....	1
38				
39				
40	73048-G01		BRACKET, COVER .....	1
41				
42	70232-G01		ARM, SHIFT LINKAGE.....	1
43				
44	73027-G01		SHAFT, DIRECTION SELECTOR .....	1
45	73031-G01		BRACKET, DIRECTION SELECTOR MOUNTING .....	1
46	73037-G01		BUZZER, REVERSE WARNING.....	1
47				
48	00438-G8		BOLT, 5/16 - 18 X 3/4 LG. ....	2
49	11098-G9		NUT, LOCK, 5/16 - 24 .....	2
50	14444-G3		SOCKET, BALL JOINT.....	2
51				
52	00544-G4		NUT, 5/16 - 24 .....	2
53	10697-G8		ROD, LINKAGE.....	1
54	15944-G3		BALL, JOINT BALL .....	1
55	70232-G02		ARM, SHIFT LINKAGE .....	1
56				
57	25664-G2		BEARING .....	1
58	14390-G1		NUT, LOCK, 3/8 - 24 .....	1
59	70233-G01		SHAFT, DIRECTION SELECTOR.....	1
60				

# DIRECTION SELECTOR

Electric Vehicle

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.


\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
61	71905-G01		HANDLE, DIRECTION SELECTOR.....	1
62	00740-G4		SCREW, STAINLESS STEEL, #10 - 32 X 1/2 LG.....	1
63				
64	00559-G8		WASHER, 5/16.....	1
65	16469-G7		WASHER, FENDER.....	1
66	73049-G01		COVER, DIRECTION SELECTOR .....	1
67	00114-G6		SCREW, 1/4 - 14 x 3/4 LG. ....	1
68				
69	14601-G16		RIVET, 5/32 (ITEMS 69 - 86 FOR USE ON DCS MODEL ONLY) .....	2
70	73037-G02		BUZZER .....	1
71	32043-G2		BRACKET, BUZZER .....	1
72	00565-G3		WASHER, LOCK, #6.....	2
73	00525-G5		NUT, #6 - 32 .....	2
74	00138-G4		SCREW, #6 - 32 X 1/2 LG.....	2
75				
76	73127-G01		LABEL, DIRECTION SELECTOR .....	1
77				
78	73134-G01		ADAPTER, SEAT WRAP.....	1
79	73133-G01		ADAPTER, DIRECTION SELECTOR SWITCH .....	1
80	31539-G1		CLAMP, NYLON .....	1
81	17618-G1		CLAMP, NYLON .....	2
82				
83	73130-G01		BOOT, RUBBER.....	1
84				
85	73128-G02		KNOB, DIRECTION SELECTOR .....	1
86	73151-G01		BLOCK, CONTACT SWITCH.....	1



NON DCS MODELS  
(LATE PRODUCTION)



THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
1	73036-G01		DIRECTION SELECTOR ASSEMBLY (INCLUDES ITEMS 2 - 46) .....	1
2	00138-G6		SCREW, #6 - 32 X 3/4 LG. ....	3
3	00139-G8		SCREW, #6 - 32 X 2 LG. ....	4
4	00414-G8		BOLT, 1/4 - 20 X 1 LG. ....	2
5				
6	00525-G5		NUT, #6 - 32.....	8
7	00532-G1		NUT, 1/4 - 20.....	2
8				
9				
10	00559-G7		WASHER, 1/4.....	4
11	00560-G1		WASHER, 3/8.....	1
12				
13	00565-G3		WASHER, LOCK, #6 .....	8
14	00565-G7		WASHER, LOCK, 1/4 .....	2
15				
16				
17	00567-G3		WASHER, LOCK, #6 .....	4
18				
19	10606-G2		MICRO SWITCH, MS2 AND MS4 .....	2
20				
21				
22	11098-G9		NUT, LOCK, 5/16 - 24.....	1
23	12806-G1		SPACER .....	4
24				
25	12835-G1		CAM.....	1
26				
27	*		SCREW .....	4
28	14390-G1		NUT, LOCK, 3/8 - 24.....	2
29	14628-G1		TAB, FASTON, 5/16 X 5/16 .....	4
30				

# DIRECTION SELECTOR

# Electric Vehicle

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
31	14651-G1		CONTACT BOARD ASSEMBLY (INCLUDES ITEMS 32 - 34) .....	1
32	24940-G1		STOP.....	2
33	00565-G7		WASHER, LOCK, 1/4 .....	2
34	00414-G6		BOLT, 1/4 - 20 X 3/4 LG. ....	2
35				
36	15461-G1		BRACKET, MOUNTING SUPPORT .....	1
37				
38				
39				
40	73048-G01		BRACKET, COVER.....	1
41				
42	70232-G01		ARM, SHIFT LINKAGE .....	1
43				
44	73027-G01		SHAFT, DIRECTION SELECTOR .....	1
45	73031-G01		BRACKET, DIRECTION SELECTOR MOUNTING.....	1
46	73037-G01		BUZZER, REVERSE WARNING .....	1
47				
48	00438-G6		BOLT, 5/16 - 18 X 3/4 LG. ....	2
49	11098-G6		NUT, LOCK, 5/16 - 18 .....	2
50	00571-G2		WASHER, 5/16.....	2
51				
52				
53	70313-G01		ROD, LINKAGE.....	1
54	22754-G3		BUSHING .....	2
55	70334-G01		ARM, BENT SHIFT LINKAGE .....	1
56				
57	25664-G2		BEARING .....	1
58	14390-G1		NUT, LOCK, 3/8 - 24 .....	2
59	70233-G01		SHAFT, DIRECTION SELECTOR.....	1
60				


THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
61	71905-G01		HANDLE, DIRECTION SELECTOR .....	1
62	00740-G4		SCREW, STAINLESS STEEL, #10 - 32 X 1/2 LG.....	1
63				
64				
65	16469-G7		WASHER, FENDER, STAINLESS STEEL.....	1
66	73049-G01		COVER, DIRECTION SELECTOR .....	1
67	00114-G6		SCREW, 1/4 - 14 x 3/4 LG. ....	1



THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.


When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.


G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
1	73180-G01		DIRECTION SELECTOR ASSEMBLY (INCLUDES ITEMS 2 - 18) .....	
2	73179-G01		BRACKET.....	1
3	73167-G01		CAM.....	1
4	73171-G01		SHAFT.....	1
5	73037-G02		BUZZER .....	1
6	73195-G01		SWITCH.....	1
7	73194-G01		SWITCH.....	1
8	73188-G01		SPRING, COMPRESSION.....	1
9	25664-G1		BUSHING .....	1
10	00771-G4		WASHER, NYLON, 1/2.....	1
11	73181-G01		WASHER, 1/2.....	1
12	14390-G1		NUT, LOCK, 3/8-24.....	1
13	00565-G3		WASHER, LOCK, 3/8 .....	2
14	00525-G5		NUT, #6.....	2
15	00138-G5		SCREW, #6 - 32 X 5/8 LG. ....	2
16	73182-G01		WASHER, NYLON, 1 3/8.....	1
17	17618-G1		CLAMP, NYLON .....	3
18	00559-G3		WASHER, #6.....	2
19				
20	28272-G01		BOLT, 1/4 - 20 X 5/8 LG. ....	2
21				
22	11027-G2		NUT, LOCK, 1/4 - 20 .....	2
23				
24	00559-G7		WASHER, 1/4.....	2
25	71905-G01		HANDLE, DIRECTION SELECTOR .....	1
26	00740-G4		SCREW, STAINLESS STEEL, #10 - 32 X 1/2 LG.....	1




**POWERWISE™ AND  
POWERWISE™ +  
BATTERY CHARGERS**




**TOTAL CHARGE®  
BATTERY CHARGERS**



**THROUGH FRAME  
TO ACCELERATOR PEDAL**





BRAKE LIGHT SWITCH CONNECTIONS

INSTALL BLK WIRE TO NORMALLY OPEN  
INSTALL RED WIRE TO COMMON

CONNECT RED WIRE FROM  
BRAKE PEDAL MICRO SWITCH  
TO RED WIRE FROM  
ACCESSORY HARNESS

CONNECT BLK WIRE FROM  
BRAKE PEDAL MICRO SWITCH  
TO BRN WIRE FROM  
ACCESSORY HARNESS

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
1	18724-G1		RECEPTACLE HOLDER.....	1
2	00645-G2		SCREW, #6 - 32 X 1 1/4 LG.....	2
3	00559-G3		WASHER, #6.....	2
4	14390-G9		NUT, LOCK, #6 - 32 .....	2
5				
6	00702-G2		NUT, 5/16 - 24 .....	12
7	25972-G32		WIRE .....	1
8	25972-G40		WIRE .....	4
9				
10	00567-G8		WASHER, LOCK, 5/16.....	8
11	00532-G3		NUT, 5/16 - 18 .....	8
12				
13	27327-G01		CLAMP, TWISTED .....	2
14	10570-G11		RIVET, STAINLESS STEEL, 5/16 .....	1
15				
16	73145-G01		HARNESS, KEY SWITCH (DCS MODEL ONLY) .....	1
17	73041-G01		HARNESS, KEY SWITCH (FLEET) .....	1
18	00568-G6		WASHER, LOCK, 3/4 .....	1
19	17062-G1		KEY, IGNITION (SET) .....	AR
20	17137-G1		NUT, FACE.....	1
21				
22	17618-G1		CLAMP, NYLON.....	1
23	17421-G1		IGNITION SWITCH KIT, INCLUDES ALL MOUNTING HARDWARE (FOR FREEDOM SEE SECTION S - HORN AND LIGHTING) .....	1
24	33623-G02		RIVET, DRIVE .....	2
25	71145-G01		DECAL, CONSOLE INSERT PLATE.....	1
26	73030-G01		PLATE, CONSOLE INSERT (KEY ONLY).....	1
27	70045-G01		RETAINER, BATTERY .....	1
28	70046-G01		BATTERY RACK .....	1
29	11027-G1		NUT, LOCK, 5/16 - 18 .....	2

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1	2	3	4	5	DESCRIPTION	QTY.
30	XXXXX-G**						BATTERY, 6 VOLT .....	6
31								
32	70121-G01						BOLT, HOLD DOWN .....	2
33	17618-G1						CLAMP, NYLON .....	1
34	24605-G1						WIRE HARNESS, BRAKE .....	1
35	73063-G01						CHARGER RECEPTACLE AND HARNESS ASSY. (FOR USE ON POWERWISE NON-DCS MODEL ONLY).....	1
36	73149-G01						CHARGER RECEPTACLE AND HARNESS ASSY. (FOR USE ON DCS MODEL ONLY).....	1
37	14601-G10						RIVET, 5/32 .....	4
38	17618-G1						CLAMP, NYLON .....	3
39	25972-G32						WIRE, BL- TO B-.....	1



THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
1	70001-G01		FRONT AXLE.....	1
2	10194-G1		BUSHING, RUBBER SHOCK ABSORBER .....	8
3	10435-G1		WASHER, SHOCK ABSORBER.....	8
4	00532-G6		NUT, 3/8 - 24 .....	4
5	00463-G6		BOLT, 7/16 - 14 X 1 3/4 LG. ....	6
6	00734-G1		NUT, LOCK, 7/16 - 14 .....	12
7				
8	70163-G02		PLATE, SPRING .....	4
9	10387-G2		PIN, COTTER, 3/32 X 1 LG. ....	2
10				
11	70220-G01		SPINDLE ASSEMBLY, DRIVER'S SIDE (INCLUDES ITEMS 12 - 25) .....	1
12	*		SPINDLE, DRIVER'S SIDE .....	1
13	16623-G1		BEARING.....	2
14	10389-G3		GREASE FITTING.....	1
15	19932-G1		WHEEL HUB ASSEMBLY (INCLUDES ITEMS 17, 18).....	1
16				
17	19862-G1		WHEEL BOLT, 1/2 - 20.....	4
18	50892-G1		BEARING AND RACE ASSEMBLY (COMPLETE) .....	1
19				
20				
21	25146-G1		SEAL, GREASE.....	1
22				
23	12093-G1		NUT, SLOTTED, 17/32.....	1
24				
25	00798-G8		PIN, COTTER, 5/32 X 1 3/4 LG. ....	1
26	70221-G01		SPINDLE ASSEMBLY, PASSENGER SIDE (INCLUDES ITEMS 13 - 25 AND 27) .....	1
27	*		SPINDLE, PASSENGER SIDE.....	1
28				
29	70327-G01		PIN, SPINDLE, 1/2 - 13 X 5 1/2 LG. ....	2

# FRONT SUSPENSION

# Electric Vehicle

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.


When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.


G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
30	16982-G1		WASHER, THRUST .....	2
31	70328-G01		TUBE, SPINDLE PIN .....	2
32				
33	00571-G5		WASHER, 1/2.....	4
34				
35	14390-G6		NUT, LOCK, 1/2 -13 .....	2
36	70049-G01		SPRING, LEAF.....	2
37				
38	00463-G4		BOLT, 7/16 - 14 X 1 1/2 LG. ....	6
39	70324-G01		SHOCK ABSORBER.....	2
40	12091-G1		CAP, SPINDLE .....	2
41	14723-G1		NUT, LUG, 1/2 - 20.....	8










- 17 - INCLUDES ITEM 18
- 62 - INCLUDES ITEMS 63 - 69
- 65 - INCLUDES ITEMS 67 - 69





- WHT TO BLK FROM HARNESS - BOTH SIDES
- BLK TO BLU/WHT FROM HARNESS - BOTH SIDES
- RED TO WHT FROM HARNESS - DRIVER'S SIDE
- RED TO YEL FROM HARNESS - PASSENGER SIDE

















THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
1	22674-G1		FUSE BLOCK .....	1
2	71010-G01		RIVET, 5/32 X 3/8 LG.....	2
3	18392-G1		FUSE, 15 AMP .....	3
4	*		TAPE, VINYL.....	AR
5	20965-G3		COVER, STEERING COLUMN (VEHICLES WITH TURN SIGNALS) .....	1
6	17318-G2		CAP AND NUT, HORN SWITCH.....	1
7	32860-G1		HORN (WITH MOUNTING HARDWARE).....	1
8	00559-G8		WASHER, 5/16.....	1
9				
10				
11	17318-G1		SWITCH, HORN .....	1
12	27068-G01		BOOT, HORN SWITCH.....	1
13	19233-G1		PLATE, HORN SWITCH .....	1
14	14601-G7		RIVET, STAINLESS STEEL, 9/16 .....	2
15	17618-G1		CLAMP, NYLON.....	2
16				
17	17867-G1		TURN SIGNAL (WITH MOUNTING HARDWARE) .....	1
18	21640-G1		FLASHER, TURN SIGNAL .....	1
19	00414-G6		SCREW, 1/4 - 20 X 3/4 LG.....	2
20	11027-G2		NUT, LOCK, 1/4 - 20 .....	2
21	74001-G01		LIGHTBAR .....	1
22	74002-G02		BRACKET, LIGHTBAR, DRIVER'S SIDE .....	1
23	74002-G01		BRACKET, LIGHTBAR, PASSENGER SIDE .....	1
24	00114-G6		SCREW, 1/4 - 14 X 3/4 LG.....	8
25				
26				
27				
28	25978-G74		WIRE.....	1
29				
30				

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1	2	3	4	5	DESCRIPTION	QTY.
31								
32								
33								
34	33636-G01						STATE OF CHARGE METER .....	1
35								
36								
37								
38	74371-G01						BEZEL, TAILLIGHT, DRIVER'S SIDE .....	1
39	74371-G02						BEZEL, TAILLIGHT, PASSENGER SIDE .....	1
40	22260-G2						TAILLIGHT ASSEMBLY, COMPLETE .....	1
41	14601-G11						RIVET, 3/16 X 5/8 LG. ....	2
42	21759-G1						BULB, REPLACEMENT, TAILLIGHT .....	AR
43								
44	73043-G01						HARNES, ACCESSORY.....	1
45								
46								
47	00568-G6						WASHER, LOCK, 3/4 .....	1
48	17063-G1						IGNITION KEY (SET) .....	AR
49	17137-G1						NUT, FACE .....	1
50								
51								
52								
53	17421-G1						SWITCH, IGNITION (INCLUDES ALL HARDWARE).....	1
54	33639-G01						SWITCH, IGNITION (WITH LIGHTS).....	1
55								
56								
57	74004-G01						BULB, REPLACEMENT, HEADLIGHT .....	AR
58	74005-G01						BULB, REPLACEMENT, MARKER LIGHT .....	AR
59	74006-G01						BULB, REPLACEMENT, TURNLIGHT .....	AR
60								

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.


When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1	2	3	4	5	DESCRIPTION	QTY.
61								
62								
63								
64	73030-G02						PLATE, CONSOLE INSERT, STATE OF CHARGE METER.....	1
65	71123-G01						DECAL, CONSOLE PLATE, STATE OF CHARGE METER WITHOUT LIGHTS .....	1
66	71129-G01						DECAL, CONSOLE PLATE, STATE OF CHARGE METER WITH LIGHTS.....	1
67								
68	10570-G11						RIVET, 3/16 X 3/4 LG.....	2
69	21573-G1						HOURMETER.....	1
70	74019-G01						BRACKET, HOURMETER .....	1
71								
72	75117-G02						HARNES, HOUR METER.....	1
73								
74								
75								
76	73030-G01						PLATE, STANDARD CONSOLE INSERT MOUNT.....	1
77								
78	71145-G01						DECAL, CONSOLE INSERT .....	1

2 - INCLUDES ITEMS 6 - 25  
4 - INCLUDES ITEMS 6 - 25




THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
1	73124-G01		MOTOR, COMPLETE (DCS MODEL ONLY).....	1
2	27045-G01		MOTOR, 2.0 HP, COMPLETE (INCLUDES ITEMS 6 - 25).....	1
3				
4	73172-G01		MOTOR, 2.7 HP, COMPLETE (INCLUDES ITEMS 6 - 25).....	1
5				
6	27630-G01		END SHIELD .....	1
7	*		ARMATURE.....	1
8	*		STATOR COMPLETE (INCLUDES ITEMS 10 AND 17).....	1
9				
10	*		STATOR SHELL AND WINDING .....	1
11				
12	27630-G05		BRUSH (WITH TERM SCREW).....	2
13	27630-G06		NUT, 1/4 - 20.....	4
14	27630-G07		WASHER, 1/4.....	4
15	27630-G08		BUSHING, INSULATED .....	2
16				
17	27630-G09		BRUSH, RIGGING.....	1
18	27630-G10		SCREW, BRUSH HOLDER.....	2
19	27630-G11		BUSHING, INSULATED .....	2
20	27630-G12		RETAINER, BEARING.....	1
21	16918-G1		BALL BEARING.....	1
22				
23	27630-G14		END SHIELD .....	1
24	27630-G15		SCREW, CLAMP .....	4
25	27630-G16		SCREW, BEARING RETAINER .....	2




THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1	2	3	4	5	DESCRIPTION	QTY.
1								
2	28095-G01						MOLY LUBE, 2 OZ.....	AR
3								
4								
5	00559-G7						WASHER, 1/4.....	3
6	00565-G7						WASHER, LOCK, 1/4.....	3
7	00797-G2						BOLT, 1/4 - 20 X 1 1/4 LG.....	3
8								
9	73069-G01						REAR AXLE ASSEMBLY (INCLUDES ITEMS 10 - 21).....	1
10	24261-G1						BUMPER SPLINE.....	1
11								
12	25227-G1						WASHER.....	1
13	25226-G1						PLUG, FILL/CHECK.....	1
14	73050-G01						VENT ASSEMBLY (PUSH IN).....	1
15								
16	72036-G01						BRACKET, BRAKE CABLE, PASSENGER SIDE.....	1
17	72036-G02						BRACKET, BRAKE CABLE, DRIVER'S SIDE.....	1
18	25228-G1						COVER, DIFFERENTIAL.....	1
19	20377-G12						AXLE SHAFT, PASSENGER SIDE.....	1
20	20377-G11						AXLE SHAFT, DRIVER'S SIDE.....	1
21	15558-G1						SCREW, 5/16 - 18 X 3/4 LG.....	10



THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.


When ordering parts, please specify the model and serial number of the product.


\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.


ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
1	70247-G01		SPRING, LEAF .....	2
2	74135-G01		SPRING, LEAF (USE ON 4 CADDY ONLY).....	2
3	72029-G01		"U" BOLT, 3/8 - 16.....	4
4	74124-G01		"U" BOLT, 3/8 - 16 (USE ON 4 CADDY ONLY).....	4
5				
6	11098-G5		NUT, LOCK, 3/8 - 16 .....	12
7	70291-G01		BUSHING, RUBBER (LEAF SPRING).....	12
8	70290-G01		SHACKLE PLATE.....	4
9				
10	70289-G02		SPACER.....	4
11				
12	00429-G4		SCREW, 3/8 - 16 X 3 1/2 LG.....	4
13				
14	12262-G1		NUT, LOCK, 3/8 - 16 .....	2
15	14158-G1		BOLT, SHOULDER, 7/16 - 14 X 3 1/4 LG. ....	2
16				
17	70324-G01		SHOCK ABSORBER .....	2
18				
19	10194-G1		BUSHING, RUBBER, SHOCK ABSORBER .....	8
20	10435-G1		WASHER, SHOCK ABSORBER.....	8
21				
22	00532-G6		NUT, 3/8 - 24 .....	4
23				
24	12262-G1		NUT, LOCK, FLANGED, 3/8 - 16 .....	2

1 - INCLUDES ITEMS 3 - 17  
25 - INCLUDES ITEMS 26 - 34






ITEMS 55 - 85 ARE FOR USE ON 4 CADDY MODELS ONLY




ITEMS 55 - 85 ARE FOR USE ON 4 CADDY MODELS ONLY

EXISTING SEAT BACK



79 - INCLUDES ITEMS 26 - 34

A



When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
1	71611-G**		SEAT BOTTOM ASSEMBLY (INCLUDES ITEMS 3 - 17) .....	1
2				
3	*		NUT, TEE .....	8
4				
5	17074-G1		BUMPER, SEAT .....	2
6				
7				
8	*		STAPLE, FLAT .....	110
9	*		STAPLE, FLAT .....	46
10				
11				
12	71012-G01		VINYL TRIM, SEAT BOTTOM.....	1
13	71602-G**		VINYL SEAT BOTTOM COVER .....	1
14	*		FOAM PADDING, SEAT BOTTOM .....	1
15	*		SEAT BOTTOM, WOOD .....	1
16				
17	71608-G01		REAR TRIM, SEAT .....	1
18				
19				
20				
21	00414-G8		BOLT, 1/4 - 20 X 1 LG. ....	4
22	00565-G7		WASHER, LOCK, 1/4 .....	4
23	11027-G2		NUT, LOCK, 1/4 - 20 .....	2
24	16816-G1		FASTENER, PLASTIC RATCHET.....	2
25	71751-G**		SEAT BACK ASSEMBLY (INCLUDES ITEMS 26 - 34).....	1
26	*		STAPLE, FLAT .....	95
27				
28	71752-G01		PLASTIC, REAR COVER SEAT BACK .....	1
29	71753-G**		VINYL SEAT BACK COVER .....	1
30	*		FOAM PADDING, SEAT BACK.....	1

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1	2	3	4	5	DESCRIPTION	QTY.
31								
32	*						SEAT BACK, WOOD .....	1
33	71002-G01						SCREW, #8 X 1 LG. ....	4
34	*						NUT, TEE.....	4
35								
36								
37								
38	71802-G01						BOLT, 3/8 - 16 X 2 1/4 LG.....	4
39	71811-G02						BRACKET, SEAT SUPPORT .....	2
40	71821-G01						BOLT, CARRIAGE, 1/4 - 20 X 1 1/2 LG. ....	2
41	71851-G01						BRACKET, BAG HOLDER.....	1
42	71853-G01						STRAP, BAG RETAINER.....	1
43	71856-G01						CLAMP, BAG RETAINER.....	2
44								
45	00720-G08						SCREW, #12 - 14 X 1 LG.....	4
46	00414-G8						BOLT, 1/4 - 20 X 1 LG.....	8
47	00565-G7						WASHER, LOCK, 1/4.....	8
48	00559-G7						WASHER, 1/4.....	8
49	71701-G01						HIP RESTRAINT, PASSENGER SIDE.....	1
50	71702-G01						HIP RESTRAINT, DRIVER'S SIDE .....	1
51								
52								
53	71610-G01						HINGE, SEAT.....	2
54								
55	74111-G01						SUPPORT, SEAT BACK (ITEMS 55 - 85 FOR USE ON 4 CADDY MODELS ONLY) .....	2
56	00414-G8						BOLT, 1/4 - 20 X 1 LG.....	4
57	00565-G7						WASHER, LOCK, 1/4.....	4
58	00559-G7						WASHER, 1/4.....	4
59	70113-G01						BUMPER, RUBBER.....	4

# SEATING AND BAGRACK

# Electric Vehicle



When ordering parts, please specify the model and serial number of the product.


\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
60	11027-G1		NUT, LOCK, 5/16 - 18 .....	6
61	01006-G02		BOLT, 3/8 - 16 X 1 1/2 LG. ....	4
62	00560-G1		WASHER, 3/8.....	4
63				
64	74131-G**		SEAT ASSEMBLY (INCLUDES ITEMS 65 - 79).....	1
65	74139-G**		SEAT BOTTOM ASSEMBLY (INCLUDES ITEMS 66 - 77).....	1
66	71602-G**		VINYL COVER, SEAT BOTTOM.....	1
67	*		FOAM, SEAT BOTTOM.....	1
68	*		WOOD, SEAT BOTTOM .....	1
69	*		NUT, TEE.....	16
70	74140-G01		TRIM, SEAT, FRONT.....	1
71	*		STAPLE, FLAT .....	110
72	*		STAPLE, FLAT .....	48
73	71702-G01		HIP RESTRAINT, DRIVER'S SIDE .....	1
74	71701-G01		HIP RESTRAINT, PASSENGER SIDE .....	1
75	00414-G8		BOLT, 1/4 - 20 X 1 LG. ....	8
76	71608-G01		TRIM, SEAT, REAR.....	1
77	00559-G7		WASHER, 1/4.....	8
78	00565-G7		WASHER, LOCK, 1/4.....	8
79	71751-G**		SEAT BACK ASSEMBLY (INCLUDES ITEMS 26 - 34) .....	1
80	74117-G01		BRACKET, REAR SEAT SUPPORT .....	2
81	00414-G8		BOLT, 1/4 - 20 X 1 LG.....	12
82	00565-G2		WASHER, LOCK, #5 .....	12
83	00559-G7		WASHER, 1/4 .....	12
84	17838-G1		BUSHING, NYLON.....	4
85	74134-G01		PIN, HITCH .....	2
86	70364-G01		SPACER.....	2







THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
1	73056-G04		ELECTRONIC SPEED CONTROL ASSEMBLY, MID 1996 AND LATER (INCLUDES ITEMS 2 - 31).....	1
2	*		WASHER, LOCK, #10 .....	2
3	*		NUT, 10 - 32.....	2
4				
5	30353-G1		DIODE.....	1
6	21764-G1		RESISTOR.....	1
7	73103-G02		WIRE HARNESS, CONTROL.....	1
8	*		NUT, 5/16 - 24.....	2
9				
10	*		WASHER, LOCK, 5/16 .....	2
11	25972-G02		WIRE, SOL - B+.....	1
12	25978-G10		WIRE, SOL - B-.....	1
13	11027-G2		NUT, 1/4 - 20.....	2
14				
15	27855-G01		SOLENOID .....	1
16	73026-G01		HEATSINK .....	1
17	25864-G02		ELECTRONIC SPEED CONTROLLER .....	1
18	73190-G01		PAD, THERMAL MOUNTING .....	1
19	71102-G01		BOLT, 1/4 - 20 X 3/4 LG.....	2
20	73028-G01		COVER .....	1
21	31539-G1		WIRE TIE .....	1
22	73053-G01		MOUNT.....	1
23				
24	71102-G01		BOLT, 1/4 - 20 X 3/4 LG.....	3
25	73039-G02		WIRE HARNESS, POWER.....	1
26				
27	00270-G5		BOLT, 5/16 - 18 X 5/8 LG.....	4
28				
29	11027-G1		NUT, 5/16 - 18.....	4



THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.


When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1	2	3	4	5	DESCRIPTION	QTY.
30								
31	25866-G01						BRACKET, SOLENOID.....	1
32								
33	71102-G01						BOLT, 1/4 - 20 X 3/4 LG. ....	4
34	73040-G01						WIRE HARNESS, CONTROL.....	1





THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
1	73056-G02		ELECTRONIC SPEED CONTROL ASSEMBLY, EARLY TO MID 1996 (INCLUDES ITEMS 2 - 31).....	1
2	*		WASHER, LOCK, #10 .....	2
3	*		NUT, 10 - 32.....	2
4				
5	30353-G1		DIODE.....	1
6	21764-G1		RESISTOR.....	1
7	73103-G02		WIRE HARNESS, CONTROL.....	1
8	*		NUT, 5/16 - 24.....	2
9				
10	*		WASHER, LOCK, 5/16 .....	2
11	25972-G02		WIRE, SOL - B+ .....	1
12	25978-G10		WIRE, SOL - B-.....	1
13	11027-G2		NUT, 1/4 - 20.....	2
14				
15	27855-G01		SOLENOID .....	1
16	73026-G01		HEATSINK .....	1
17	25864-G02		ELECTRONIC SPEED CONTROLLER .....	1
18	73190-G01		PAD, THERMAL MOUNTING .....	1
19	71102-G01		BOLT, 1/4 - 20 X 3/4 LG.....	2
20	73028-G01		COVER .....	1
21	31539-G1		WIRE TIE .....	1
22	73053-G01		MOUNT.....	1
23				
24	71102-G01		BOLT, 1/4 - 20 X 3/4 LG.....	3
25	73039-G01		WIRE HARNESS, POWER.....	1
26				
27	00270-G5		BOLT, 5/16 - 18 X 5/8 LG.....	4
28				
29	11027-G1		NUT, 5/16 - 18.....	4


THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.



\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
30			
31	25866-G01	BRACKET, SOLENOID.....	1
32			
33	71102-G01	BOLT, 1/4 - 20 X 3/4 LG.....	4
34	73040-G01	WIRE HARNESS, CONTROL.....	1



- 1 - INCLUDES ITEMS 2 - 41
- 32 - INCLUDES ITEMS 33 - 41
- 36 - INCLUDES ITEMS 37, 38



THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
1	73198-G01		SPEED CONTROL ASSEMBLY (INCLUDES ITEMS 2 - 41) .....	1
2	*		WASHER, LOCK, #10 .....	2
3	*		NUT, 10 - 32.....	2
4				
5	12914-G1		TAB, TERMINAL.....	1
6	73150-G01		RESISTOR.....	1
7				
8	*		NUT, 5/16 - 24.....	2
9				
10	*		WASHER, LOCK, 5/16 .....	2
11	25972-G56		WIRE, C - B+ .....	1
12				
13	11027-G2		NUT, 1/4 - 20.....	2
14				
15	27855-G01		SOLENOID .....	1
16	73026-G01		HEATSINK .....	1
17	73144-G01		SPEED CONTROLLER .....	1
18	73190-G01		PAD, THERMAL MOUNTING .....	1
19	71102-G01		BOLT, 1/4 - 20 X 3/4 LG.....	5
20				
21	31539-G1		WIRE TIE .....	1
22	73053-G01		MOUNT.....	1
23				
24	71102-G03		BOLT, 1/4 - 20 X 1 1/4 LG.....	3
25	73152-G01		WIRE HARNESS, POWER.....	1
26	73153-G01		WIRE HARNESS, CONTROL (THRU JUNE 1995).....	1
27	73191-G01		WIRE HARNESS, CONTROL (FROM JULY 1995) .....	1
28	00270-G5		BOLT, 5/16 - 18 X 5/8 LG.....	3
29	11027-G1		NUT, 5/16 - 18.....	3
30				

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.


\* Indicates a component that is not available as an individual part.



G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1	2	3	4	5	DESCRIPTION	QTY.
31	25866-G01						BRACKET, SOLENOID.....	1
32	73137-G01						COVER ASSEMBLY (INCLUDES ITEMS 33 - 41) .....	1
33	73028-G02						COVER (WITH GASKET) .....	1
34	73132-G01						LABEL, TOW SWITCH.....	1
35								
36	73125-G01						SWITCH, TOGGLE WITH SEAL (INCLUDES ITEMS 37, 38) .....	1
37	*						SCREW, #5 - 40 .....	4
38	*						NUT, 15/32 - 32.....	4
39	73139-G01						NUT, SEAL .....	1
40	73138-G01						HARNESS, TOW SWITCH .....	1
41	17618-G1						CLAMP, NYLON.....	1
42								
43	71102-G01						BOLT, 1/4 - 20 X 3/4 LG. ....	4
44	25972-G22						WIRE, BL+ TO SOL .....	1

FOR USE ON FREEDOM VEHICLES ONLY

1 - INCLUDES ITEMS 2 - 28





SOLENOID DETAILS

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
1	73055-G02		SOLID STATE SPEED CONTROL ASSEMBLY - FOR USE ON FREEDOM VEHICLES ONLY (INCLUDES ITEMS 2 - 28) .....	1
2	*		WASHER, LOCK, #10 .....	2
3	*		WASHER, 5/16 .....	2
4				
5	30353-G1		DIODE.....	1
6	21764-G1		RESISTOR.....	1
7	28325-G01		WIRE HARNESS, CHARGER CONNECTOR.....	1
8	*		NUT, 5/16 - 24.....	2
9	*		NUT, #10 - 32.....	2
10	00559-G7		WASHER, 1/4 .....	2
11	25978-G88		WIRE, FROM SOL.....	1
12	25972-G02		WIRE, SOL - B+.....	1
13	25978-G10		WIRE, FROM SOL.....	1
14	11027-G2		NUT, 1/4 - 20.....	6
15				
16	20468-G1		SOLENOID .....	1
17				
18	73060-G01		SOLID STATE SPEED CONTROLLER .....	1
19	11027-G1		NUT, LOCK, 5/16 - 18.....	4
20				
21	74014-G01		MOUNT, CONTROLLER.....	1
22				
23				
24	00414-G5		SCREW, 1/4 - 20 X 5/8 LG. ....	4
25				
26	73095-G02		WIRE HARNESS, POWER.....	1
27				
28	00270-G5		BOLT, 5/16 - 18 X 5/8 LG.....	4
29				

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.


When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
30	23723-G2		COVER, SOLID STATE SPEED CONTROL.....	1
31	16469-G1		WASHER, FENDER.....	1
32	14419-G1		WING NUT.....	1
33				
34	00715-G2		SCREW, 1/4 - 20 X 5/8 LG.....	4
35	11027-G2		NUT, 1/4 - 20.....	4

- 1 - INCLUDES ITEMS 2 - 28
- 2 - INCLUDES ITEMS 3 - 6
- 20 - INCLUDES ITEMS 21 - 28
- 30 - INCLUDES ITEMS 31 - 43
- 63 - INCLUDES ITEMS 64 - 68



When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
1	70314-G01		STEERING BOX ASSEMBLY, COMPLETE (INCLUDES ITEMS 2 - 10) .....	1
2	75364-G01		STEERING HOUSING (INCLUDES ITEMS 3-6).....	1
3	*		BEARING, SLEEVE .....	1
4	*		BEARING SLEEVE .....	1
5	*		BEARING, FLANGED .....	1
6	10389-G3		GREASE FITTING .....	1
7				
8	00426-G6		BOLT, 3/8 - 16 X .75 LG.....	2
9	18456-G1		GREASE FITTING, 90° .....	1
10	70177-G01		COVER, RACK GUIDE.....	1
11	70225-G01		GASKET, RACK GUIDE COVER.....	1
12	70178-G01		SPRING, COMPRESSION.....	1
13	70179-G01		GUIDE, RACK .....	1
14	11391-G1		CLAMP .....	1
15	70041-G01		COVER, RACK .....	1
16	11391-G1		CLAMP .....	1
17	70183-G01		RACK COVER BELLOWS.....	1
18	11391-G5		CLAMP .....	1
19				
20	70299-G01		STEERING GEAR KIT (INCLUDES ITEMS 21 - 28).....	1
21	*		GEAR PINION.....	1
22	*		BALL BEARING .....	1
23	*		EXTERNAL RETAINING RING .....	1
24	*		STEERING RACK.....	1
25	*		RACK BALL END (WITH NUT).....	1
26	*		NUT, 7/16 - 20 .....	1
27	*		90° GREASE FITTING.....	2
28	*		INTERNAL RETAINING RING .....	1
29				
30	70360-G01		STEERING SHAFT/COLUMN KIT (INCLUDES ITEMS 31 - 43).....	1

When ordering parts, please specify the model and serial number of the product.


\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1	2	3	4	5	DESCRIPTION	QTY.
31	14322-G3						STEERING SHAFT.....	1
32	70333-G01						STEERING COLUMN .....	1
33	70226-G01						COUPLING .....	1
34	00550-G1						LOCK NUT, 1/4 - 20 .....	2
35	70227-G01						BOLT, 1/4 - 20 X 7/8" LG.....	2
36	00118-G2						SCREW, #6 - 18 X 1/4" LG.....	1
37	70223-G01						STEERING HOUSING GASKET .....	1
38	00876-G2						BOLT, 3/8 - 16 X 1 1/4" LG.....	3
39	00878-G1						LOCK WASHER, 3/8" .....	3
40	70189-G01						INTERNAL RETAINING RING.....	1
41	17161-G1						BUSHING/SEAL KIT (INCLUDES ITEMS 42, 43) .....	1
42	*						STEERING COLUMN BUSHING .....	1
43	*						SHAFT SEAL .....	1
44								
45	70184-G01						IDLER.....	1
46								
47	70216-G01						THRUST WASHER, 1 1/2" I.D.....	1
48	70195-G01						THRUST WASHER, 7/8" .....	1
49	00734-G6						LOCK NUT, 7/8 - 9 .....	1
50	00798-G8						COTTER PIN, 5/32 X 1 3/4" LG.....	1
51								
52	00470-G4						BOLT, 7/16 - 20 X 2 1/2" LG.....	1
53	00734-G3						LOCK NUT, 7/16 - 20 .....	1
54	00462-G7						BOLT, 7/16 - 14 X 7/8" LG.....	2
55	00566-G2						LOCK WASHER, 7/16" .....	2
56								
57	18325-G1						STEERING WHEEL (INCLUDES ITEM 58) .....	1
58	*						HUB COVER.....	1
59	14390-G2						LOCK NUT, 5/8 - 18 .....	1
60	27102-G01						CLIPBOARD.....	1

When ordering parts, please specify the model and serial number of the product.  
 \* Indicates a component that is not available as an individual part.  
 G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
61	00999-G01		SCREW, #8 - 18 X 7/8" LG. ....	2
62				
63	70074-G01		TIE ROD ASSEMBLY (INCLUDES ITEMS 64 - 68) .....	2
64	18434-G2		NUT, 9/16 - 18.....	2
65	10387-G2		COTTER PIN, 3/32 X 1" LG.....	2
66	50209-G1		SLOTTED NUT, 7/16 - 20 .....	2
67	50641-G1		RUBBER BOOT.....	2
68	10389-G3		GREASE FITTING.....	2
69				
70	50209-G1		SLOTTED NUT, 7/16 - 20.....	1
71	10387-G2		COTTER PIN, 3/32 X 1" LG.....	3




When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
1	27942-G01		DRIVER SIDE BRAKE ASSEMBLY (INCLUDES ITEMS 3 - 10) .....	1
2	27942-G02		PASSENGER SIDE BRAKE ASSEMBLY (INCLUDES ITEMS 3 - 10).....	1
3	27945-G01		BRAKE SHOE KIT (INCLUDES ITEM 4).....	2
4	*		BRAKE SHOE.....	2
5	27944-G01		BRAKE SPRING KIT (INCLUDES ITEMS 6 - 10) .....	2
6	*		UPPER SPRING .....	1
7	*		LOWER SPRING .....	1
8	*		PIN .....	2
9	*		CUP AND SPRING.....	2
10	*		ADJUSTER SPRING .....	1
11	17803-G2		BOLT, 5/16 - 24 X 1" LG.....	8
12	15126-G1		LOCK NUT, 5/16 - 24 .....	8
13	21809-G1		INNER BRAKE DRUM WASHER .....	2
14	21807-G1		BRAKE DRUM ASSEMBLY (INCLUDES ITEMS 15 - 16).....	2
15	*		BRAKE DRUM.....	1
16	19862-G1		LUG BOLT .....	4
17	24939-G2		SPINDLE CAP ADAPTER.....	2
18	21830-G1		OUTER BRAKE DRUM WASHER .....	2
19	00518-G8		SLOTTED NUT, 3/4 - 16 .....	2
20	10387-G1		COTTER PIN .....	2
21				
22	12091-G2		SPINDLE CAP .....	2
23				
24	72036-G01		PASSENGER SIDE BRAKE CABLE BRACKET.....	1
25	72036-G02		DRIVER SIDE BRAKE CABLE BRACKET .....	1



THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
1	22997-G2		BRAKE ASSEMBLY, PASSENGER SIDE (INCLUDES ITEMS 2 - 8, 14 - 30) .....	1
2	22518-G1		BACKING PLATE .....	1
3	23360-G1		ADJUSTER.....	1
4	23357-G1		LEVER ASSEMBLY (INCLUDES ITEMS 5 - 8, 14 - 16) .....	1
5	*		SPRING .....	1
6	*		RETAINER .....	1
7	*		WASHER, SHOULDER.....	1
8	23536-G1		TORSION SPRING, PASSENGER SIDE (SILVER).....	1
9	22997-G1		BRAKE ASSEMBLY, DRIVER'S SIDE (INCLUDES ITEMS 10 - 30) .....	1
10	22519-G1		BACKING PLATE .....	1
11	23361-G1		ADJUSTER.....	1
12	23358-G1		LEVER ASSEMBLY (INCLUDES ITEMS 5 - 7, 13 - 16) .....	1
13	23537-G1		TORSION SPRING, DRIVER'S SIDE (GOLD) .....	1
14	23363-G1		ADJUSTER BODY.....	1
15	23382-G1		WASHER, 1/4 .....	1
16	23362-G1		THRUST WASHER, 1/4.....	1
17				
18	22511-G1		DUST COVER .....	1
19	23356-G1		ANCHOR BLOCK.....	1
20	00565-G1		WASHER, LOCK, 1/4 .....	2
21	13632-G1		NUT, 6 MM.....	2
22				
23	23359-G1		SPRING, BRAKE ADJUSTER.....	1
24	17290-G1		SPRING, BRAKE ANCHOR .....	1
25	17291-G1		CLAMP, SHOE.....	2
26	17292-G1		PIN, SHOE CLAMP TENSION .....	2
27				
28	23364-G1		BRAKE SHOE SET (INCLUDES ITEMS 29, 30).....	1
29	23354-G1		BRAKE SHOE, TRAILING .....	1

# WHEEL BRAKE, NON-BENDIX

Electric Vehicle


THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.


\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1	2	3	4	5	DESCRIPTION	QTY.
30	23355-G1						BRAKE SHOE, LEADING .....	1
31								
32								
33	17083-G2						BOLT, 5/16 - 24 X 1 LG. ....	8
34	15126-G1						NUT, LOCK, 5/16 - 24 .....	8
35								
36								
37	15485-G1						WASHER, INNER WHEEL RIM .....	2
38								
39								
40	19186-G1						BRAKE DRUM WITH LUG BOLTS .....	2
41								
42								
43	15487-G1						WASHER, OUTER WHEEL RIM .....	2
44								
45	10387-G1						PIN, COTTER, 1/8 X 1 1/2 LG. ....	2
46	15483-G1						NUT, SLOTTED, 5/8 - 18.....	2
47	12091-G2						CAP, SPINDLE .....	2
48								
49	24939-G1						ADAPTOR, SPINDLE CAP .....	2



- 1 - INCLUDES ITEMS 2, 11, 12
- 3 - INCLUDES ITEMS 4, 11, 12
- 7 - INCLUDES ITEMS 8, 11, 12
- 9 - INCLUDES ITEMS 10, 11, 12



THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5	DESCRIPTION	QTY.
1	27772-G01		18 X 8.5 - 8 CARLISLE TIRE AND WHEEL ASSEMBLY, LINKS (INCLUDES ITEMS 2, 11, 12).....	AR
2	27772-G05		18 X 8.5 - 8 CARLISLE TIRE, LINKS .....	AR
3	27772-G02		18 X 8.5 - 8 CARLISLE TIRE AND WHEEL ASSEMBLY, TURF GLIDE (INCLUDES ITEMS 4, 11, 12).....	AR
4	27772-G06		18 X 8.5 - 8 CARLISLE TIRE, TURF GLIDE .....	AR
5				
6				
7	27772-G03		18 X 8.5 - 8 CARLISLE TIRE AND WHEEL ASSEMBLY, TURF SAVER (INCLUDES ITEMS 8, 11, 12).....	AR
8	27772-G07		18 X 8.5 - 8 CARLISLE TIRE, TURF SAVER .....	AR
9	27772-G04		18 X 8.5 - 8 CARLISLE TIRE AND WHEEL ASSEMBLY, FAIRWAY (INCLUDES ITEMS 10, 11, 12).....	AR
10	27772-G08		18 X 8.5 - 8 CARLISLE TIRE, FAIRWAY .....	AR
11	15169-G1		WHEEL RIM, 4 LUG, STANDARD .....	AR
12	11657-G1		VALVE STEM .....	AR



# SPECIAL TOOLS

## SPECIAL TOOLS LISTING

# SPECIAL TOOLS

## SPECIAL TOOLS..... Part No.

BATTERY MAINTANANCE KIT .....	25587-G01
SEAL INSTALLATION TOOL (REAR AXLE SHAFT SEAL).....	18739-G1
BATTERY SET DISCHARGER, 36 VOLT, 75 AMP.....	28251-G01
CURRENT INDICATOR.....	16489-G1
MULTI-METER, DIGITAL.....	27481-G01
CRIMPING TOOL .....	27765-G01
SLIDE HAMMER (AXLE/HUB REMOVAL) .....	15947-G1
SLIDE HAMMER (AXLE REMOVAL ONLY).....	18753-G1

## OIL, 10W-30

5 GALLONS .....	25730-G03
12 QUART CASE.....	25730-G04
55 GALLON DRUM.....	25730-G05

## PAINT

.6 OUNCE BRUSH ON PAINT - HUNTER GREEN.....	28002-G04
.6 OUNCE BRUSH ON PAINT - CHAMPAGNE BEIGE.....	28002-G03
12 OUNCE SPRAY - HUNTER GREEN .....	28140-G09
12 OUNCE SPRAY - CHAMPAGNE BEIGE.....	28140-G15

# ACCESSORIES

## ACCESSORIES LISTING

# ACCESSORIES

## ACCESSORIES LISTING

## KIT NO.

SUN TOP KIT.....	75040-G01 .....	See Kit Instruction Sheet 75055
SUN TOP KIT (4 CADDY ONLY).....	75123-G01 .....	See Kit Instruction Sheet 75158
WINDSHIELD KIT, 4 CADDY ONLY.....	75133-G01 .....	See Kit Instruction Sheet 75161
WINDSHIELD KIT, TINT, 4 CADDY ONLY .....	75133-G02 .....	See Kit Instruction Sheet 75161
WINDSHIELD KIT, 2 BEND .....	75041-G03 .....	See Kit Instruction Sheet 75043
WINDSHIELD KIT, 2 BEND, TINTED .....	75041-G04 .....	See Kit Instruction Sheet 75043
WINDSHIELD KIT, SPLIT, .....	75077-G01	
WINDSHIELD KIT, SPLIT, TINTED.....	75077-G02	
WINDSHIELD KIT, SPLIT, 4 CADDY ONLY .....	75077-G03	
WINDSHIELD KIT, SPLIT, TINTED.....	75077-G04	
SAND RAKE .....	14735-G1	
TOW BAR KIT (PERMANENT USE) .....	75310-G01 .....	See Kit Instruction Sheet 75311
WEATHER ENCLOSURE (3 SIDED).....	75078-G01	
WEATHER ENCLOSURE (4 SIDED).....	75079-G01	
REAR VIEW MIRROR (REQUIRES SUN TOP).....	19528-G2 .....	See Kit Instruction Sheet 75162
MESSAGE HOLDER KIT (REQUIRES SUNTOP).....	75094-G01	
HOURMETER (ELECTRIC ONLY) .....	75113-G02 .....	See Kit Instruction Sheet 75118
COOLER JUG / BRACKET KIT .....	75170-G01	
BAG COVER / RAIN CURTAIN KIT .....	75191-G01	
SEAT REFURBISHMENT SPRAY (WHITE) .....	28166-G01	
ASHTRAY KIT.....	75109-G02 .....	See Kit Instruction Sheet 75110
URNSIGNAL KIT (4 CADDY ONLY) .....	75107-G02	
SANDBOTTLE .....	75009-G01 .....	See Kit Instruction Sheet 75029
8" CHROME HUBCAP .....	14913-G* .....	See Kit Instruction Sheet 28244
6" CHROME HUBCAP .....	16042-G* .....	See Kit Instruction Sheet 28244
GOLD SPOKE HUBCAP .....	19241-G* .....	See Kit Instruction Sheet 28244
SILVER SPOKE HUBCAP .....	19241-G* .....	See Kit Instruction Sheet 28244
4-CADDY KIT .....	74150-G01 .....	See Kit Instruction Sheet 74155
CENTER BASKET .....	75003-G02 .....	See Kit Instruction Sheet 75025
SIDE BASKET .....	75007-G02 .....	See Kit Instruction Sheet 75026
SCUFF GUARDS.....	75127-G02 .....	See Kit Instruction Sheet
SUN TOP WITHOUT BAG RACK .....	75135-G01 .....	See Kit Instruction Sheet 75137

## GENERAL INDEX

TWO BAG ATTACHMENT .....	75183-G01 .....	See Kit Instruction Sheet 75184
CONVERTIBLE CARRIER KIT .....	75179-G* .....	See Kit Instruction Sheet 75283
4-CADDY TO CONVERTIBLE CARRIER KIT .....	75278-G* .....	See Kit Instruction Sheet 75284
4 BAG ATTACHMENT .....	75335-G01 .....	See Kit Instruction Sheet 75336

# ACCESSORIES


# ACCESSORIES

## ACCESSORIES ILLUSTRATED

**NOTE:** TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO. 75009-G01  
**NOTE:** SIDE BASKET CANNOT BE USED ON SAME SIDE OF VEHICLE WITH SAND BOTTLE KIT.

**READ ALL INSTRUCTIONS BEFORE PROCEEDING.**

1. INSTALLATION TIP: INSTALL THE 1/4-20 TAPTITE BOLT ITEM 1 INTO THE DESIGNATED HOLE (SEE ILLUSTRATION) IN THE METAL SEAT BACK SUPPORT TO FORM CLEAN, STRAIGHT THREADS. BACK THE TAPTITE SCREW OUT OF THE SEATBACK SUPPORT.
2. ALIGN THE HOLES IN THE REINFORCING PLATE AND THE SAND BOTTLE HOLDER, ITEM 2 WITH THE HOLE INDICATED IN THE THE METAL SEAT BACK SUPPORT. INSERT THE TAPTITE SCREW AND SECURE FIRMLY.



**MEDALIST/TXT**



Item 1  
 1/4-20 x 3/4 Lg. Taprite Bolt

THE SYMBOL  REFERS TO A NOTE CORRESPONDING TO THE LETTER ENCLOSED WITHIN IT. SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF REPLACEMENT PARTS.

ITEM	QTY	PART NO.	DESCRIPTION
1	1	71102-G01	BOLT, TAPTITE, 1/4-20 X 3/4 LG.
2	1	27374-G01	HOLDER, SAND BOTTLE
3	1	27373-G01	BOTTLE, SAND

TITLE		<b>SAND BOTTLE INSTALLATION INSTRUCTION KIT</b>		REV C
<b>E-Z-GO</b>	FORN BY L WEBB ORIG DATE 11/29/93	REV BY C THOMANN REV DATE 07/21/95	DRAWING A NO. 75029	PG. 1 OF 1

**NOTE:** TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO. 75007-G02


**READ ALL INSTRUCTIONS BEFORE PROCEEDING.**

1. ALIGN HOLES ON THE SIDE BASKET, ITEM 1 WITH HOLES IN THE SEAT BACK SUPPORT BRACKET AS SHOWN IN ILLUSTRATION.

**NOTE**

BASKET MAY BE INSTALLED ON EITHER SIDE OF VEHICLE

2. INSTALL THE THREAD FORMING BOLTS, ITEM 2 INTO EACH HOLE. TIGHTEN TO 60 - 85 IN. LBS. TORQUE.



ITEM	QTY	PART NO.	DESCRIPTION
1	1	75008-G01	BASKET, SIDE
2	3	71102-G02	BOLT, 1/4-20 X 1/2 LG.

**TITLE SIDE BASKET INSTALLATION**

THE SYMBOL ◁ REFERS TO A NOTE CORRESPONDING TO THE LETTER ENCLOSED WITHIN IT. SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF REPLACEMENT PARTS.



DRN BY L WEBB  
ORIG DATE 01/03/94

REV BY  
REV DATE

**A** DRAWING  
NO. 75026

REV -



PG. 1 OF 1

E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA, GA. 30913-2699, 1-800-241-5855

**NOTE:** TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO. 75003-G02

**READ ALL INSTRUCTIONS BEFORE PROCEEDING.**

1. PLACE THE CENTER BASKET, ITEM 1 JUST BEHIND THE BAG RACK AS SHOWN IN ILLUSTRATION BELOW.
2. ALIGN THE GROOVE IN THE BASKET BRACKET, ITEM 2 WITH THE TOP EDGE OF THE CENTER BASKET. (SEE DETAIL A.)
3. INSTALL THE THREAD FORMING SCREWS, ITEM 4 INTO THE BASKET BRACKET AND TIGHTEN TO 15 - 20 IN. LBS. TORQUE.
4. SECURE THE CENTER BASKET TO THE SEAT BACK SUPPORTS WITH PLASTITE SCREWS, ITEM 3 AT EACH SIDE AS SHOWN. TIGHTEN TO 60 - 85 IN. LBS. TORQUE.



DETAIL A


ITEM	QTY	PART NO.	DESCRIPTION
1	1	75001-G01	BASKET, CENTER
2	1	75002-G01	BRACKET, BASKET
3	2	71002-G01	SCREW, #8 X 3/8 LG. PLASTITE
4	2	71102-G02	SCREW, 1/4-20 X 1/2 LG.

THE SYMBOL ◁ REFERS TO A NOTE CORRESPONDING TO THE LETTER ENCLOSED WITHIN IT. SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF REPLACEMENT PARTS.

**TITLE CENTER BASKET INSTALLATION**

<b>E-Z-GO</b> <b>TEXTRON</b>	DRN BY	L WEBB	REV BY	L WEBB	DRAWING	REV A
	ORIG DATE	01/03/84	REV DATE	01/24/84	NO. 75025	PG. 1 OF 1

E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA, GA. 30913-2699, 1-800-241-5855



THE SYMBOL ◁ REFERS TO A NOTE CORRESPONDING TO THE LETTER ENCLOSED WITHIN IT. SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF REPLACEMENT PARTS.

TITLE **SUN TOP INSTALLATION (WITH BAG RACK)**

**EZ-GO** **TEXTRON**


DRN BY L WEBB  
ORIG DATE 12/20/83

REV BY J.Brand  
REV DATE 02/07/86


DRAWING NO. 75055

REV E  
PG. 1 OF 3


E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA, GA. 30913-2699, 1-800-241-5855




ITEM 3  
5/16" WASHER  
QTY. 8




ITEM 4  
5/16-18 X 1 3/4" BOLT  
QTY. 4




ITEM 5  
5/16" TEFLON WASHER  
QTY. 4




ITEM 6  
5/16-18 LOCK NUT  
QTY. 4




ITEM 8  
5/16-18 X 2 1/8" BOLT  
QTY. 4




ITEM 9  
5/16" LOCK WASHER  
QTY. 4



ITEM 10  
SPACER  
QTY. 2




ITEM 11  
5/16" WASHER  
QTY. 6



ITEM 12  
1/4-20 X 2 1/4" BOLT  
QTY. 2




ITEM 14  
PLASTIC SPACER  
QTY. 4



ITEM 15  
1/4" WASHER  
QTY. 8



ITEM 16  
1/4-20 LOCK NUT  
QTY. 4



ITEM 17  
1/4-20 X 2" BOLT  
QTY. 2

NOTE: ALL HARDWARE SHOWN ACTUAL SIZE

THE SYMBOL  REFERS TO A NOTE CORRESPONDING TO THE LETTER ENCLOSED WITHIN IT. SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF REPLACEMENT PARTS.

TITLE **SUN TOP INSTALLATION (WITH BAG RACK)**



DRN BY L. WEBB  
ORIG DATE 12/20/93

REV BY J. Brand  
REV DATE 02/07/96

A

DRAWING NO. 75055

REV E

PG. 2 OF 3

E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA, GA. 30913-2699, 1-800-241-5855

NOTE: TO ORDER THIS ENTIRE FIELD KIT, REQUEST 75040-G01

**READ ALL INSTRUCTIONS BEFORE PROCEEDING.**

**A. REAR STRUTS**

1. REMOVE CENTER BASKET AND OTHER ACCESSORIES THAT MAY LIMIT ACCESS REQUIRED FOR INSTALLING REAR STRUTS.
2. PLACE REAR STRUT, ITEM 2 THRU THE SQUARE HOLE IN THE TOP OF THE SEAT BACK SUPPORT.
3. ALIGN THE HOLES IN THE REAR STRUT WITH THE HOLES IN THE SEAT BACK SUPPORT BRACKET. PUSH THE STRUT TOWARD THE CENTER OF THE CAR TO GIVE CLEARANCE BETWEEN THE STRUT AND THE SEAT BACK SUPPORT.
4. PLACE WASHER, ITEM 3 ONTO BOLT, ITEM 4 AND INSERT BOLT JUST THRU SEAT BACK SUPPORT (2 - 3 THREADS). PLACE THE SMALL WHITE TEFLON WASHER, ITEM 5 ONTO THE BOLT BETWEEN THE STRUT AND SEAT BACK SUPPORT TO PREVENT SQUEAKING.
5. INSERT THE BOLT WITH THE TWO WASHERS IN PLACE THRU THE REAR STRUT. SECURE HARDWARE WITH WASHER, ITEM 3 AND LOCK NUT, ITEM 6. **DO NOT TIGHTEN HARDWARE.**
6. REPEAT STEPS 4 AND 5 FOR THE OTHER HOLE.
7. REPEAT PROCEDURE AT THE OTHER SIDE OF VEHICLE.
8. INSERT TUBE CAPS, ITEM 18 INTO THE TOP OF THE REAR STRUTS.

**B. FRONT STRUT**

1. REMOVE AND DISCARD THE FOUR ALLEN HEAD BOLTS FROM THE FRONT COWL USING A 7/32" ALLEN WRENCH.
2. AT THE TOP HOLE, INSTALL THE FRONT STRUT, ITEM 7 WITH BOLT, ITEM 8 AND BLACK LOCK WASHER, ITEM 9, ON THE OUTSIDE OF STRUT, AND A SPACER, ITEM 10 AND A WASHER, ITEM 11 BETWEEN THE FRONT COWL AND STRUT. **DO NOT TIGHTEN HARDWARE.**
3. AT THE BOTTOM HOLE, SECURE THE FRONT STRUT, ITEM 7 WITH BOLT, ITEM 8 AND BLACK LOCK WASHER, ITEM 9, ON THE OUTSIDE OF STRUT, AND TWO BLACK WASHERS, ITEM 11 BETWEEN THE FRONT COWL AND STRUT. **DO NOT TIGHTEN HARDWARE.**

**C. SUN TOP**

1. PLACE SUN TOP, ITEM 1 ONTO STRUTS
2. SECURE SUN TOP LOOSELY WITH BOLTS, ITEM 17 AT FRONT AND ITEM 12 AT REAR, PLASTIC SPACER, ITEM 14, WASHER, ITEM 15, AND LOCK NUT, ITEM 16. SEE ILLUSTRATIONS FOR INSTALLATION SEQUENCE.
3. TIGHTEN ALL SUN TOP HARDWARE TO 3 - 5 FT. LBS. TORQUE.
4. TIGHTEN ALL REAR STRUT HARDWARE TO 13 - 15 FT. LBS. TORQUE.
5. TIGHTEN ALL FRONT STRUT HARDWARE TO 17 - 19 FT. LBS. TORQUE.

ITEM	QTY	PART NO.	DESCRIPTION
1	1	27069-G01	TOP, SUN
2	2	75046-G01	STRUT, REAR
3	8	00571-G2	WASHER, 5/16"
4	4	00439-G6	BOLT, 5/16-18 X 1 3/4"
5	4	17255-G1	WASHER, TEFLON, 5/16"
6	4	11098-G6	NUT, LOCK, 5/16-18
7	1	75045-G01	STRUT, FRONT
8	4	71056-G03	BOLT, 5/16-18 X 2 1/8"
9	4	00905-G8	WASHER, LOCK, 5/16"
10	2	75048-G01	SPACER
11	6	00570-G2	WASHER, 5/16"
12	2	00753-G6	BOLT, STAINLESS STEEL, 1/4-20 X2 1/4"
13			
14	4	75051-G01	SPACER, PLASTIC
15	8	00559-G7	WASHER, 1/4"
16	4	00891-G2	NUT, LOCK, 1/4-20
17	2	00753-G5	BOLT, STAINLESS STEEL, 1/4-20 X 2"
18	2	19853-G1	CAP, TUBE, 1"

THE SYMBOL  REFERS TO A NOTE CORRESPONDING TO THE LETTER ENCLOSED WITHIN IT. SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF REPLACEMENT PARTS.

**TITLE SUN TOP INSTALLATION (WITH BAG RACK)**




DRN BY L WEBB  
ORIG DATE 12/20/83

REV BY J. Brand  
REV DATE 02/07/96

DRAWING NO. 75055  
**A**

REV E

PG. 3 OF 3



THE SYMBOL ◁ REFERS TO A NOTE CORRESPONDING TO THE LETTER ENCLOSED WITHIN IT. SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF REPLACEMENT PARTS.

**TITLE SUN TOP INSTALLATION (WITHOUT BAG RACK)**

**REV B**  
**DRAWING NO. 75137**


**EZ-GO** **TEXTRON**

DRN BY L. WEBB  
 ORIG DATE 06/18/94


REV BY J. Brand  
 REV DATE 02/07/96

**A**  
 PG. 1 OF 3

E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA, GA. 30913-2699, 1-800-241-5855




ITEM 3  
5/16" WASHER  
QTY. 8




ITEM 8  
5/16-18 X 2 1/8" BOLT  
QTY. 4




ITEM 4  
5/16-18 X 1 3/4" BOLT  
QTY. 2




ITEM 5  
5/16" TEFLON WASHER  
QTY. 4



ITEM 6  
5/16-18 LOCK NUT  
QTY. 4




ITEM 11  
5/16" BLACK WASHER  
QTY. 6




ITEM 10  
SPACER  
QTY. 2




ITEM 9  
5/16" LOCK WASHER  
QTY. 4




ITEM 14  
PLASTIC SPACER  
QTY. 4




ITEM 15  
1/4" WASHER  
QTY. 8



ITEM 16  
1/4-20 LOCK NUT  
QTY. 4



ITEM 12  
1/4-20 X 2 1/4" BOLT  
QTY. 2



ITEM 17  
1/4-20 X 2" BOLT  
QTY. 2

NOTE: ALL HARDWARE SHOWN ACTUAL SIZE

THE SYMBOL  REFERS TO A NOTE CORRESPONDING TO THE LETTER ENCLOSED WITHIN IT. SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF REPLACEMENT PARTS.

TITLE	<b>SUN TOP INSTALLATION (WITHOUT BAG RACK)</b>				REV C
	DRN BY	L. WEBB	REV BY	J. Brand	DRAWING NO. 75137
	ORIG DATE	06/16/94	REV DATE	02/07/96	PG. 2 OF 3
E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA, GA. 30913-2699, 1-800-241-5855					

NOTE: TO ORDER THIS ENTIRE FIELD KIT, REQUEST 75135-G01

**READ ALL INSTRUCTIONS BEFORE PROCEEDING.**

**A. REAR STRUTS**

1. ALIGN THE HOLES IN THE REAR STRUT WITH THE HOLES IN THE SEAT BACK SUPPORT BRACKET. PUSH THE STRUT AWAY FROM THE CENTER OF THE CAR TO GIVE CLEARANCE BETWEEN THE STRUT AND THE SEAT BACK SUPPORT.
2. PLACE WASHER, ITEM 3 ONTO BOLT, ITEM 4 AND INSERT BOLT JUST THRU SEAT BACK SUPPORT (2 - 3 THREADS). PLACE THE SMALL WHITE TEFLON WASHER, ITEM 5 ONTO THE BOLT BETWEEN THE STRUT AND SEAT BACK SUPPORT TO PREVENT SQUEAKING.
3. INSERT THE BOLT WITH THE TWO WASHERS IN PLACE THRU THE REAR STRUT. SECURE HARDWARE WITH WASHER, ITEM 3 AND LOCK NUT, ITEM 6. **DO NOT TIGHTEN HARDWARE.**
4. REPEAT STEPS 2 AND 3 FOR THE OTHER HOLE.
5. REPEAT PROCEDURE AT THE OTHER SIDE OF VEHICLE.
6. INSERT TUBE CAPS, ITEM 18 INTO THE TOP OF THE REAR STRUTS.

**B. FRONT STRUT**

1. REMOVE AND DISCARD THE FOUR ALLEN HEAD BOLTS FROM THE FRONT COWL USING A 7/32" ALLEN WRENCH.
2. AT THE TOP HOLE, INSTALL THE FRONT STRUT, ITEM 7 WITH BOLT, ITEM 8 AND BLACK LOCK WASHER, ITEM 9, ON THE OUTSIDE OF STRUT, AND A SPACER, ITEM 10 BETWEEN THE FRONT COWL AND STRUT. **DO NOT TIGHTEN HARDWARE.**
3. AT THE BOTTOM HOLE, SECURE THE FRONT STRUT, ITEM 7 WITH BOLT, ITEM 8 AND BLACK LOCK WASHER, ITEM 9, ON THE OUTSIDE OF STRUT, AND TWO BLACK WASHERS, ITEM 11 BETWEEN THE FRONT COWL AND STRUT. **DO NOT TIGHTEN HARDWARE.**

**C. SUN TOP**


1. PLACE SUN TOP, ITEM 1 ONTO STRUTS
2. SECURE SUN TOP LOOSELY WITH BOLTS, ITEM 17 AT FRONT AND ITEM 12 AT REAR, PLASTIC SPACER, ITEM 14, WASHER, ITEM 15, AND LOCK NUT, ITEM 16. SEE ILLUSTRATIONS FOR INSTALLATION SEQUENCE.
3. TIGHTEN ALL SUN TOP HARDWARE TO 3 - 5 FT. LBS. TORQUE.
4. TIGHTEN ALL REAR STRUT HARDWARE TO 13 - 15 FT. LBS. TORQUE.
5. TIGHTEN ALL FRONT STRUT HARDWARE TO 13 - 15 FT. LBS. TORQUE.

ITEM	QTY	PART NO.	DESCRIPTION
1	1	27069-G01	TOP, SUN
2	2	75136-G01	STRUT, REAR
3	8	00571-G2	WASHER, 5/16"
4	4	00439-G6	BOLT, 5/16-18 X 1 3/4"
5	4	17255-G1	WASHER, TEFLON, 5/16"
6	4	11098-G6	NUT, LOCK, 5/16-18
7	1	75045-G01	STRUT, FRONT
8	4	71056-G03	BOLT, 5/16-18 X 2 1/8"
9	4	00905-G8	WASHER, LOCK, BLACK, 5/16"
10	2	75048-G01	SPACER
11	6	00570-G2	WASHER, BLACK, 5/16"
12	2	00753-G6	BOLT, STAINLESS STEEL, 1/4-20 X2 1/4"
13			
14	4	75051-G01	SPACER, PLASTIC
15	8	00559-G7	WASHER, PLATED, 1/4"
16	4	00891-G2	NUT, LOCK, 1/4-20
17	2	00753-G5	BOLT, STAINLESS STEEL, 1/4-20 X 2"
18	2	19853-G1	CAP, TUBE, 1"


THE SYMBOL  REFERS TO A NOTE CORRESPONDING TO THE LETTER ENCLOSED WITHIN IT. SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF REPLACEMENT PARTS.

**TITLE SUN TOP INSTALLATION (WITHOUT BAG RACK)**


DRN BY	L WEBB	REV BY	J. Brand	DRAWING
ORIG DATE	06/16/94	REV DATE	02/07/96	NO. 75137
			<b>A</b>	PG. 3 OF 3



6" CHROME HUBCAP



8" CHROME HUBCAP



GOLD / SILVER SPOKE HUBCAP

ITEM	QTY	PART NO.	DESCRIPTION
1	1	14913-G1	8" CHROME HUBCAP
2	4	14913-G2	8" CHROME HUBCAP SET
3	1	16042-G1	6" CHROME HUBCAP
4	4	16042-G2	6" CHROME HUBCAP SET
5	1	19241-G2	GOLD SPOKE HUBCAP
6	4	19241-G4	GOLD SPOKE HUBCAP SET
7	1	19241-G1	SILVER SPOKE HUBCAP
8	4	19241-G3	SILVER SPOKE HUBCAP SET

THE SYMBOL ◁ REFERS TO A NOTE CORRESPONDING TO THE LETTER ENCLOSED WITHIN IT. SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF REPLACEMENT PARTS.

TITLE **WHEEL COVER INSTALLATION**

REV -



DRN BY  
ORIG DATE

CGT  
0207/96

REV BY  
REV DATE

DRAWING  
NO. 28244




PG. 1 OF 1

**NOTE:** TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO. 75041-G0\*

\* CONTACT SERVICE PARTS FOR AVAILABILITY.

**READ ALL INSTRUCTIONS BEFORE PROCEEDING.**

1. INSERT THE RUBBER GROMMETS, ITEM 3 INTO THE TOP AND BOTTOM HOLES ON BOTH SIDES OF THE WINDSHIELD, ITEMS 1, 2, 9, OR 10.
2. INSERT THE SPACERS, ITEM 4 INTO THE RUBBER GROMMETS.
3. INSERT THE PLUG BUMPERS, ITEM 5 INTO THE CENTER HOLES OF THE WINDSHIELD, ITEMS 1, 2 OR THE TOP OF WINDSHIELD, ITEMS 9 OR 10.
4. PLACE THE WINDSHIELD AGAINST THE FRONT STRUT WITH THE SMALL TAPERED END AT THE TOP.
5. INSERT THE BOLTS, ITEM 6 THRU WINDSHIELD AND THE FRONT STRUT AND SECURE WITH WASHERS, ITEM 7 AND LOCK NUTS, ITEM 8.



ITEM	QTY	PART NO.	DESCRIPTION
1	1	75021-G01	WINDSHIELD, CLEAR, 2 BEND
2	1	75021-G02	WINDSHIELD, TINTED, 2 BEND
3	4	72147-G01	GROMMET, RUBBER
4	4	23726-G7	SPACER
5	2	75124-G01	BUMPER, PLUG
6	4	16705-G6	SCREW, 1/4-20 X 1 3/4 LG.
7	4	00660-G7	WASHER, 1/4"
8	4	00891-G2	NUT, LOCK, 1/4-20
9	1	75203-G01	WINDSHIELD, CLEAR, 4 BEND
10	1	75203-G02	WINDSHIELD, TINTED, 4 BEND
11	1	75021-G03	WINDSHIELD, CLEAR, 2 BEND, OASIS

THE SYMBOL REFERS TO A NOTE CORRESPONDING TO THE LETTER ENCLOSED WITHIN IT. SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF REPLACEMENT PARTS.

**TITLE WINDSHIELD INSTALLATION**




DRN BY: L.WEBB  
ORIG DATE: 12/17/93  
REV BY: J.Brand  
REV DATE: 02/23/96

DRAWING NO. 75043  
A


REV D

PG. 1 OF 2


NOTE: ALL HARDWARE SHOWN ACTUAL SIZE




ITEM 3  
RUBBER GROMMET  
QTY. 4




ITEM 4  
SPACER  
QTY. 4



ITEM 5  
PLUG BUMPER  
QTY. 2



ITEM 6  
1/4-20 X 1 3/4" SCREW  
QTY. 4



ITEM 7  
1/4" WASHER  
QTY. 4



ITEM 8  
1/4-20 NUT, LOCK  
QTY. 4

THE SYMBOL ◁ REFERS TO A NOTE CORRESPONDING TO THE LETTER ENCLOSED WITHIN IT. SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF REPLACEMENT PARTS.

TITLE WINDSHIELD INSTALLATION

REV D



DRN BY L. WEBB  
ORIG DATE 12/17/83  
REV BY J. BRAND  
REV DATE 02/23/96

DRAWING NO. 75043  
A


PG. 2 OF 2

E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA, GA. 30913-2699, 1-800-241-5855

**NOTE:** TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO. 75109-G02

**READ ALL INSTRUCTIONS BEFORE PROCEEDING.**



1. INSERT THE ASH TRAY, ITEM 1 INTO THE GASKET, ITEM 2 UNTIL THE GASKET HOOKS OVER THE FLANGES ON THE TOP AND BOTTOM OF THE ASH TRAY.
2. USING BRACKET, ITEM 3 AS A TEMPLATE, INSERT THE (4) SELF DRILLING SCREWS, ITEM 4. LOCATE BRACKET APPROXIMATELY AS SHOWN IN ILLUSTRATION.
3. SNAP THE ASH TRAY INTO THE BRACKET.



ITEM	QTY	PART NO.	DESCRIPTION
1	1	27731-G01	ASH TRAY
2	1	27736-G01	GASKET, ASH TRAY
3	1	75108-G01	BRACKET, ASH TRAY
4	4	00100-G4	SCREW, 10-16 X 1/2" LG.

TITLE ASH TRAY INSTALLATION				REV -
DRN BY	L WEBB	REV BY		
ORIG DATE	01/21/94	REV DATE		
<b>E-Z-GO</b> <b>TEXTRON</b>			<b>A</b>	DRAWING NO. 75110

THE SYMBOL  REFERS TO A NOTE CORRESPONDING TO THE LETTER ENCLOSED WITHIN IT. SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF REPLACEMENT PARTS.



THE SYMBOL ◁ REFERS TO A NOTE CORRESPONDING TO THE LETTER ENCLOSED WITHIN IT. SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF REPLACEMENT PARTS.

TITLE **REAR VIEW MIRROR INSTALLATION INSTRUCTIONS**

REV -



DRN BY CGT  
ORIG DATE 05/16/94

REV BY  
REV DATE  
**A**  
DRAWING NO. 75162

PG. 1 OF 2

E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA, GA. 30903-0388, 1-800-241-5855

NOTE: TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO. 19528-G2

**READ ALL INSTRUCTIONS BEFORE PROCEEDING.**

1. DISCARD PLASTIC MOUNTING BRACKETS AND ADHESIVE SUPPLIED WITH KIT. THESE ITEMS ARE USED IN OTHER APPLICATIONS.
2. REMOVE THE FRONT TOP HARDWARE FROM THE FRONT TOP STRUT. IT IS NOT NECESSARY TO REMOVE TOP.
3. LOCATE AND DRILL A .147 DIA. HOLE (#26 DRILL) THROUGH CENTER OF FRONT TOP STRUT (INSIDE SURFACE ONLY). SEE DETAIL A.
4. USING SCREW, ITEM 3 FASTEN SUPPORT BRACKET, ITEM 5 TO FRONT TOP STRUT AS SHOWN IN DETAIL A.
5. LOOSEN SETSCREW SUPPLIED WITH MIRROR.
6. SLIDE MIRROR, ITEM 1 ONTO BRACKET AND TIGHTEN SETSCREW. *DO NOT* OVERTIGHTEN. DAMAGE TO MIRROR WILL OCCUR.
7. REINSTALL THE TOP ONTO THE FRONT TOP STRUT. TIGHTEN HARDWARE TO 3 - 5 FT. LBS. TORQUE.

ITEM	QTY	PART NO.	DESCRIPTION
1	1	19496-G1	MIRROR, REAR VIEW
2	1	19527-G1	SCREW, STAINLESS STEEL, SELF TAP-PING, #8 - 32 x 5/8 LG.
3	1	19502-G2	BRACKET, SUPPORT
4	1		
5	1		

THE SYMBOL  REFERS TO A NOTE CORRESPONDING TO THE LETTER ENCLOSED WITHIN IT. SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF REPLACEMENT PARTS.

TITLE **REAR VIEW MIRROR INSTALLATION INSTRUCTIONS**



DRN BY  
ORIG DATE




CGT  
05/16/94

REV BY  
REV DATE

**A**  
DRAWING  
NO. 75162

REV -

PG. 2 OF 2



THE SYMBOL ◁ REFERS TO A NOTE CORRESPONDING TO THE LETTER ENCLOSED WITHIN IT. SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF REPLACEMENT PARTS.

**TITLE HOUR METER INSTALLATION**



DRN BY J RICE  
ORIG DATE 02/21/95

REV BY A  
REV DATE

DRAWING NO. 75118

REV -

**NOTE:** TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO. 75113-G02

**READ ALL INSTRUCTIONS BEFORE PROCEEDING.**

**A. ASSEMBLE HOUR METER**

1. Insert Hour Meter (item 1) through Bracket (item 2), positioned as shown.
2. Using hardware supplied with the Hour Meter, secure Hour Meter to Bracket.
3. Attach Harness (item 5) to Hour Meter as shown, Yellow wire to Positive (+) terminal and Black wire to Negative (-) terminal of Hour Meter.

**B. ATTACH HOUR METER ASSEMBLY**

1. Locate the four (4) predrilled holes in the passenger side seat support.
2. Secure the Hour Meter Assembly to the TOP two (2) holes using Bolts (item 3) and Nuts (item 4) as shown.

**C. CONNECT TO ELECTRONIC SPEED CONTROL**

1. Locate the cables from the Electronic Speed Control to the batteries. Disconnect both of these cables from the batteries.
2. Remove the four (4) bolts securing the cover on the Electronic Speed Control, and remove the cover from the Electronic Speed Control.
3. Remove the nut and lock washer from the left solenoid terminal and install Yellow wire from Harness to terminal and reinstall lock washer and nut.
4. Repeat procedure on right terminal for Black wire.
5. Replace cover and reinstall bolts.
6. Reconnect Electronic Speed Control cables to batteries as connected earlier.

ITEM	QTY	PART NO.	DESCRIPTION
1	1	21573-G1	METER, HOUR
2	1	74019-G01	BRACKET, HOUR METER
3	2	00150-G4	BOLT, #10-24 - 1/2 LG.
4	2	11098-G7	NUT, #10-24
5	1	75117-G02	HARNESS, HOUR METER

**TITLE HOUR METER INSTALLATION**

**REV -**

THE SYMBOL ◁ REFERS TO A NOTE CORRESPONDING TO THE LETTER ENCLOSED WITHIN IT. SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF REPLACEMENT PARTS.



DRN BY  
ORIG DATE







J.RICE  
02/21/95

REV BY  
REV DATE

A  
NO. 75118

DRAWING  
NO. 75118

PG. 2 OF 2



THE SYMBOL ◁ REFERS TO A NOTE CORRESPONDING TO THE LETTER ENCLOSED WITHIN IT. SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF REPLACEMENT PARTS.

TITLE **TXT FOUR BAG ATTACHMENT INST'L INSTRUCTIONS**

REV -

**E-Z-GO** **TEXTRON**

DRN BY J. RICE  
ORIG DATE 08/16/95

DRAWING NO. 75336  
A

PG. 1 OF 2

E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA, GA. 30903-0388, 1-800-241-5855

**NOTE:** TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO. 75335-G01  
**READ ALL INSTRUCTIONS BEFORE PROCEEDING.**

**A. FOUR BAG ATTACHMENT ASSEMBLY**

1. Install the top assembly, item 1 to the bottom assembly, item 2 with clevis pin, item 3 and cap nut, item 4. See Detail A.

**B. INSTALLING FOUR BAG ATTACHMENT TO VEHICLE**

**NOTE**

It is necessary that the bottom part of the four bag attachment be disengaged from the bumper and at a level below the bumper (approx. 6-8 inches above the ground) before attempting Step 1. Note the approximate angle of the top assembly and retaining brackets shown.

1. Place the top retaining brackets over the vehicle bag rack.
2. Press down on the top retaining bracket while slightly raising the bottom part of the four bag attachment engaging the brackets with the underside of the vehicle bag rack.
3. While firmly holding retaining bracket against top of bag rack, raise the bottom of the four bag attachment *just enough to clear* the bumper on the bagwell and place on top of bumper as shown.

**CAUTION**

**LIFTING UP ON THE BOTTOM OF THE FOUR BAG ATTACHMENT TOO FAR WILL BEND THE RETAINING BRACKETS AT THE TOP, MAKING THE ACCESSORY UNUSABLE.**

4. Loosen knob on clamp sufficiently to place hook under bagwell, setting it into notch in frame.
5. Tighten the bumper clamp by turning knob clockwise until the bottom is secure.
6. Locate the retainer near the center of the four bag attachment. Slide upward to release the bagwell and lower bagwell to horizontal position.

**C. REMOVING FOUR BAG ATTACHMENT FROM VEHICLE**

1. Fold the bagwell up to the vertical support and secure with retainer.
2. Loosen the bumper clamp by turning knob counterclockwise and unhook clamp from bumper.

3. Lift up on the bottom part of the four bag attachment *just enough to clear* the bumper and pull down and away from vehicle.

**CAUTION**

**LIFTING UP ON THE BOTTOM OF THE FOUR BAG ATTACHMENT TOO FAR WILL BEND THE RETAINING BRACKETS AT THE TOP, MAKING THE ACCESSORY UNUSABLE.**

4. Let the bottom part of the four bag attachment angle downward to disengage the retaining brackets at the top.
5. Lift upward and forward simultaneously to remove accessory from vehicle.

ITEM	QTY	PART NO.	DESCRIPTION
1	1	75121-G01	TOP ASSEMBLY
2	1	75334-G01	BOTTOM ASSEMBLY
3	1	17651-G2	PIN, CLEVIS, 5/16 x 1 1/4" LG.
4	1	28129-G01	NUT, PUSH, 5/16"
5	1	75130-G01	LABEL, WARNING (REPLACEMENT)
6	2	00560-G1	WASHER, 3/8" (REPLACEMENT)
7	2	13728-G1	RUBBER BUMPER (REPLACEMENT)

**THE SYMBOL ◁ REFERS TO A NOTE CORRESPONDING TO THE LETTER ENCLOSED WITHIN IT. SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF REPLACEMENT PARTS.**

**TITLE** TXT FOUR BAG ATTACHMENT INST'L INSTRUCTIONS

**REV** -



DRN BY  
ORIG DATE

**A**

DRAWING NO. 75336

PG. 2 OF 2

**NOTE: TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO. 75179-G\***

**READ ALL INSTRUCTIONS BEFORE PROCEEDING.**

<b>TOOL LIST .....</b>	<b>QTY. REQUIRED</b>
Jack, floor.....	1
Safety stands .....	4
Chocks .....	4
Wrench, 7/16" .....	1
Wrench, 1/2" .....	1
Wrench, 9/16" .....	1
Hammer, plastic faced .....	1
Hammer, ball peen.....	1
Center punch .....	1


<b>TOOL LIST.....</b>	<b>QTY. REQUIRED</b>
Ratchet, 3/8" drive.....	1
Extension, 3/8", 3" .....	1
Socket, 7/16" .....	1
Socket, 1/2" .....	1
Socket, 9/16" .....	1
Torque wrench, ft. lbs. 3/8" drive .....	1
Screwdriver, Phillips .....	1
Tape measure.....	1
Rivet Gun for 3/16" pop rivet .....	1

**A. INSTALLING HEAVY DUTY SPRINGS**

**⚠ WARNING ⚠**

**BE SURE THE VEHICLE IS ON A FIRM AND LEVEL SURFACE. NEVER GET UNDER A VEHICLE WHILE IT IS SUPPORTED BY A JACK. USE SAFETY STANDS AND TEST THE STABILITY OF THE VEHICLES ON THE STANDS. ALWAYS PLACE CHOCKS IN FRONT AND BEHIND THE WHEELS THAT ARE NOT TO BE RAISED. USE CAUTION SINCE THE VEHICLE IS EXTREMELY UNSTABLE DURING THE LIFTING PROCESS.**

1. Place chocks in front and behind each front wheel. Center the jack under the rear bumper. (See Fig. 1)



**Fig. 1**

2. Raise the vehicle and place a safety stand under the outer ends of the rear bumper. (See Fig. 1)


<b>TITLE</b>					<b>REV A</b>
<b>CONVERTIBLE CARRIER INSTALLATION INSTRUCTIONS</b>					
<b>EZGO TEXTRON</b>	DRN BY ORIG DATE	J.RICE 05/25/95	REV BY REV DATE	J.RICE 07/14/95	DRAWING NO. 75283
E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA, GA. 30903-0388, 1-800-448-7476					PG. 1 OF 12

3. Lower the jack and test the stability of the vehicle on the two safety stands.
4. At the passenger side, remove the bottom shock absorber nut. (See Fig. 2)

## CAUTION

NEVER LIFT OR SUPPORT THE VEHICLE ON THE REAR AXLE DIFFERENTIAL CASTING.  
BE CAREFUL NOT TO POSITION THE JACK IN AN AREA THAT COULD DAMAGE THE  
BRAKE CABLES OR HANGERS.

5. Place the jack near the center section of the rear axle and raise just enough to place a second set of safety stands at each end of the axle tubes as close to the wheel as possible. (See Fig. 1)
6. Remove the 'U' bolts and securing hardware. The nuts and 'U' bolts may be discarded but the washers should be retained for later use. (See Fig. 2)



**Fig. 2**

7. Remove the shackles and hardware securing the spring to the frame. Remove the spring.
8. Installation of heavy duty spring is the reverse order of disassembly.
9. Install the heavy duty spring (item 1) with 'U' bolts (item 2), washers (removed from old spring), and nuts (item 3). Tighten hardware to 18-22 ft. lbs. torque.

<b>TITLE</b>	<b>CONVERTIBLE CARRIER INSTALLATION INSTRUCTIONS</b>	<b>REV A</b>
<b>EZGO TEXTRON</b>	DRN BY J.RICE ORIG DATE 05/25/95	REV BY J.RICE REV DATE 07/14/95
	DRAWING NO. 75283	PG. 2 OF 12

## NOTE

*When installing rear spring shackles, be sure that the cupped side of the shackle plate faces the spring.*

10. Replace the hardware to secure the front end of the spring to the frame. Tighten to 21 - 25 ft. lbs. torque.
11. Replace the hardware and shackles to secure the rear end of the spring to frame. Tighten to 18 - 22 ft. lbs. torque.
12. Replace the shock absorber nut. It must be tightened until the shock absorber bushing expands to the diameter of the shock absorber washer.
13. Repeat procedure at driver's side of vehicle.

### B. INSTALLING SEAT BACK SUPPORT (Refer to Fig. 3)

1. Remove the existing seat back from the seat back support and retain hardware. Remove the seat back support and bag rack assembly from the frame of the vehicle.
2. Place spacer (item 25) on frame and install the new seat back supports (item 4) to the frame using washers (item 5) and bolts (item 6). Finger tighten hardware to allow for adjustment.




Fig. 3

3. Using existing hardware, secure the existing seat back to the new seat back support. Tighten to 5 - 7 ft. lbs. torque.
4. Install rubber bumpers (item 10) on vertical part of seat support bracket using one lock nut (item 11) (per bumper) as shown in Fig. 3. Tighten to dimension specified.
5. Tighten bolts (item 6) to 21 - 25 ft. lbs. torque.

TITLE **CONVERTIBLE CARRIER INSTALLATION INSTRUCTIONS**

REV A

**EZGO TEXTRON**

DRN BY J.RICE  
ORIG DATE 05/25/95

REV BY J.RICE  
REV DATE 07/14/95

DRAWING NO. 75283

PG. 3 OF 12

### C. INSTALLING NEW REAR BUMPER

1. Remove screw and washer fastening each end of existing bumper to rear fender. (On later models remove rivet.)
2. Remove hole plugs (4 places) in existing rear bumper and remove bolts securing bumper to vehicle.
3. Remove bumper and replace with new bumper (item 24) contained in kit, using bolts removed above to re-attach bumper to vehicle. Note the new bumper is secured with bolts inserted through the inner 2 mounting holes only. (See Fig. 4) Tighten to 21 - 25 ft. lbs. torque.
4. Fasten each end of bumper to rear fender using rivet (item 49). (Hole in fender may need to be enlarged to 13/64".)
5. Install hole plugs, removed earlier, in all 4 holes.

### D. INSTALLING VERTICAL FRAME SUPPORT.




Fig. 4

1. Place vertical frame support (items 12 and 13) between the seat back support and bagwell as shown. Insert bolt (item 14) and washer (item 5) from inside bagwell and place washer (item 5) and nut (item 3) underneath frame (See Fig. 4). Finger tighten the hardware since the bottom washer and nut will be removed later for further installation.
2. Secure the top of the vertical frame support to the seat back support using bolt (item 15), washers (item 5) and nut (item 3) (See Fig. 4). Do not tighten hardware.

TITLE		<b>CONVERTIBLE CARRIER INSTALLATION INSTRUCTIONS</b>				REV A	
<b>EZGO TEXTRON</b>		DRN BY	J. RICE	REV BY	J. RICE	DRAWING NO.	75283
		ORIG DATE	05/25/95	REV DATE	07/14/95	PG. 4 OF 12	

## NOTE

At this point, before tightening any hardware, it is critical the exact spacing is achieved to accommodate the fitting of the seat assembly into the channels of the seat back support.

3. As a 'test fit', place the support frame (item 26) into the channels of the seat back support (See Fig. 6) and tighten the hardware securing the seat back support to the vehicle frame and vertical frame support to 21-25 ft. lbs. torque.
4. Remove the support frame.

### E. INSTALLING FOOT REST

1. Before attaching foot rest (item 19), mark hole centers as dimensioned and attach support tube (item 29) to foot rest with self drilling and tapping screws (item 41). Insert hole plugs (item 43) and end plugs (item 42) in support tube. (See Fig. 5)
2. Install the end plugs (item 18) into the tubing ends of the foot rest (item 19).
3. Remove the nut (item 3) and washer (item 5) (previously installed) from the underside of the frame. (See Fig. 5)




Fig. 5

TITLE CONVERTIBLE CARRIER INSTALLATION INSTRUCTIONS

REV A

**EZGO** **TEXTRON**

DRN BY J.RICE  
ORIG DATE 05/25/95

REV BY J.RICE  
REV DATE 07/14/95


DRAWING NO. 75283

PG. 5 OF 12

## NOTE

*Installation Tip: To perform step 4, it may require the assistance of another person or it may be necessary to use a jack to raise and hold the foot rest while installing hardware.*

4. Place the foot rest (item 19) up against the bottom of bumper aligning the bolts that were previously installed in the bagwell with the holes in the horizontal part of the foot rest bracket. Be sure the vertical part of the foot rest bracket is inserted between the bumper and the vertical frame supports. See Detail in Fig. 5
5. Reinstall the washer and nut under the bagwell. Finger tighten to allow adjustment.
6. Align holes in foot rest bracket with holes in vertical frame support.
7. Insert carriage bolt (item 20) through the hole in bracket and vertical support and secure with washer (item 5) and nut (item 3). (See Fig. 5)
8. Tighten the nut (item 3) on the underside of the frame to 21 - 25 ft. lbs. torque. (See Fig. 5)



**Fig. 6**

### **F. INSTALLING SUPPORT FRAME (Refer to Fig. 6)**

1. Insert the nylon bushings (item 21) into the pivot brackets in the support frame (item 26) (4 places).
2. Place the support frame into the channels of the seat back support aligning pivot brackets with existing holes.
3. Insert the bolt (item 31) through the pivot from the center of vehicle (2 places) and secure with washer (item 36) and nut (item 34).
4. Secure front of support frame to seat back support using bolt (item 38), washer (item 36) and nut (item 11).
5. Insert end plug (item 44) in each end of both tubes of support frame.

TITLE <b>CONVERTIBLE CARRIER INSTALLATION INSTRUCTIONS</b>					REV <b>A</b>		
<b>E-Z-GO</b> <b>TEXTRON</b>		DRN BY ORIG DATE	J. RICE 05/25/95	REV BY REV DATE	J. RICE 07/14/95	DRAWING NO. 75283	PG. 6 OF 12

### G. INSTALLING FIXED BED (Refer to Fig. 6)

1. Attach fixed bed (item 30) to support frame (item 26) using bolt (item 45) and washer (item 36). (Two places on each end of fixed bed. Do not tighten hardware at this time as some adjustment may be necessary.

### H. INSTALLING HANDRAIL (Refer to Fig. 7)

1. Insert end plug (item 42) in each end of handrail (item 27).
2. Attach handrail at forward end of support frame (item 26) using bolt (item 48), lock washer (item 37) and acorn nut (item 35). Do not tighten hardware at this time.
3. Repeat procedure on other side of support frame.

### I. INSTALLING LOAD BED AND SEAT BOTTOM (Refer to Fig. 7)

1. Position load bed (item 28) in support frame as shown.
2. Position seat bottom (item 47) in support frame as shown.
3. Insert teflon washer (item 32) between support frame and load bed and again between load bed and seat bottom as shown.
4. Secure all components by inserting bolt (item 23) through handrail, support frame, washer, bed assembly, washer and seat bottom and secure with lock nut (item 34). (See Detail in Fig. 8) Tighten fixed bed hardware to 5 - 7 ft. lbs. torque and handrail hardware to 12 - 14 ft. lbs. torque.

### J. INSTALLING VALANCE PANEL

1. Place the valance panel (item 16) as shown in Fig. 7 with the sides inside the bagwell.
2. Secure the valance panel to the vertical support brackets using two rivets (item 17) in each bracket.




Fig. 7

TITLE **CONVERTIBLE CARRIER INSTALLATION INSTRUCTIONS**

REV A

**EZGO** **TEXTRON**

DRN BY J.RICE  
ORIG DATE 05/25/95

REV BY J.RICE  
REV DATE 07/14/95

DRAWING NO. 75283

PG. 7 OF 12

### K. INSTALLING SEAT BACK (Refer to Fig. 8)

1. Attach seat back (item 46) to seat back support (item 22) using bolt (item 7), lock washer (item 8) and washer (item 9). Tighten to 5 - 7 ft. lbs. torque.
2. Secure seat back to handrail using bolt (item 39) and acorn nut (item 40). Tighten to 5 - 7 ft. lbs torque.
3. Insert end plug (item 33) in each end of seat back support tube.






Fig. 8

TITLE		CONVERTIBLE CARRIER INSTALLATION INSTRUCTIONS				REV A		
<b>EZGO</b> <b>TEXTRON</b>		DRN BY	J.RICE	REV BY	J.RICE	DRAWING NO.	75283	PG. 8 OF 12
		ORIG DATE	05/25/95	REV DATE	07/14/95			
E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA, GA. 30903-0388, 1-800-448-7476								


NOTE: HARDWARE SHOWN ACTUAL SIZE




Item 3  
3/8-16 Lock Nut  
Qty. 14




Item 5  
3/8" Washer  
Qty. 14




Item 6  
3/8-16 x 1 1/4" Bolt  
Qty. 4




Item 7  
1/4-20 x 1" Bolt  
Qty. 4




Item 8  
1/4" Lock Washer  
Qty. 4




Item 9  
1/4" Washer  
Qty. 4





Item 10  
Adjustable Rubber Bumper  
Qty. 4




Item 11  
5/16-18 Lock Nut  
Qty. 6





Item 14  
3/8-16 x 1 1/2" Bolt  
Qty. 2





Item 15  
3/8-16 x 1" Bolt  
Qty. 2




Item 17  
Plastic Rivet  
Qty. 6



Item 18, 44  
End Plug, 1"  
Qty. 2, 4



Item 20  
3/8-16 x 1 1/4" Carriage Bolt  
Qty. 14



Item 21  
Bushing, Nylon  
Qty. 4



Item 23  
5/16-18 x 1 1/2" Bolt  
Qty. 2

TITLE **CONVERTIBLE CARRIER INSTALLATION INSTRUCTIONS**

REV A

**EZGO TEXTRON**


DRN BY J.RICE  
ORIG DATE 05/25/95

REV BY J.RICE  
REV DATE 07/14/95


DRAWING NO. 75283

PG. 9 OF 12


NOTE: HARDWARE SHOWN ACTUAL SIZE




Item 31  
5/16-18 x 2 1/2" Bolt  
Qty. 2




Item 32  
5/8" Washer, Teflon  
Qty. 4




Item 33, 42  
End Plug, 3/4"  
Qty. 2, 6




Item 34  
5/16-18 Lock Nut  
Qty. 4




Item 35  
5/16-18 Acorn Nut  
Qty. 2



Item 36  
5/16" Washer  
Qty. 4



Item 37  
5/16" Lock Washer  
Qty. 2




Item 38  
5/16-18 x 1" Bolt  
Qty. 2



Item 39  
1/4-20 x 1 3/4" Bolt  
Qty. 2




Item 40  
1/4-20 Acorn Nut  
Qty. 2



Item 41  
#12-24 x 3/4" Screw  
Qty. 2




Item 43  
Hole Plug, 1/2"  
Qty. 2



Item 45  
1/4-20 x 3/4" Bolt  
Qty. 4



Item 48  
5/16-18 x 1 1/4" Bolt  
Qty. 2



Item 49  
Rivet, 3/16"  
Qty. 2

NOTE:

Items 18 and 44 are the same in appearance. However, item 18 is for 14 gauge tubing and 44 is for 11 gauge tubing.

Items 33 and 42 are the same in appearance. However, item 33 is for 11 gauge tubing and 42 is for 14 gauge tubing.

Check fit each end plug for tightest fit for correct application.

TITLE				CONVERTIBLE CARRIER INSTALLATION INSTRUCTIONS		REV A	
E-Z-GO TEXTRON		DRN BY ORIG DATE	J.RICE 05/25/95	REV BY REV DATE	J.RICE 07/14/95	DRAWING NO.	75283
E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA, GA. 30903-0388, 1-800-448-7476						PG. 10 OF 12	

## KIT CONTENTS

ITEM	QTY	PART NO.	DESCRIPTION
1	2	74135-G01	SPRING, HEAVY DUTY
2	4	74124-G01	'U' BOLT, 3/8-16 x 2 1/2" LG.
3	14	11098-G5	NUT, LOCK, 3/8-16
4	2	74111-G01	SUPPORT, SEAT BACK
5	14	00560-G1	WASHER, 3/8"
6	4	01006-G02	BOLT, 3/8-16 X 1 1/2" LG.
7	4	00414-G8	BOLT, 1/4-20 X 1" LG.
8	4	00565-G7	WASHER, LOCK, 1/4"
9	4	00559-G7	WASHER, 1/4"
10	4	70113-G01	BUMPER, ADJUSTABLE RUBBER
11	6	11027-G1	NUT, LOCK, 5/16-18
12	1	74126-G02	SUPPORT, VERTICAL FRAME, DRIVER'S SIDE
13	1	74126-G01	SUPPORT, VERTICAL FRAME, PASSENGER SIDE
14	2	00427-G4	BOLT, 3/8-16 X 1 1/2" LG.
15	2	00426-G8	BOLT, 3/8-16 X 1" LG.
16	1	74149-G01	PANEL, VALANCE
17	4	16816-G2	RIVET, PLASTIC
18	2	19853-G1	END PLUG, 1"
19	1	70361-G01	FOOT REST (INCLUDES WARNING LABEL (74132-G01))
20	2	00769-G2	BOLT, CARRIAGE, 3/8-16 X 1 1/4" LG.
21	4	17838-G1	BUSHING, NYLON
22	1	74131-G*	SEAT ASSEMBLY
23	2	00762-G4	BOLT, 5/16-18 X 1 1/2"
24	1	71456-G01	BUMPER, REAR, NOTCHED
25	2	70364-G01	SPACER
26	1	74193-G01	FRAME, SUPPORT
27	2	75196-G01	HANDRAIL
28	1	75229-G01	BED
29	1	75268-G01	TUBE, SUPPORT

<b>TITLE    CONVERTABLE CARRIER INSTALLATION INSTRUCTIONS</b>					<b>REV A</b>	
<b>EZGO TEXTRON</b>	DRN BY ORIG DATE	J.RICE 05/25/95	REV BY REV DATE	J.RICE 07/14/95	DRAWING NO.        75283	PG. 11 OF 12

## KIT CONTENTS

ITEM	QTY	PART NO.	DESCRIPTION
30.....	1.....	75273-G01 .....	BED, FRONT
31.....	2.....	00440-G4 .....	BOLT, 5/16-18 X 2 1/2" LG.
32.....	4.....	17255-G1 .....	WASHER, TEFLON
33.....	2.....	75261-G01 .....	PLUG, END, 3/4"
34.....	4.....	00654-G3 .....	NUT, LOCK, 5/16-18
35.....	2.....	00520-G3 .....	NUT, ACORN, 5/16-18
36.....	4.....	00559-G8 .....	WASHER, 5/16"
37.....	2.....	00664-G8 .....	WASHER, LOCK, 5/16"
38.....	2.....	00438-G8 .....	BOLT, 5/16-18 X 1" LG.
39.....	2.....	16705-G6 .....	BOLT, 1/4-20 X 1 3/4" LG.
40.....	2.....	00520-G1 .....	NUT, ACORN, 1/4-20
41.....	2.....	00106-G6 .....	SCREW, #12-24 X 3/4" LG.
42.....	6.....	19859-G1 .....	END PLUG, 3/4"
43.....	2.....	20271-G2 .....	HOLE PLUG, 1/2"
44.....	4.....	75261-G02 .....	END PLUG, 1"
45.....	4.....	00661-G6 .....	BOLT, 1/4-20 X 3/4" LG.
46.....	1.....	71751-G* .....	SEAT BACK
47.....	1.....	75263-G* .....	SEAT BOTTOM
48.....	2.....	00762-G02 .....	BOLT, 5/16-18 X 1 1/4"
49.....	2.....	71055-G01 .....	RIVET, 3/16"

(G\* is determined by the color of seat back or seat bottom)

TITLE <b>CONVERTIBLE CARRIER INSTALLATION INSTRUCTIONS</b>				REV <b>A</b>
<b>EZGO TEXTRON</b>	DRN BY J.RICE ORIG DATE 05/25/95	REV BY J.RICE REV DATE 07/14/95	DRAWING NO. 75283	PG. 12 OF 12
E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA, GA. 30903-0388, 1-800-448-7476				

**NOTE:** TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO. 74150-G01

**READ ALL INSTRUCTIONS BEFORE PROCEEDING.**

<b>TOOL LIST .....</b>	<b>QTY. REQUIRED</b>
Jack, floor.....	1
Safety stands .....	4
Chocks .....	4
Wrench, 7/16" .....	1
Wrench, 1/2" .....	1
Wrench, 9/16" .....	1
Hammer, plastic faced .....	1
.....	


<b>TOOL LIST.....</b>	<b>QTY. REQUIRED</b>
Ratchet, 3/8" drive .....	1
Extension, 3/8", 3" .....	1
Socket, 7/16" .....	1
Socket, 1/2" .....	1
Socket, 9/16" .....	1
Torque wrench, ft. lbs. 3/8" drive .....	1
Screwdriver, Phillips .....	1
Rivet Gun for 3/16" pop rivet .....	1

**A. INSTALLING HEAVY DUTY SPRINGS**



**BE SURE THE VEHICLE IS ON A FIRM AND LEVEL SURFACE. NEVER GET UNDER A VEHICLE WHILE IT IS SUPPORTED BY A JACK. USE SAFETY STANDS AND TEST THE STABILITY OF THE VEHICLES ON THE STANDS. ALWAYS PLACE CHOCKS IN FRONT AND BEHIND THE WHEELS THAT ARE NOT TO BE RAISED. USE CAUTION SINCE THE VEHICLE IS EXTREMELY UNSTABLE DURING THE LIFTING PROCESS.**

1. Place chocks in front and behind each front wheel. Center the jack under the rear bumper. (See Fig. 1)



**Fig. 1**

2. Raise the vehicle and place a safety stand under the outer ends of the rear bumper. (See Fig. 1)


<b>TITLE    4 CADDY INSTALLATION INSTRUCTIONS</b>						<b>REV A</b>
<b>EZGO TEXTRON</b>	DRN BY ORIG DATE	J. RICE 05/22/95	REV BY REV DATE	J. RICE 07/14/96	DRAWING NO.            74155	PG. 1 OF 8
E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA, GA. 30903-0388, 1-800-448-7476						

3. Lower the jack and test the stability of the vehicle on the two safety stands.
4. At the passenger side, remove the bottom shock absorber nut. (See Fig. 2)

## CAUTION

NEVER LIFT OR SUPPORT THE VEHICLE ON THE REAR AXLE DIFFERENTIAL CASTING.  
BE CAREFUL NOT TO POSITION THE JACK IN AN AREA THAT COULD DAMAGE THE  
BRAKE CABLES OR HANGERS.

5. Place the jack near the center section of the rear axle and raise just enough to place a second set of safety stands at each end of the axle tubes as close to the wheel as possible. (See Fig. 1)
6. Remove the 'U' bolts and securing hardware. The nuts and 'U' bolts may be discarded but the washers should be retained for later use. (See Fig. 2)



**Fig. 2**

7. Remove the shackles and hardware securing the spring to the frame. Remove the spring.
8. Installation of heavy duty spring is the reverse order of disassembly.
9. Install the heavy duty spring (item 1) with 'U' bolts (item 2), washers (removed from old spring), and nuts (item 3). Tighten hardware to 18-22 ft. lbs. torque.

<b>TITLE</b>	<b>4 CADDY INSTALLATION INSTRUCTIONS</b>	<b>REV A</b>
<b>EZGO TEXTRON</b>	DRN BY J.RICE ORIG DATE 05/22/95	REV BY J.RICE REV DATE 07/14/95
	DRAWING NO. 74155	PG. 2 OF 8
E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA, GA. 30903-0388, 1-800-448-7476		

## NOTE

When installing rear spring shackles, be sure that the cupped side of the shackle plate faces the spring.

10. Replace the hardware to secure the front end of the spring to the frame. Tighten to 21 - 25 ft. lbs. torque.
11. Replace the hardware and shackles to secure the rear end of the spring to frame. Tighten to 18 - 22 ft. lbs. torque.
12. Replace the shock absorber nut. It must be tightened until the shock absorber bushing expands to the diameter of the shock absorber washer.
13. Repeat procedure at driver's side of vehicle.

### B. INSTALLING SEAT BACK SUPPORT (Refer to Fig. 3)

1. Remove the existing seat back from the seat back support and retain hardware. Remove the seat back support and bag rack assembly from the frame of the vehicle.
2. Install the new seat back supports (item 4) to the frame using washers (item 5) and bolts (item 6). Finger tighten hardware to allow for adjustment.




Fig. 3

3. Using existing hardware, secure the existing seat back to the new seat back support. Tighten to 5 - 7 ft. lbs. torque.
4. Install rubber bumpers (item 10) on vertical part of seat support bracket using one lock nut (item 11) (per bumper) as shown in Fig. 3. Tighten to dimension specified.
5. Tighten bolts (item 6) to 21 - 25 ft. lbs. torque.

TITLE **4 CADDY INSTALLATION INSTRUCTIONS**

REV A

**EZGO** **TEXTRON**

DRN BY J.RICE  
ORIG DATE 05/22/95

REV BY J.RICE  
REV DATE 07/14/95


DRAWING NO. 74155

PG. 3 OF 8

### C. REPLACING REAR BUMPER

1. Remove screw and washer fastening each end of bumper to rear fender. (In later models remove rivet.)
2. Remove hole plugs (4 places) in rear bumper (item 24) and remove bolts securing bumper to vehicle.
3. Remove bumper and replace with modified bumper contained in kit, using hardware removed above to re-attach bumper to vehicle. Replace bolts using inner 2 mounting holes only. (See Fig. 4) Tighten to 21 - 25 ft. lbs. torque.
4. Fasten each end of bumper to rear fender using 3/16" rivet (item 26). (Hole in fender may need to be enlarged to 13/64")
5. Replace hole plugs, removed earlier, in all 4 holes.

### D. INSTALLING VERTICAL FRAME SUPPORT.



**Fig. 4**

1. Place vertical frame support (items 12 and 13) between the seat back support and bagwell as shown. Insert bolt (item 14) and washer (item 5) from inside bagwell and place washer (item 5) and nut (item 3) underneath frame (See Fig. 4). Finger tighten the hardware since the bottom washer and nut will be removed later for further installation.
2. Secure the top of the vertical frame support to the seat back support using bolt (item 15), washers (item 5) and nut (item 3) (See Fig. 4). Do not tighten hardware to allow for adjustment.

TITLE <b>4 CADDY INSTALLATION INSTRUCTIONS</b>						REV A		
<b>EZGO TEXTRON</b>		DRN BY ORIG DATE	J.RICE 05/22/95	REV BY REV DATE	J.RICE 07/14/95	DRAWING NO.	74155	PG. 4 OF 8
E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA, GA. 30903-0388, 1-800-448-7476								

## NOTE

Before tightening any hardware, it is critical the exact spacing is achieved to accommodate the fitting of the seat assembly into the channels of the seat back support.

3. As a 'test fit', place the seat assembly (item 22) into the channels of the seat back support (See Fig. 6) and tighten the hardware securing the seat back support to the vehicle frame and vertical frame support to 21-25 ft. lbs. torque.
4. Remove the seat assembly.

### E. INSTALLING FOOT REST

1. Install the end plugs (item 18) into the tubing ends of the foot rest assembly (item 19).
2. Remove the nut (item 3) and washer (item 5) (previously installed) from the underside of the frame. (See Fig. 5)




Fig. 5

## NOTE

*Installation Tip: To perform step 3, it may require the assistance of another person or it may be necessary to use a jack to raise and hold the foot rest assembly while installing hardware.*

TITLE **4 CADDY INSTALLATION INSTRUCTIONS**

REV A

**EZGO** **TEXTRON**

DRN BY J.RICE  
ORIG DATE 05/22/95

REV BY J.RICE  
REV DATE 07/14/95

DRAWING NO. 74155

PG. 5 OF 8

3. Place the foot rest (item 19) up against the bottom of bumper aligning the bolts that were previously installed in the bagwell with the holes in the horizontal part of the foot rest bracket. Be sure the vertical part of the foot rest bracket is inserted between the bumper and the vertical frame supports. See Detail in Fig. 5
4. Reinstall the washer and nut under the bagwell. Finger tighten to allow adjustment.
5. Align holes in foot rest bracket with holes in vertical frame support.
6. Insert carriage bolt (item 20) through the hole in bracket and vertical support and secure with washer (item 5) and nut (item 3). (See Fig. 5)
7. Tighten the nut (item 3) on the underside of the frame to 21 - 25 ft. lbs. torque. (See Fig. 5)

#### F. INSTALLING VALANCE PANEL

1. Place the valance panel (item 16) as shown in Fig. 6 with the sides inside the bagwell.
2. Secure the valance panel to the vertical support brackets using two rivets (item 17) in each bracket.

#### G. INSTALLING SEAT ASSEMBLY (Refer to Fig. 6)

1. Insert the nylon bushings (item 21) into the pivot brackets on the seat assembly (item 22, 4 places).
2. Secure the seat assembly into the channels of the seat back support aligning pivot brackets with existing holes.
3. Insert the hitch pin (item 23) through the pivot from the center of vehicle (2 places). (See Fig. 6)






Fig. 6

TITLE <b>4 CADDY INSTALLATION INSTRUCTIONS</b>						REV <b>A</b>
<b>EZGO</b> <b>TEXTRON</b>	DRN BY ORIG DATE	J. RICE 05/22/95	REV BY REV DATE	J. RICE 07/14/95	DRAWING NO. 74155	PG. 6 OF 8
E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA, GA. 30903-0388, 1-800-448-7476						


NOTE: HARDWARE SHOWN ACTUAL SIZE




Item 3  
3/8-16 Lock Nut  
Qty. 14




Item 5  
3/8 Washer  
Qty. 14




Item 6  
3/8-16 x 1 1/2" Bolt  
Qty. 4




Item 7  
1/4-20 x 1" Bolt  
Qty. 4




Item 8  
1/4 Lock Washer  
Qty. 4




Item 9  
1/4 Washer  
Qty. 4




Item 10  
Adjustable Rubber Bumper  
Qty. 4




Item 11  
5/16-18 Lock Nut  
Qty. 6





Item 14  
3/8-16 x 1 1/2" Bolt  
Qty. 2




Item 15  
3/8-16 x 1" Bolt  
Qty. 2





Item 17  
Plastic Rivet  
Qty. 6




Item 18  
End Plug, 1"  
Qty. 2




Item 20  
3/8-16 x 1 1/4" Carriage Bolt  
Qty. 14



Item 21  
Bushing, Nylon  
Qty. 4



Item 23  
Pin, Hitch  
Qty. 2



Item 26  
Rivet, 3/16"  
Qty. 2

TITLE **4 CADDY INSTALLATION INSTRUCTIONS**

REV A

**EZGO** **TEXTRON**

DRN BY J.RICE  
ORIG DATE 05/22/95

REV BY J.RICE  
REV DATE 07/14/95

DRAWING NO. 74155

PG. 7 OF 8

## KIT CONTENTS

ITEM	QTY	PART NO.	DESCRIPTION
1	2	74135-G01	SPRING, HEAVY DUTY
2	4	74124-G01	'U' BOLT, 3/8-16 x 2 1/2" LG.
3	14	11098-G5	NUT, LOCK, 3/8-16
4	2	74111-G01	SUPPORT, SEAT BACK
5	14	00560-G1	WASHER, 3/8
6	4	01006-G02	BOLT, 3/8-16 X 1 1/2" LG.
7	4	00414-G8	BOLT, 1/4-20 X 1" LG.
8	4	00565-G7	WASHER, LOCK, 1/4"
9	4	00559-G7	WASHER, 1/4"
10	4	70113-G01	BUMPER, ADJUSTABLE RUBBER
11	6	11027-G1	NUT, LOCK, 5/16-18
12	1	74126-G02	SUPPORT, VERTICAL FRAME, DRIVER'S SIDE
13	1	74126-G01	SUPPORT, VERTICAL FRAME, PASSENGER SIDE
14	2	00427-G4	BOLT, 3/8-16 X 1 1/2" LG.
15	2	00426-G8	BOLT, 3/8-16 X 1" LG.
16	1	74149-G01	PANEL, VALANCE
17	4	16816-G2	RIVET, PLASTIC
18	2	19853-G1	END PLUG, 1"
19	1	70361-G01	FOOT REST (INCLUDES WARNING LABEL (74132-G01))
20	2	00769-G2	BOLT, CARRIAGE, 3/8-16 X 1 1/4" LG.
21	4	17838-G1	BUSHING, NYLON
22	1	74131-G*	SEAT ASSEMBLY
23	2	74134-G01	PIN, HITCH
24	1	71456-G01	BUMPER, REAR, NOTCHED
25	2	70364-G01	SPACER
26	2	71055-G01	RIVET, 3/16"


<b>TITLE</b>	<b>4 CADDY INSTALLATION INSTRUCTIONS</b>	<b>REV A</b>
--------------	--	--------------

<b>EZGO</b> <b>TEXTRON</b>	DRN BY J.RICE ORIG DATE 05/22/95	REV BY J.RICE REV DATE 07/14/95	DRAWING NO. 74155	PG. 8 OF 8
----------------------------	-------------------------------------	------------------------------------	-------------------	------------


**NOTE:** TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO. 75041-G03 (CLEAR)  
75041-G04 (TINTED)

**READ ALL INSTRUCTIONS BEFORE PROCEEDING.**

1. Insert the rubber grommets (item 3) into the top and bottom holes on both sides of the windshield (item 1 or item 2).
2. Insert the spacers (item 4) into the rubber grommets.
3. From the rear of the windshield, insert the plug bumpers (item 5) into the center holes of the windshield. See Detail A.
4. Place the windshield (item 1 or item 2) against the front strut with the small tapered end at the top.
5. Insert the bolts (item 6) through the windshield and front strut and secure with washers (item 7) and lock nuts (item 8).
6. Tighten enough to ensure that spacer (item 4) does not rattle.



**DETAIL A**



ITEM	QTY	PART NO.	DESCRIPTION
1	1	75160-G01	WINDSHIELD, CLEAR
2	1	75160-G02	WINDSHIELD, TINTED
3	4	72147-G01	GROMMET, RUBBER
4	4	23726-G7	SPACER
5	2	75124-G01	BUMPER, PLUG
6	4	16705-G6	SCREW, 1/4-20 X 1 3/4 LG.
7	4	00660-G7	WASHER, 1/4"
8	4	00891-G2	NUT, LOCK, 1/4-20

THE SYMBOL REFERS TO A NOTE CORRESPONDING TO THE LETTER ENCLOSED WITHIN IT. SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF REPLACEMENT PARTS.

**TITLE 4-CADDY CONVERSION WINDSHIELD INSTALLATION**




DRN BY L WEBB  
ORIG DATE 07/14/94



REV BY A  
REV DATE  
DRAWING NO. 75161

REV A


PG. 1 OF 1




**DETAIL A**



**DETAIL B**



**DETAIL C**  
(FRONT)



**DETAIL D**  
(REAR)

THE SYMBOL  REFERS TO A NOTE CORRESPONDING TO THE LETTER ENCLOSED WITHIN IT. SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF REPLACEMENT PARTS.

TITLE **4-CADDY CONVERSION SUN TOP INSTALLATION**

REV C

**EZ-GO** 

DRN BY L WEBB 07/15/94  
REV BY J.Brand 02/07/96

DRAWING NO. 75158  
A


PG. 1 OF 3

E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA, GA. 30913-2699; 1-800-241-5855


NOTE: ALL HARDWARE SHOWN ACTUAL SIZE




ITEM 16.  
3/8-16 X 5" BOLT  
QTY. 2




ITEM 19  
3/8-16 X 2 1/2" BOLT  
QTY. 2




ITEM 20  
3/8-16 X 2" BOLT  
QTY. 2




ITEM 3  
3/8-16 X 1 3/4" BOLT  
QTY. 4




ITEM 10  
5/16-18 X 2 1/8" BOLT  
QTY. 4




ITEM 17  
SPACER  
QTY. 2




ITEM 4  
3/8 WASHER  
QTY. 18




ITEM 5  
3/8 NYLON WASHER  
QTY. 4




ITEM 6  
3/8-16 LOCK NUT  
QTY. 4




ITEM 11  
5/16" BLACK LOCK WASHER  
QTY. 4





ITEM 12  
SPACER  
QTY. 2



ITEM 13  
3/8" BLACK WASHER  
QTY. 4



ITEM 18  
WASHER  
QTY. 2



ITEM 21  
SPACER  
QTY. 2

THE SYMBOL  REFERS TO A NOTE CORRESPONDING TO THE LETTER ENCLOSED WITHIN IT. SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF REPLACEMENT PARTS.

TITLE 4-CADDY CONVERSION SUN TOP INSTALLATION				REV C
	DRN BY	REV BY	DRAWING	PG. 2 OF 3
	ORIG DATE	REV DATE	NO. 75158	
		J. WEBB	J. BRAND	
		07/14/94	02/07/96	
E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA, GA. 30913-2699, 1-800-241-5855				

NOTE: TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO. 75123-G01

**READ ALL INSTRUCTIONS BEFORE PROCEEDING.**

**A. REAR STRUTS**

1. At driver's side, align the holes in the rear strut (item 1) with the holes in the seat back support bracket, being sure that the open end of the strut faces the rear of the vehicle as shown in Details A and D.
2. Insert the bolt (item 3) and washer (item 4) through the seat back support bracket. Place nylon washer (item 5) between the seat back support bracket and rear strut. Secure with washer (item 4) and lock nut (item 6) at outer side of rear strut as shown in Detail A. **DO NOT TIGHTEN HARDWARE.**
3. Repeat procedure with rear strut (item 2) at passenger side of vehicle.
4. Insert end caps (item 7) into the top of the rear struts as shown in Detail D.

**B. FRONT STRUTS**

1. Remove and discard the four allen head bolts from the front cowl using a 7/32" allen wrench.
2. At the upper hole (both sides of vehicle), install the front strut (item 9) with bolt (item 10) and black lock washer (item 11) on the outside of strut, and a spacer (item 12) between the front cowl and strut. **DO NOT TIGHTEN HARDWARE.** See Detail B.
3. At the lower hole, secure the strut with bolt (item 10) and black lock washer (item 11) on the outside of strut, and two black washers (item 13) between the front cowl and strut. **DO NOT TIGHTEN HARDWARE.** See Detail B.

**C. SUNTOP**

1. Place sun top (item 1) onto struts.
2. **AT FRONT END OF VEHICLE:** Secure sun top loosely with bolts (item 16), washers (item 4), spacers (item 17), washers (item 18) and lock nuts (item 6). See Detail C for hardware sequence. **DO NOT TIGHTEN HARDWARE.**
3. **AT REAR END OF VEHICLE:** At the hole closest to rear of vehicle, insert bolt (item 20) and washer (item 4) and secure with washer (item 4) and lock nut (item 6). See Detail D.
4. Insert bolt (item 19) and washer (item 4) through the other hole. Place spacer (item 21) between sun top and strut. Secure with washer (item 4 and lock nut (item 6). See Detail D.
5. Tighten all hardware to 13 - 15 ft. lbs. torque.

ITEM	QTY	PART NO.	DESCRIPTION
1	1	75074-G01	STRUT, REAR, DRIVER'S SIDE
2	1	75074-G02	STRUT, REAR, PASSENGER SIDE
3	4	00665-G5	BOLT, 3/8-16 X 1 3/4" LG.
4	18	00679-G1	WASHER, 3/8
5	4	00771-G5	WASHER, NYLON, 3/8
6	10	00891-G5	NUT, LOCK, 3/8-16
7	2	19853-G1	CAP, END
8			
9	1	75125-G01	STRUT, FRONT
10	4	71056-G03	BOLT, 5/16-18 X 2 1/8" LG.
11	4	00905-G8	WASHER, LOCK, BLACK, 5/16
12	2	75048-G01	SPACER, 1/2" THICK
13	4	00879-G1	WASHER, BLACK, 3/8
14			
15	1	27604-G01	TOP, SUN
16	2	00674-G8	BOLT, 3/8-16 X 5" LG.
17	2	18716-G1	SPACER
18	2	00653-G1	WASHER, 3/8
19	2	00665-G3	BOLT, 3/8-16 X 2 1/2" LG.
20	2	00665-G6	BOLT, 3/8-16 X 2" LG.
21	2	24647-G1	SPACER, 1/4" THICK

THE SYMBOL  REFERS TO A NOTE CORRESPONDING TO THE LETTER ENCLOSED WITHIN. SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF REPLACEMENT PARTS.

TITLE 4-CADDY CONVERSION SUN TOP INSTALLATION

REV C



DRN BY L. WEBB 07/14/94  
 REV BY J. BRAND 02/07/96  
 REV DATE

DRAWING NO. 75158  
 A

PG. 3 OF 3


**NOTE:** TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO.75278-G\*  
G\* IS DETERMINED BY COLOR OF SEAT

**READ ALL INSTRUCTIONS BEFORE PROCEEDING.**

<b>TOOL LIST</b>	<b>QTY. REQUIRED</b>
Jack, floor.....	1
Ratchet, 3/8" drive.....	1
Extension, 3/8" drive.....	1
Socket, 7/16".....	1
Socket, 1/2".....	1
Socket, 9/16".....	1
Hammer, ball peen.....	1
Center punch.....	1

<b>TOOL LIST</b>	<b>QTY. REQUIRED</b>
Hammer, plastic faced.....	1
Torque wrench, ft. lbs., 3/8" drive.....	1
Wrench, 7/16".....	1
Wrench, 1/2".....	1
Wrench, 9/16".....	1
Screwdriver, Phillips.....	1
Tape measure.....	1

**A. INSTALLING SUPPORT TUBE**



**Fig. 1**

1. Mark hole centers as dimensioned and attach support tube (item 11) to foot rest assembly with self drilling and tapping screws (item 23).

<b>TITLE 4 CADDY TO CONVERTIBLE CARRIER RETROFIT INSTRUCTIONS</b>				<b>REV -</b>
<b>EZGO TEXTRON</b>	DRN BY ORIG DATE	J.RICE 05/04/95	REV BY REV DATE	DRAWING NO. 75284
				PG. 1 OF 7

## B. REMOVING SEAT

1. Remove hitch pin at seat pivot, 2 places, and remove seat from vehicle.




Fig. 2

## C. INSTALLING SUPPORT FRAME (Refer to Fig. 3)

1. Insert the nylon bushings (item 5) into the pivot brackets in the support frame (item 8) (4 places).
2. Place the support frame into the channels of the seat back support aligning pivot brackets with existing holes.
3. Insert the bolt (item 13) through the pivot from the center of vehicle (2 places) and secure with washer (item 18) and nut (item 34).
4. Secure front of support frame to seat back support using bolt (item 20), washer (item 18) and nut (item 4).
5. Insert end plug (item 26) in each end of both support frame cross tubes.




Fig. 3

TITLE **4 CADDY TO CONVERTIBLE CARRIER RETROFIT INSTRUCTIONS**

REV -

**EZGO TEXTRON**

DRN BY J. RICE  
ORIG DATE 05/04/95

REV BY  
REV DATE

DRAWING NO. 75284

PG. 2 OF 7

#### D. INSTALLING FIXED BED (Refer to Fig. 3)

1. Attach fixed bed (item 12) to support frame (item 8) using bolt (item 27) and washer (item 18). (Two places on each end of front bed. Tighten to 5 - 7 ft. lbs. torque.

#### E. INSTALLING HANDRAIL (Refer to Fig. 4)

1. Insert end plug (item 24) in each end of handrail (item 9).
2. Attach handrail at forward end of support frame (item 8) using bolt (item 30), lock washer (item 19) and acorn nut (item 17). Do not tighten hardware at this time.
3. Repeat procedure on other side of support frame.

#### F. INSTALLING LOAD BED AND SEAT BOTTOM (Refer to Fig. 4)

1. Position load bed (item 10) in support frame as shown.
2. Position seat bottom (item 29) in support frame as shown.
3. Insert teflon washer (item 14) between support frame and load bed and again between load bed and seat bottom as shown.
4. Secure all components by inserting bolt (item 7) through handrail, support frame, washer, bed assembly, washer and seat bottom and secure with lock nut (item 16). Tighten all handrail hardware to 12 - 14 ft. lbs. torque.




Fig. 4

TITLE **4 CADDY TO CONVERTIBLE CARRIER RETROFIT INSTRUCTIONS**

REV -

**EZGO** **TEXTRON**

DRN BY J.RICE  
ORIG DATE 05/04/95

REV BY  
REV DATE

DRAWING NO. 75284

PG. 3 OF 7

## G. Adjust Seat Back Bumper

1. Loosen nut on each seat back bumper and readjust to dimension shown.




Fig. 5

## H. INSTALLING SEAT BACK (Refer to Fig. 6)

1. Attach seat back (item 28) to seat back support (item 6) using bolt (item 1), lock washer (item 2) and washer (item 3). Tighten to 5 - 7 ft. lbs. torque.
2. Secure seat back to handrail using bolt (item 21) and acorn nut (item 22). Tighten to 5 - 7 ft. lbs torque.
3. Insert end plug (item 15) in each end of seat back support tube.




Fig. 6

TITLE **4 CADDY TO CONVERTIBLE CARRIER RETROFIT INSTRUCTIONS**

REV -

**EZGO TEXTRON**


DRN BY J.RICE  
ORIG DATE 05/04/95

REV BY  
REV DATE


DRAWING NO. 75284

PG. 4 OF 7


NOTE: HARDWARE SHOWN ACTUAL SIZE




Item 1  
1/4-20 x 1" Bolt  
Qty. 4




Item 2  
1/4" Lock Washer  
Qty. 4



Item 3  
1/4" Washer  
Qty. 4




Item 4  
5/16-18 Lock Nut  
Qty. 6




Item 5  
Bushings, Nylon  
Qty. 4




Item 7  
5/16-18 x 1 1/2" Bolt  
Qty. 2




Item 13  
5/16-18 x 2 1/2" Bolt  
Qty. 2



Item 14  
5/8" Washer, Teflon  
Qty. 4




Item 15, 24  
End Plug, 3/4"  
Qty. 2,6




Item 16  
5/16-18 Lock Nut  
Qty. 4



Item 17  
5/16-18 Acorn Nut  
Qty. 2



Item 18  
5/16" Washer  
Qty. 2



Item 19  
5/16" Lock Washer  
Qty. 2

NOTE:

Items 15 and 24 are the same in appearance. However, item 15 is for 11 gauge tubing and 24 is for 14 gauge tubing.

Check fit each end plug for tightest fit for correct application.

TITLE **4 CADDY TO CONVERTIBLE CARRIER RETROFIT INSTRUCTIONS**

REV -

**EZGO TEXTRON**


DRN BY J.RICE  
ORIG DATE 05/04/96

REV BY  
REV DATE

DRAWING NO. 75284

PG. 5 OF 7


NOTE: HARDWARE SHOWN ACTUAL SIZE




Item 20  
5/16-18 x 1" Bolt  
Qty. 2




Item 21  
1/4-20 x 1 3/4" Bolt  
Qty. 2




Item 22  
1/4-20 Acorn Nut  
Qty. 2




Item 23  
#12-24 x 3/4" Screw  
Qty. 2




Item 25  
Hole Plug, 1/2"  
Qty. 2



Item 26  
End Plug, 1"  
Qty. 2



Item 27  
1/4-20 x 3/4" Bolt  
Qty. 4



Item 30  
5/16-18 X 1 1/4" Bolt  
Qty. 2

TITLE **4 CADDY TO CONVERTIBLE CARRIER RETROFIT INSTRUCTIONS**

REV -

**EZGO** **TEXTRON**

DRN BY J.RICE  
ORIG DATE 05/04/95

REV BY  
REV DATE

DRAWING NO. 75284

PG. 6 OF 7

## KIT CONTENTS

ITEM	QTY	PART NO.	DESCRIPTION
1	4	00414-G8	BOLT, 1/4-20 X 1" LG.
2	8	00664-G7	WASHER, LOCK, 1/4"
3	4	00559-G7	WASHER, 1/4"
4	4	11027-G1	NUT, LOCK, 5/16-18
5	4	17838-G1	BUSHING, NYLON
6	1	75258-G01	SUPPORT, SEAT BACK
7	2	00762-G4	BOLT, 5/16-18 X 1 1/2"
8	1	74193-G01	FRAME, SUPPORT
9	2	75196-G01	HANDRAIL
10	1	75229-G01	BED
11	1	75268-G01	TUBE, SUPPORT
12	1	75273-G01	BED, FRONT
13	2	00440-G4	BOLT, 5/16-18 X 2 1/2" LG.
14	4	17255-G1	WASHER, TEFLON
15	2	75261-G01	PLUG, END, 3/4"
16	4	00654-G3	NUT, LOCK, 5/16-18
17	2	00520-G3	NUT, ACORN, 5/16-18
18	2	00559-G8	WASHER, 5/16"
19	2	00664-G8	WASHER, LOCK, 5/16"
20	2	00438-G8	BOLT, 5/16-18 X 1" LG.
21	2	16705-G6	BOLT, 1/4-20 X 1 3/4" LG.
22	2	00520-G1	NUT, ACORN, 1/4-20
23	2	00106-G6	SCREW, #12-24 X 3/4" LG.
24	6	19859-G1	END PLUG, 3/4"
25	2	20271-G2	HOLE PLUG, 1/2"
26	4	75261-G02	END PLUG, 1"
27	4	00661-G6	BOLT, 1/4-20 X 3/4" LG.
28	1	71751-G*	SEAT BACK
29	1	75263-G*	SEAT BOTTOM
30	2	00762-G02	BOLT, 5/16"-18 X 1 1/4"

*NOTE: G\* is determined by the color of seat back and seat bottom*

<b>TITLE</b>	<b>4 CADDY TO CONVERTIBLE CARRIER RETROFIT INSTRUCTIONS</b>	<b>REV -</b>
<b>EZGO TEXTRON</b>	DRN BY J.RICE ORIG DATE 06/04/95	REV BY REV DATE
	DRAWING NO. 75284	PG. 7 OF 7
E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA, GA. 30903-0388, 1-800-448-7476		


**NOTE:** TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO.75310-G01

**READ ALL INSTRUCTIONS BEFORE PROCEEDING.**

TOOL LIST	QTY. REQUIRED	TOOL LIST	QTY. REQUIRED
Ratchet, 1/2" drive.....	1	Wrench, 7/16".....	1
Socket, 7/16", 1/2" Drive.....	1	Wrench, 9/16".....	1
Socket, 9/16", 1/2" Drive.....	1	Wrench, 3/4".....	1
Socket, 3/4", 1/2" Drive.....	1	Wrench, 7/8".....	1
Socket, 7/8", 1/2" Drive.....	1	Wrench, 1 1/8".....	1
Socket, 1 1/8", 1/2" Drive.....	1	Screwdriver, Phillips.....	1
Torque Wrench, ft. lbs., 1/2" Drive.....	1	Pliers.....	1
Allen Wrench, 3/16".....	1		

**A. INSTALLING TOW BAR ON TOWING VEHICLE**

1. Tow bar has been partially assembled for your convenience.
2. Remove nut (item 9) and washer (item 8) from bolt (item 5).
3. Place tow bar into bagwell as shown and insert bolt through hole in center of bagwell near rear bumper.
4. Place washer (item 8) on bolt and secure tow bar to vehicle with nut (item 9). Tighten to 40 - 45 ft. lbs. torque.
5. Insert bolt (item 20) through male stop (item 19) and attach to tow bar weld nut as shown. Tighten by turning male stop until tight.



**Fig. 1**

TITLE			<b>PERMANENT TOW BAR INSTALLATION INSTRUCTIONS</b>			REV C			
<b>EZGO TEXTRON</b>			DRN BY ORIG DATE	J.RICE 07/05/95	REV BY REV DATE	J.RICE 11/01/95	DRAWING NO.	75311	PG. 1 OF 8

## B. INSTALLING TOWED VEHICLE HITCH

1. Remove cotter pins (item 27) from both ends of pivot bolt (item 23).
2. Loosen slotted nut (item 26) on lower end of pivot bolt.
3. Remove nut (item 30) and lock washer (item 29) from upper end of pivot bolt.
4. With bolt inserted through hitch (item 22), and thrust washer (item 24) on top of hitch, insert pivot bolt through bracket on front axle from bottom and secure with washer (item 29) and nut (item 30). Tighten to 75 - 150 ft. lbs. torque. (Ensure thrust washer (item 24) between hitch and bracket is not pinched by bolt flange.) Insert cotter pin (item 27) through hole in pivot bolt and bend over with pliers.
5. While moving hitch back and forth, tighten slotted nut on bottom of pivot bolt until hitch moves freely and vertical play in joint is minimized. (Ensure thrust washer (item 24) is not pinched by bolt flange.) Align a nut slot with a hole in pivot bolt, insert cotter pin (item 27) and bend over with pliers.
6. Insert tie rod ball joint into passenger side spindle from the bottom and tighten slotted nut (Item 39) until ball joint is seated in spindle (36 ft.lbs. minimum). Insert cotter pin (item 40) through slotted nut and ball joint if possible. Continue to tighten nut as necessary to insert cotter pin. Bend over cotter pin with pliers.
7. With front wheels turned straight ahead, adjust tow bar tie rod length so that hitch is also pointing straight. Retighten jam nuts.




Fig. 2

TITLE		PERMANENT TOW BAR INSTALLATION INSTRUCTIONS				REV C		
<b>EZGO</b> <b>TEXTRON</b>		DRN BY	J.RICE	REV BY	J.RICE	DRAWING NO.	75311	PG. 2 OF 8
		ORIG DATE	07/05/95	REV DATE	11/01/95			
E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA, GA. 30903-0388, 1-800-448-7476								

### C. INSTALLING TOW BAR STOP

1. Insert bolt (item 43) through stop (female) (item 19) and loosely attach to stop mounting plate with nut (item 44).
2. Insert bolts (item 43) through mounting plate (item 41) and place in center of basket bottom, near bagrack.
3. Place stop mounting plate under center basket as shown and loosely secure with nuts (item 44).




Fig. 3

4. Raise tow bar to vertical position and adjust stop (female) (item 19) position in mounting plate (item 42) slot until tow bar stop (male) is easily inserted into stop (female) and tow bar is held securely in vertical position. Slide plates back to position tow bar as close to basket as possible.
5. Tighten all mounting hardware to 10 ft. lbs. torque.

### D. TOWING A VEHICLE

1. Position towing vehicle in front of vehicle to be towed.
2. Lower tow bar to horizontal position and engage tow bar onto hitch, ensuring latch is seated and hitch is securely captured by tow bar latch. Slide latch stop snugly under latch preventing latch from opening.
3. Check tow bar connection by moving tow bar up and down, sideways, and pushing vehicles apart. Tow bar must not separate from towed vehicle hitch.
4. Do not tow at speeds greater than 5 mph, and do not tow more than 3 vehicles at a time.
5. NOTE: Inspect tow bar latch for material deterioration before and after each use and repair as necessary.

TITLE

PERMANENT TOW BAR INSTALLATION INSTRUCTIONS

REV C


**EZGO** **TEXTRON**

DRN BY J.RICE  
ORIG DATE 07/05/95

REV BY J.RICE  
REV DATE 11/01/95

DRAWING NO. 75311


PG. 3 OF 8




TITLE **PERMANENT TOW BAR INSTALLATION INSTRUCTIONS** REV C

<b>EZGO</b> <b>TEXTRON</b>	DRN BY	J.RICE	REV BY	J.RICE	DRAWING NO.	75311	PG. 4 OF 8
	ORIG DATE	07/05/95	REV DATE	11/01/95			


NOTE: HARDWARE SHOWN ACTUAL SIZE




Item 5  
1/2-20 X 3" Bolt  
Qty. 1



Item 6  
1/2" Washer  
Qty. 1





Item 7  
Spring Washer  
Qty. 1





Item 8  
1/2" Washer  
Qty. 1




Item 9  
1/2-20 Lock Nut  
Qty. 1



Item 10  
Latch Stop  
Qty. 1



Item 11  
Delrin Washer  
Qty. 2




Item 12  
Pivot Pin  
Qty. 1




Item 13  
Coil Spring Pin  
Qty. 1



Item 15  
Compression Spring  
Qty. 1



Item 16  
Cup Washer  
Qty. 1



Item 17  
3/8 x 1 5/8" Shoulder Bolt  
Qty. 1



Item 20  
6mm X 30mm Bolt  
Qty. 1

TITLE **PERMANENT TOW BAR INSTALLATION INSTRUCTIONS**

REV C

**EZGO TEXTRON**


DRN BY J.RICE  
ORIG DATE 07/05/95

REV BY J.RICE  
REV DATE 11/01/95


DRAWING NO. 75311

PG. 5 OF 8


NOTE: HARDWARE SHOWN ACTUAL SIZE




Item 24  
Thrust Washer  
Qty. 2




Item 25  
Washer  
Qty. 1




Item 26  
3/4-16 Castle Nut  
Qty. 1




Item 28  
Bearing  
Qty. 1




Item 29  
3/4" Lock Washer  
Qty. 1



Item 30  
3/4-16 Nut  
Qty. 1



Item 39  
7/16-20 Castle Nut  
Qty. 2




Item 27  
1/8 X 1 1/4" Cotter Pin  
Qty. 2



Item 40  
3/32 X 1" Cotter Pin  
Qty. 2



Item 43  
1/4-20- X 1" Bolt  
Qty. 3



Item 44  
1/4-20 Lock Nut  
Qty. 3

TITLE **PERMANENT TOW BAR INSTALLATION INSTRUCTIONS**

REV C

**EZGO** **TEXTRON**

DRN BY J.RICE  
ORIG DATE 07/05/95

REV BY J.RICE  
REV DATE 11/01/95

DRAWING NO. 75311

PG. 6 OF 8

## KIT CONTENTS

ITEM	QTY	PART NO.	DESCRIPTION
1	1	75304-G01	TOW BAR (TOWING VEHICLE) (INCLUDES ITEMS 2 - 18)
2	1	75299-G01	TOW BAR
3	1	75302-G01	UPPER PIVOT
4	1	75291-G01	LOWER PIVOT
5	1	00410-G8	BOLT, 1/2-20 X 3" LG.
6	1	00675-G3	WASHER, 1/2"
7	1	75339-G01	SPRING WASHER
8	1	00571-G5	WASHER, 1/2"
9	1	11098-G8	LOCK NUT, 1/2-20
10	1	75362-G01	LATCH STOP
11	2	75340-G01	DELTRIN WASHER
12	2	75360-G01	PIVOT PIN
13	2	13571-G7	SPRING PIN
14	1	75303-G01	LATCH
15	1	20852-G2	COMPRESSION SPRING
16	1	25661-G02	CUP WASHER
17	1	13005-G4	SHOULDER BOLT, 3/8 X 1 5/8" LG.
18	1	75370-G01	WARNING LABEL
19	1	75338-G01	STOP (MALE AND FEMALE)
20	1	12547-G4	SCREW, 6mm x 30 mm
21	1	75308-G01	TOW BAR HITCH (TOWED VEHICLE) (INCLUDES ITEMS 22 - 40)
22	1	75305-G01	HITCH
23	1	75292-G01	PIVOT BOLT
24	2	75309-G01	THRUST WASHER
25	1	75342-G01	WASHER
26	1	00518-G8	CASTELLATED NUT, 3/4-16
27	2	10387-G1	COTTER PIN, 1/8 X 1 1/4" LG.
28	1	75307-G01	BEARING
29	1	00566-G6	LOCK WASHER, 3/4"
30	1	00533-G8	NUT, 3/4-16

<b>TITLE</b>	<b>PERMANENT TOW BAR INSTALLATION INSTRUCTIONS</b>	<b>REV C</b>
<b>EZGO TEXTRON</b>	DRN BY J.RICE ORIG DATE 07/05/95	REV BY J.RICE REV DATE 11/01/95
	DRAWING NO. 75311	PG. 7 OF 8
E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA, GA. 30903-0388, 1-800-448-7476		

## KIT CONTENTS

ITEM	QTY	PART NO.	DESCRIPTION
31	1	75306-G01	TIE ROD (INCLUDES ITEMS 30 - 39)
32	1	75287-G01	STEERING LINK
33	1	27205-G01	TIE ROD END (LEFT HAND THREADS)
34	1	*	JAM NUT, 9/16-18 (LEFT HAND THREADS)
35	1	27205-G02	TIE ROD END (RIGHT HAND THREADS))
36	1	*	JAM NUT, 9/16-18 (RIGHT HAND THREADS)
37	2	10389-G3	STRAIGHT GREASE FITTING
38	2	50641-G1	RUBBER BOOT
39	2	50209-G2	CASTELLATED NUT, , 7/16-20
40	2	10387-G2	COTTER PIN, 3/32 X 1" LG.
41	1	75318-G01	MOUNTING PLATE
42	1	75319-G01	STOP MOUNT PLATE
43	3	16705-G1	BOLT, 1/4-20 X 1" LG.
44	3	00891-G2	LOCK NUT, 1/4-20

<b>TITLE    PERMANENT TOW BAR INSTALLATION INSTRUCTIONS</b>			<b>REV C</b>
	DRN BY    J,RICE ORIG DATE    07/05/95	REV BY    J,RICE REV DATE    11/01/95	DRAWING NO.    75311
E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA, GA. 30903-0388, 1-800-448-7476			


# DIAGRAMS AND SCHEMATICS

## WIRING DIAGRAMS AND SCHEMATICS

REFER TO TECHNICIAN'S REPAIR AND SERVICE MANUAL FOR  
NOTES, CAUTIONS AND WARNINGS.

MANUAL P/N: 28292-G01


# ELECTRIC VEHICLE ACCESSORY WIRING



FOR VEHICLES WITHOUT TURN SIGNALS REMOVE WHT WIRE FROM LEFT TURN SIGNAL  
 REMOVE YEL WIRE FROM RIGHT TURN SIGNAL CONNECT BRN WIRE TO RED

● INDICATES BUTT CONNECTION WITHIN WIRING HARNESS

# ELECTRIC VEHICLE WIRING DIAGRAM / SCHEMATIC



WIRES INDICATED  ARE CONTAINED IN POWER HARNESS  
 ALL OTHER WIRES ARE CONTROL WIRING  
 MS2 IS CLOSED WHEN DIRECTION SELECTOR SWITCH IS IN FWD OR REVERSE  
 MS3 IS ACTIVATED BY ACCELERATOR PEDAL  
 MS4 IS CLOSED BY DIRECTION SELECTOR SWITCH IN REVERSE ONLY







E-Z-GO Division of Textron Inc.  
P.O. Box 388 Augusta, Georgia 30903-0388 USA  
Inside USA Phone: 1-800-241-5855, FAX: 1-800-448-8124  
Outside USA Phone: 010-1-706-798-4311, FAX: 010-1-706-771-4609

Copyrighted Material  
This manual may not be reproduced in whole or  
in part without the express permission of  
E-Z-GO Division of Textron Inc.  
Technical Communications Department