



# YAMAHA G9, G14E, G16E WITH SERIES MOTOR - 3 WIRE THROTTLE

- \* REMOVE BATTERIES AND CONTROLLER. CUT OFF WIRES FLUSH WITH FACEPLATE OF OLD CONTROLLER
- \* CRIMP 3/16" RING TERM ON YEL/BLK WIRE. CONNECT TO SOLENOID WITH RED/WHT WIRE. CUT OFF BLUE WIRE FLUSH W/CONNECTOR
- \* CRIMP 1/4" FEMALE SPADE TO WIRES. CONNECT AS SHOWN
- \* BEND CONTROLLER IN CAR BACK TOWARDS BATTERIES, DRILL NEW HOLES FOR CONTROLLER AND INSTALL.
- \* CONNECT LARGE WIRES TO CONTROLLER AS FOLLOWS:  
 > A2 TO M- < B+ TO B+ < B- TO B-
- \* RECONNECT THROTTLE SENSOR PLUG AND PINK WIRE
- \* CUT OFF BROWN WIRE AND TAPE END (DR HEATSHRINK)
- \* ADD RESISTOR ACROSS SOLENOID (NOT INCLUDED)
- \* ADD DIODE ACROSS SOLENOID COIL (NOT INCLUDED)

REVISIONS			DWG SCALE: NTS		
REV.	ECO.	DATE	APVD	DRWN	TTHome
A	010407	010407	TT		

PROPRIETARY  
 THIS DESIGN, DRAWING OR INFORMATION IS THE PROPERTY OF D&D MOTOR SYSTEMS, INC. AND IS TO BE KEPT CONFIDENTIAL. NO PART OF THIS DOCUMENTATION IS TO BE REPRODUCED, COPIED, OR DISCLOSED IN ANY MANNER WITHOUT THE WRITTEN PERMISSION OF D&D.

FILE	YMA-03-14-16-wire-dia.dwg	SHEET	101
------	---------------------------	-------	-----

DO NOT SCALE DRAWING