


# SERVICE PARTS MANUAL



# **ELECTRIC AND GASOLINE METAL VEHICLES**

MANUAL: 28081-G01

MODEL YEAR: 1994/1995 ISSUED: 01/04/94

**REVISED: 07/12/95** 

# **SERVICE PARTS MANUAL**

# MEDALIST ELECTRIC AND GASOLINE VEHICLES

MODEL YEARS: 94/95

#### **VEHICLES**

MEDALIST FLEET GASOLINE

MEDALIST FLEET ELECTRIC

MEDALIST FLEET DCS ELECTRIC

MEDALIST FLEET FREEDOM GASOLINE

MEDALIST FREEDOM HP GASOLINE

MEDALIST FREEDOM ELECTRIC

MEDALIST FREEDOM DCS ELECTRIC

MEDALIST 4 CADDY GASOLINE

MEDALIST 4 CADDY ELECTRIC

CUSTOMER SERVICE DEPARTMENT PHONE 1-800-227-7029 FAX 1-800-752-6175 E-Z-GO DIVISION OF TEXTRON, INC., P.O.BOX 388, AUGUSTA, GEORGIA 30903-0388, 1-800-241-5855

## **LIMITED WARRANTY**

# WARRANTY

TO OBTAIN A COPY OF THE LIMITED WARRANTY THAT IS APPLICABLE TO YOUR VEHICLE, CALL OR WRITE YOUR LOCAL DISTRIBUTOR, BRANCH OR E-Z-GO WARRANTY DEPARTMENT.

THE USE OF NON E-Z-GO PARTS MAY VOID YOUR WARRANTY.

OVERFILLING OF BATTERIES MAY VOID YOUR WARRANTY.

TAMPERING WITH OR ADJUSTING OF GOVERNOR TO PERMIT THE VEHICLE TO OPERATE AT ABOVE FACTORY SETTINGS (12 - 15 MPH) WILL VOID YOUR VEHICLE WARRANTY.



ENGINE EXHAUST FROM THIS PRODUCT CONTAINS CHEMICALS KNOWN, IN CERTAIN QUANTITIES, TO CAUSE CANCER, BIRTH DEFECTS, OR OTHER REPRODUCTIVE HARM.

SECTIONS		***************************************	Page No.
How to use the E-Z-GO Service Ma	ınual	***************************************	VÍÍ
California Emisssions Warranty	***************************************	***************************************	Back Cover
Fuji Engine Warranty	••••••		Back Cover
Illustrated Parts Breakdo	wn:		
	ELECTRIC	GASOLINE	ELECTRIC/GASOLINE
	VEHICLE	VEHICLE	VEHICLE
Illustration	Page No.	Page No.	Page No.
ACCELERATOR LINKAGE	A-1	B-1	_
<ul> <li>Accelerator Pedal</li> </ul>			
<ul> <li>Accelerator Rod</li> </ul>			
BATTERY CHARGER, TC® III, 36 Y	VDCC-1		
BATTERY CHARGER, POWERWIS	SE™C-7		
BATTERY CHARGER, POWERWIS	SE™ +C-13		
BODY AND ASSOCIATED PARTS	******************		D-1
Bagwell			
<ul> <li>Battery Racks</li> </ul>			
<ul> <li>Center Console</li> </ul>			
<ul> <li>Floorboard</li> </ul>			
<ul> <li>Hip Restraint</li> </ul>			
BRAKE LINKAGE	***************************************	***************************************	E-1
CARBURETOR	***************************************	F-1	
CLUTCHES		G-1	
Drive Belt			
Drive Clutch			
Driven Clutch			
DIRECTION SELECTOR			
DIRECTION SELECTOR			
ELECTRICAL SYSTEM			
ENGINE AND MUFFLER		M-1	
• Engine			
• Muffler			
Oil Filter			
• Spark Plugs			
ENGINE AND STARTER MOUNTIN	VG	N-1	
Belt, Starter/Generator			
Adjuster, Starter/Generato	or		
• Engine Guard			
• Isolator			

#### Illustrated Parts Breakdown:

	ELECTRIC	GASOLINE	ELECTRIC/GASOLINE
	VEHICLE	VEHICLE	VEHICLE
Illustration	Page No.	Page No.	Page No.
FILTERED AIR SYSTEM	***************************************	0-1	-
Air Cleaner			
FRONT SUSPENSION		********************	Q-1
<ul> <li>Front Axle Assembly</li> </ul>			
<ul> <li>Leaf Springs and idler Assembly</li> </ul>			
<ul> <li>Hub and Spindle Assemblies</li> </ul>			
<ul> <li>Tie Rod Assembly</li> </ul>			
FUEL SYSTEM		R-1	
• Fuel Gauge			
<ul> <li>Fuel Pump</li> </ul>			
<ul> <li>Fuel Tank Assembly</li> </ul>			
HORN AND LIGHTING			S-1
Headlamp			
• Horn			
<ul> <li>Rear Lamp Assembly</li> </ul>			
<ul> <li>State of Charge Meter</li> </ul>			
<ul> <li>Turn Signal Assembly</li> </ul>			
Wire Harness			
MOTOR	T-1		
REAR AXLE	U-1	V-1	
REAR SUSPENSION	W-1	X-1	
SEATING AND BAGRACK			Y-1
SOLID STATE SPEED CONTROL	Z-1		
<ul> <li>Control Rod</li> </ul>			
<ul> <li>Mounting Assembly</li> </ul>			
• Solenoid			
<ul> <li>Speed Control Cover</li> </ul>			
SOLID STATE SPEED CONTROL			
(DCS MODEL ONLY)	Z-5		
Control Rod			
<ul> <li>Mounting Assembly</li> </ul>			
• Solenoid			
<ul> <li>Speed Control Cover</li> </ul>			
STARTER/GENERATOR		AA-1	
<ul> <li>Brush Holder Assembly</li> </ul>			
• Pulley			
<ul> <li>Terminal Assembly</li> </ul>			

# Illustrated Parts Breakdown: **ELECTRIC** GASOLINE **ELECTRIC/GASOLINE** VEHICLE VEHICLE VEHICLE Illustration Page No. Page No. Page No. STEERING.....BB-1 Rack and Rod Assembly Steering Wheel Tie Rod Assembly Brake Assembly Brake Drum Assembly Brake Shoe Set WHEELS AND TIRES.......DD-1 Tread Styles Tire and Wheel Assembly Valve Stem Wheel Rim SPECIAL TOOLS ......Page No. Special Tools Listing......Appendix - A ACCESSORIES ......Page No. Accessory Listing ...... Appendix - B ACCESSORIES ......Page No. Accessory Installations ...... Appendix - C Divot Repair Kit (Sand Bottle) Side Basket Center Basket Sun Top Wheel Covers Windshield

Mud Flaps

As	htrav
~0	1111678

Wheel Covers

Rear View Mirror

Four Bag Attachment (Medalist only)

Hour Meter

- 4-Caddy Conversion
- 4-Caddy Conversion Windshield
- 4-Caddy Conversion Sun Top
- 4-Caddy Convertible Carrier Kit

WIRING DIAGRAMS AND SCHEMATICS	Page No.
Electric and Gasoline Vehicles	Appendix - D

#### HOW TO USE THE E-Z-GO SERVICE PARTS MANUAL

This manual is divided into several sections:

- GENERAL INFORMATION
- ILLUSTRATED PARTS BREAKDOWN FOR MEDALIST ELECTRIC AND GASOLINE POWERED GOLF CARS
- APPENDIX A

The first section, GENERAL INFORMATION, contains the following information:

- WARRANTY INFORMATION
- GENERAL INDEX
- HOW TO USE THE E-Z-GO SERVICE PARTS MANUAL

The second section, ILLUSTRATED PARTS BREAKDOWN (IPB) FOR THE MEDALIST ELECTRIC POWERED AND GASOLINE GOLF CARS, contains illustrations and parts lists for all systems of your vehicle.

The third section, SERVICE ACCESSORIES AND SPECIAL TOOLS, contains a listing of E-Z-GO service accessories and special tools and that may be purchased from the company to aid in the servicing of the vehicle.

#### **USE OF THE MANUAL**

To use this manual, consult the GENERAL INDEX to locate the information or illustration required.


E-Z-GO manuals are revised annually to coincide with the model year change. The manual will cover all models and model years stated on the cover page. Sections that remain unchanged have the last date they were revised in the lower inside margin. New components that are interchangeable with the previous year are automatically revised and the issue date is changed.

Introduction of some revisions varies due to supply of components; therefore, it is possible that various combinations of components may be found that are not directly reflected by each illustration. Consult the illustration that best suits your situation and then contact the Service Parts Department. It is important that the serial number of your vehicle and its model number be supplied to Service Parts when ordering any replacement components.

Locate the serial number plate (see Body and Associated Parts located in the IPB section of this manual for its location) and note the complete number shown on the plate.

All relevant systems are listed in the General Index and has an alphabetical prefix. The illustration always appears first and is followed by its related parts list. Additional illustrations and parts lists with the same prefix indicate significant changes that have taken place since the last issue.

#### HOW TO USE THE E-Z-GO SERVICE PARTS MANUAL



#### 1. WHEN THE PART NUMBER IS NOT KNOWN

- Determine the function and application of the part required. Turn to the General Index and select the most appropriate title.
- Turn to the page number indicated and locate the desired part on the illustration.
- From the illustration, obtain the item number assigned to the desired part. Refer to the accompanying description for specific information regarding the part.

#### 2. IF YOU KNOW THE PART NUMBER

Locate the part number or description in the appropriate column on the parts list page.


NOTE: It is suggested that you confirm that the part selected is correct by verifying it with the pictorial representation on the illustrated page.

Should an asterisk (\*) appear in the part number column on the parts list page, read upwards until a part number is found. The part number is the lowest assembly sold by E-Z-GO and the asterisk (\*) indicates that the part depicted is not available for sale by E-Z-GO.


NOTE: Descriptions are indented under the assembly that they are used on. That assembly is, in turn listed under the assembly that it is used on. This process is repeated until the highest final assembly is reached.

To facilitate the maintenance and repair of the vehicle, a Technician's Repair and Service Manual [28124-G01 (Electric vehicle) and 28125-G01 (Gasoline vehicle)] is available from the E-Z-GO Service Parts Department.

# **ILLUSTRATED PARTS BREAKDOWN**



# **ACCELERATOR LINKAGE**



#### THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	25870-G03	PEDAL BOX ASSEMBLY (INCLUDES ITEMS 3 - 32, 34, 36 - 40)	1
2	25870-G05	PEDAL BOX ASSEMBLY, DCS MODEL ONLY	
	2255 22	(INCLUDES ITEMS 3 - 29, 32 - 40)	
3	00550-G2	NUT, LOCK, 1/4 - 28	
4	00532-G4	NUT, LOCK, 5/16 - 24	
5	00684-G6	SCREW, #8 - 32 X 3/4 LG	
6	00982-G01	SCREW, #4 - 14 X 5/8 LG	2
7			
8	00983-G01	NUT, SELF THREADING	
9	00984-G01	SCREW, #8 - 10 X 1/2 LG	
10	00486-G2	SETSCREW, #8 - 32 X 1/8 LG	
11	00986-G01	PUSHNUT, 19/64 I.D	1
12	10385-G4	YOKE, CLEVIS (ADJUSTABLE)	1
13	10386-G3	PIN, CLEVIS, 5/16 x 15/16 LG	1
14			
15	10387-G3	PIN, COTTER, 3/32 x 3/4 LG	1
16	17677-G1	RETAINER, SPRING	1
17	17677-G2	RETAINER, SPRING	1
18			
19	17979-G1	BUSHING, ACCELERATOR ROD	1
20	25799-G01	ACCELERATOR PEDAL ASSEMBLY (INCLUDES ITEMS 22 - 24)	1
21			
22	16409-G1	RIVET, OVAL, 3/8 X 15/32 LG	6
23	27512-G01	PAD, ACCELERATOR PEDAL	1
24	*	PEDAL, ACCELERATOR	1
25			
26	25853-G01	PEDALBOX AND COVER (SEAL AND BEARING)	1
27		,	
28	25854-G01	INDUCTIVE THROTTLE SENSOR	1
29	25859-G01	ACCELERATOR ROD	1
			-


# **Electric Vehicle**


# **ACCELERATOR LINKAGE**


THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

25861-G01 25879-G03 26551-G01 25861-G02 26969-G01 25879-G04 70116-G01 70134-G01 17255-G1 73046-G01 17838-G1	SWITCH, MICRO WIRING HARNESS, PEDAL BOX ASSEMBLY PLUNGER SWITCH, MICRO (DCS MODEL ONLY) CAM, PLUNGER WIRING HARNESS, PEDAL BOX ASSEMBLY (DCS MODEL ONLY) BRACKET, PEDAL PIN, PEDAL PIVOT WASHER, TEFLON, 1/32 X 5/8 SPRING, COMPRESSION BUSHING	1 1 1 1 1 1
26551-G01 25861-G02 26969-G01 25879-G04 70116-G01 70134-G01 17255-G1 73046-G01	PLUNGER SWITCH, MICRO (DCS MODEL ONLY) CAM, PLUNGER WIRING HARNESS, PEDAL BOX ASSEMBLY (DCS MODEL ONLY) BRACKET, PEDAL PIN, PEDAL PIVOT WASHER, TEFLON, 1/32 X 5/8. SPRING, COMPRESSION	. 1 . 1 . 1 . 1 . 1
25861-G02 26969-G01 25879-G04 70116-G01 70134-G01 17255-G1 73046-G01	SWITCH, MICRO (DCS MODEL ONLY)  CAM, PLUNGER  WIRING HARNESS, PEDAL BOX ASSEMBLY (DCS MODEL ONLY)  BRACKET, PEDAL  PIN, PEDAL PIVOT  WASHER, TEFLON, 1/32 X 5/8  SPRING, COMPRESSION	. 1 . 1 . 1 . 1
26969-G01 25879-G04 70116-G01 70134-G01 17255-G1 73046-G01	CAM, PLUNGER	. 1 . 1 . 1 . 1
25879-G04 70116-G01 70134-G01 17255-G1 73046-G01	WIRING HARNESS, PEDAL BOX ASSEMBLY (DCS MODEL ONLY) BRACKET, PEDAL PIN, PEDAL PIVOT WASHER, TEFLON, 1/32 X 5/8 SPRING, COMPRESSION	. 1
70116-G01 70134-G01 17255-G1 73046-G01	BRACKET, PEDAL  PIN, PEDAL PIVOT  WASHER, TEFLON, 1/32 X 5/8  SPRING, COMPRESSION	. 1 . 1 . 1
70134-G01 17255-G1 73046-G01	PIN, PEDAL PIVOT WASHER, TEFLON, 1/32 X 5/8 SPRING, COMPRESSION	. 1
17255-G1 73046-G01	WASHER, TEFLON, 1/32 X 5/8SPRING, COMPRESSION	. 1
73046-G01	SPRING, COMPRESSION	. 1
17838-G1	BUSHING	. з
00715-G2	BOLT, 5/16 - 18 X 5/8 LG.	. 4
70135-G01	COVER, PEDAL PIVOT	. 1
		<u> </u>







# **Gasoline Vehicle**

# **ACCELERATOR LINKAGE**

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	72062-G01	ACCELERATOR PEDAL BOX ASSEMBLY (INCLUDES ITEMS 2 - 46)	1
2	70116-G01	BRACKET, ACCELERATOR PEDAL	. 1
3	25853-G02	PEDAL BOX AND COVER	. 1
4	00487-G3	SETSCREW, 1/4 - 20 X 3/8 LG	. 1
5			
6	00984-G01	SCREW, #8 - 32 X 1/2 LG	. 4
7	10387-G3	PIN, COTTER, 3/32 x 3/4 LG	. 1
8	25799-G01	ACCELERATOR PEDAL ASSEMBLY (INCLUDES ITEMS 9 - 11)	. 1
9	16409-G1	RIVET, OVAL, 3/8 X 15/32 LG	. 6
10	27512-G01	PAD, ACCELERATOR PEDAL	. 1
11	70125-G01	PEDAL, ACCELERATOR	. 1
12			
13	00684-G6	SCREW, #8 - 10 X 1/2 LG	4
14	17838-G1	BUSHING	. 3
15	70134-G01	PIN, PEDAL PIVOT	. 1
16	00986-G01	PUSHNUT, 19/64	. 1
17			
18			
19	25861-G01	SWITCH, MICRO	. 1
20	00982-G01	SCREW, #4 - 14 X 5/8 LG	2
21	72201-G01	WIRING HARNESS, PEDAL BOX	1
22	72065-G01	CABLE, ACCELERATOR (WITH NUT)	1
23	72198-G01	CAM, MICRO SWITCH	1
24			
25	72199-G01	BRACKET, PIVOT	_ 1
26	72066-G01	CONTROLARM	1
27	25768-G01	PIVOT ROD	1
28	14390-G1	NUT, LOCK, 3/8 - 24	1
29			
30	73046-G01	SPRING, COMPRESSION	1

When ordering parts, please specify the model and serial number of the product. 
\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.


ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
31	17677-G1	RETAINER, SPRING	1
32	72072-G01	ROD, ACCELERATOR	1
33	17979-G1	BUSHING, ACCELERATOR ROD	1
34	00532-G4	NUT, 5/16 - 24	1
35	10386-G3	PIN, CLEVIS, 5/16 X 1 LG	1
36	23860-G1	BEARING	2
37	24621-G1	WASHER, NYLON, 5/16	2
38	17255-G1	WASHER, TEFLON, 5/16	1
39	12064-G1	PUSHNUT, 1/4	1
40	01009-G01	NUT, NYLON, 5/16 - 24	1
41	14390-G10	NUT, LOCK, #10 - 24	1
42	10385-G4	YOKE, CLEVIS	1
43	00550-G4	NUT, LOCK, 5/16 - 24	1
44	72074-G01	LINK, CONTROL ARM	1
45	72225-G01	BOLT, SHOULDER, SOCKET BUTTON HEAD	1
46	17677-G2	RETAINER, SPRING	1
47			
48	25690-G01	GOVERNOR BELLCRANK ASSEMBLY (INCLUDES ITEMS 49 - 54)	1
49	25765-G01	BELLCRANK, GOVERNOR	1
50	24479-G1	BALL, BALL JOINT	1
51	00734-G5	NUT, LOCK, 10 - 32	1
52			
53	22751-G2	BRACKET, GOVERNOR	1
54	14390-G4	NUT, LOCK, 1/4 - 20	1
55			
56	00491-G4	SETSCREW, 1/4 - 20 X 1/2 LG	1
57	25738-G01	SPRING, GOVERNOR TO ACCELERATOR BRACKET	1
58	25653-G01	BRACKET, ACCELERATOR CABLE	1
59	*	WASHER (PROVIDED ON DIFFERENTIAL)	2
60	*	NUT (PROVIDED ON DIFFERENTIAL)	2


# **Gasoline Vehicle**

# **ACCELERATOR LINKAGE**

When ordering parts, please specify the model and serial number of the product.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
61	25702-G01	GOVERNOR PIVOT BRACKET ASSEMBLY (INCLUDES ITEMS 62 - 64)	. 1
62	14390-G1	NUT, LOCK, 3/8 - 24	. 1
63	25655-G01	BRACKET, BELLCRANK	. 1
64	25763-G01	PIVOT, GOVERNOR	. 1
65			
66	00565-G8	WASHER, LOCK, 5/16	. 2
67	00276-G6	BOLT, 5/16 - 24 X 3/4 LG.	. 2
68	00526-G4	NUT, #10 - 32	. 2
69	25737-G03	LINKAGE ROD, GOVERNOR	1
70	25737-G01	LINKAGE ROD, CARBURETOR (COMPLETE)	. 1
71	25737-G02	LINKAGE ROD, THROTTLE (COMPLETE)	. 1
72	14390-G1	NUT, LOCK, 3/8 - 24	. 1
73	24465-G1	SOCKET, BALLJOINT	AR
74	25760-G01	BELLCRANK CARBURETOR LINKAGE	. 1
75	00414-G8	BOLT, 1/4 - 20 X 1 LG.	. 2
76	72197-G01	PIVOT BRACKET	. 1
77	14390-G4	NUT, LOCK, 1/4 - 20	. 2
78	00715-G2	BOLT, 5/16 - 18 X 3/4 LG	. 4
79	25693-G04	CHOKE CONTROL ASSEMBLY, COMPLETE (WITH NUTS)	. 1
80	00568-G4	WASHER, LOCK, 9/16	. 1
81	00545-G4	NUT, 9/16 - 18	. 1
82	00544-G4	NUT, 5/16 - 24	. 2
83	26728-G01	BRACKET, CHOKE	. 1
84	12064-G3	PUSHNUT, 3/16	. 1
85			
86	72154 <b>-</b> G01	ADAPTER, CHOKE CABLE	. 1
87	72155-G01	RETAINER, ADAPTER	. 1
88	70135-G01	COVER, PEDAL PIVOT	. 1





THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	26984-G01	BATTERY CHARGER ASSEMBLY, TOTAL CHARGE® III, PORTABLE 36V, 10 FT. DC CORD (INCLUDES ITEMS 3 - 95)	1
2			
3	19096-G1	TOP COVER	1
4	24919-G1	CHASSIS	1
5			
6	*	LABEL, OPERATING INSTRUCTIONS (SERIALIZED)	1
7			
8	17077-G1	CAPACITOR (WITH MOUNTING BRACKET)	1
9			
10	00372-G4	SCREW, #8 - 32 X 1/2 LG	2
11	005 <del>6</del> 5-G4	WASHER, LOCK, #8	2
12	00526-G1	NUT, #8 - 32	2
13			
14	18768-G1	HEATSINK	1
15	18488-G1	DIODE, SILICON RECTIFIER	2
16	00567-G7	WASHER, LOCK, 1/4	2
17	00532-G2	NUT, 1/4 - 28	2
18	11572-G2	NUT, PLASTIC EXPANSION	3
19	00525-G5	NUT, #6 - 32	2
20	00138-G3	SCREW, #6 - 32 X 3/8 LG.	2
21			
22			
23	00567-G3	WASHER, LOCK, #6	2
24	00525-G5	NUT, #6 - 32	2
25			
26	00512-G7	SCREW, SELF DRILL AND TAP, #8 X 7/8 LG	3
27	00378-G4	SCREW, #10 - 24 X 1/ 2 LG	1
28	00526-G3	NUT, #10 - 24	1
29	00565-G5	WASHER, LOCK, #10	1

## **Electric Vehicle**

# BATTERY CHARGER, TOTAL CHARGE® III

#### THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
30	00565-G3	WASHER, #6 - 32	. 2
31	26320-G01	VARISTOR, MOV	. 2
32	26962-G01	TERMINAL BLOCK	1
33	00987-G06	SCREW, #6 - 32 X 3/4 LG	. 2
34	24243-G1	AMMETER (INCLUDES ITEM 35)	. 1 ;
35	*	BRACKET, AMMETER	. 1
36	00525-G5	NUT, #6 - 32	. 2
37	00565-G5	WASHER, LOCK, #10	. 2
38	00526-G4	NUT, #10 - 32	. 2
39			
40	19952-G1	WIRE	. 1
41			
42	00372-G3	SCREW, #8 - 32 X 3/8 LG.	. 1
43	00565-G4	WASHER, LOCK, #8	. 1
44	00526-G1	NUT, #8 - 32	. 1
45			
46	19372-G8	TRANSFORMER	. 1
47	11027-G2	NUT, LOCK, 1/4 - 20	. 4
48	00414-G5	BOLT, 1/4 - 20 X 5/8 LG	. 4
49	19388-G1	AC CORD	. 1
50	13557-G2	STRAIN RELIEF, PLASTIC (AC CORD)	. 1
51			
52			
53	18747-G1	DC CORD ASSEMBLY (INCLUDES ITEMS 54 - 56)	. 1
54	*	DC CORD	. 1
55	28030-G01	CONNECTOR, CONTACT KIT	. 2
56	27815-G01	CONNECTOR	. 1
57	18972-G1	CHARGER RECEPTACLE HANDLE KIT (INCLUDES ITEMS 58, 59)	. 1
58	*	HANDLE, HALF, L.H	. 1
59	*	HANDLE, HALF, R.H	. 1

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
60			
61	00647-G8	SCREW, STAINLESS STEEL, #6 - 32 X 29/32 LG	2
62	00647-G3	SCREW, STAINLESS STEEL, #6 - 32 X 3/8 LG.	2
63	13521-G5	NUT, LOCK, #6 - 32	4
64	00650-G2	WASHER, #5	2
65	20628-G1	LABEL, CAUTION	1
66	13557-G3	STRAIN RELIEF, PLASTIC (DC CORD)	1
67			
68			
69	00614-G4	SCREW, SELF DRILL AND TAP, #8 - 18 X 1/2 LG	10
70	19950-G1	ELECTRONIC MODULE ASSEMBLY (INCLUDES ITEMS 71 - 79)	1
71	27417-G01	MODULE	1
72	19459-G1	BRACKET	1
73			
74	27877-G01	SPACER, SUPPORT	4
75			
76	;		
77	32519-G01	WIRE	1
78	19949-G1	WIRE	1
79	19954-G1	WIRE	1
80			
81			
82	19360-G1	SPLICE, WIRE, CLOSED END	2
83	19363-G1	FUSE BLOCK	1
84	19361-G1	FUSE, 15 AMP	1
85	19434-G1	LABEL, IDENTIFICATION	1
86	19441-G1	WIRE	1
87	19362-G1	CIRCUIT BREAKER, 50 AMP (INCLUDES ITEMS 88, 89)	2
88	00559-G5	WASHER, #10	4
89	00526-G4	NUT, #10 - 32	2

# **Electric Vehicle**

# **BATTERY CHARGER, TOTAL CHARGE® III**


THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.


When ordering parts, please specify the model and serial number of the product.


\* Indicates a component that is not available as an individual part.


G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
90	00565-G4	WASHER, LOCK, #8	2
91	00526-G1	NUT, #8 - 32	
92	00372-G6	SCREW, #8 - 32 X 3/4 LG.	2
93	00372-G5	SCREW, #8 - 32 X 5/8 LG	2
94	00565-G4	WASHER, #8	2
95	00526-G1	NUT, #8 - 32	2









THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.


ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	28115-G01	CHARGER ASSEMBLY (COMPLETE) INCLUDES ITEMS 2 - 58	1
2	00372-G3	SCREW, #8 - 32 X 3/8 LG	1
3	00372-G4	SCREW, #8 - 32 X 1/2 LG	4
4			
5	00378-G4	SCREW, #10 - 24 X 1/2 LG	2
6	00414-G5	SCREW, 1/4 - 20 X 5/8 LG.	3
7	00513-G6	SCREW, #8 - 18 X 1 3/4 LG	2
8	00526-G1	NUT, #8 - 32	5
9			
10	00526-G3	NUT, #10 - 24	2
11	*	NUT, #10 - 32	3
12			
13	00559-G3	WASHER, #6	3
14	00559-G4	WASHER, #8	12
15			
16			
17	00565-G4	WASHER, LOCK, #8	5
18	00565-G5	WASHER, LOCK, #10	4
19			
20	00614-G4	SCREW, #8 - 18 X 1/2 LG	6
21	00771 <b>-</b> G6	WASHER, NYLON, SPECIAL	1
22	00969-G01	SCREW, #8 - 32 X 3/8 LG	3
23	00984-G01	SCREW, #8 - 10 X 1/2 LG	2
24			
25	*	WASHER, BRASS, #10	4
26	01005-G01	SCREW, #6 - 19 X 5/16 LG	3
27	11027-G2	NUT, LOCK, 1/4 - 20	3
28	11572-G3	NUT, PLASTIC EXPANSION	2
29	13557-G2	STRAIN RELIEF, AC	1
30	13557-G3	STRAIN RELIEF, DC	1


## **Electric Vehicle**


# BATTERY CHARGER, POWERWISE TM


THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.
When ordering parts, please specify the model and serial number of the product.
\* Indicates a component that is not available as an individual part.
G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
31			
32	19388-G4	CORD, AC	. 1
33	22589-G2	WASHER, SHOULDER	1
34			
35	25977-G32	WIRE, 4"	. 1
36	26979-G01	BRACKET, CAPACITOR	. 1
37	27877-G01	SUPPORT, SPACER	. 4
38	28091-G01	LABEL, FRONT	. 1
39			
40	*	COVER	. 1
41	*	CHASSIS	. 1
42	28102-G01	HANDLE	. 1
43	28103-G01	TRANSFORMER	. 1
44	28104-G01	HEAT SINK	. 1
45	28105-G01	AMMETER	. 1
46	28106-G01	FUSE, 50 AMP	. 1
47	28109-G01	CAPACITOR	. 1
48			
49	28110-G01	CLIP, ELECTRICAL	. 1
50	28111-G01	SUPPORT, CONTROL BOARD	. 3
51	28112-G01	DIODE	. 1
52			
53	28126-G01	BOARD, CONTROL	. 1
54	28126-G03	BOARD, POWER INPUT	. 1
55	28136-G01	TOP LABEL, VENTILATION	. 1
56	28136-G02	TOP LABEL, CORD CONDITION	. 1
57	17618-G1	CLAMP, NYLON	2
58	28137-G**	DC PLUG (COMPLETE)	1









#### THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.


ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	28115-G02	CHARGER ASSEMBLY (COMPLETE) INCLUDES ITEMS 2 - 58	1
2	00372-G3	SCREW, #8 - 32 X 3/8 LG.	1
3	00372-G4	SCREW, #8 - 32 X 1/2 LG	4
4			
5	00378-G4	SCREW, #10 - 24 X 1/2 LG	2
6	00414-G5	SCREW, 1/4 - 20 X 5/8 LG.	3
7	00513-G6	SCREW, #8 - 18 X 1 3/4 LG	2
8	00526-G1	NUT, #8 - 32	5
9			
10	00526-G3	NUT, #10 - 24	2
11	00528-G4	NUT, #10 - 32	3
12			
13	00559-G3	WASHER, #6	3
14	00559-G4	WASHER, #8	12
15			
16		·	
17	00565-G4	WASHER, LOCK, #8	5
18	00565-G5	WASHER, LOCK, #10	4
19			
20	00614-G4	SCREW, #8 - 18 X 1/2 LG	6
21	00771-G6	WASHER, NYLON, SPECIAL	1
22	00969-G01	SCREW, #8 - 32 X 3/8 LG	3
23	00984-G01	SCREW, #8 - 10 X 1/2 LG	2
24			
25	01003-G01	WASHER, BRASS, #10	4
26	01005-G01	SCREW, #6 - 19 X 5/16 LG	3
27	11027-G2	NUT, LOCK, 1/4 - 20	3
28	11572-G3	NUT, PLASTIC EXPANSION	2
29	13557-G2	STRAIN RELIEF, AC	1
30	13557-G3	STRAIN RELIEF, DC	1


## **Electric Vehicle**


# BATTERY CHARGER, POWERWISE TM +


THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.


ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
31	·	· · · · · · · · · · · · · · · · · · ·	
32	19388-G4	CORD, AC	. 1
33	22589-G2	WASHER, SHOULDER	. 1
34			
35	25977-G32	WIRE, 4"	. 1
36	26979-G01	BRACKET, CAPACITOR	. 1
37	27877-G01	SUPPORT, SPACER	. 4
38	28091-G02	LABEL, FRONT	. 1
39			
40	*	COVER	. 1
41	*	CHASSIS	. 1
42	28102-G01	HANDLE	. 1
43	28103-G01	TRANSFORMER	. 1
44	28104-G01	HEAT SINK	. 1
45	28105-G01	AMMETER	. 1
46	28106-G01	FUSE, 50 AMP	. 1
47	28109-G01	CAPACITOR	. 1
48			
49	28110-G01	CLIP, ELECTRICAL	. 1
50	28111-G01	SUPPORT, CONTROL BOARD	. з
51	28112-G01	DIODE	. 1
52			
53	28126-G02	BOARD, CONTROL	. 1
54	28126-G04	BOARD, POWER INPUT	. 1
55	28136-G01	TOP LABEL, VENTILATION	. 1
56	28136-G02	TOP LABEL, CORD CONDITION	. 1
57	17618-G1	CLAMP, NYLON	2
58	28137-G**	DC PLUG (COMPLETE)	. 1
			:











Page D-5 Service Parts Manual

### **BODY AND ASSOCIATED PARTS**

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	71151-G01	INSTRUMENT PANEL ASSEMBLY (INCLUDES ITEMS 2 - 5)	. 1
2	71153-G01	BALL DEFLECTOR, PASSENGER SIDE	1
3	71154-G01	BALL DEFLECTOR, DRIVER'S SIDE	1
4	·		
5	00614-G5	SCREW, #8 - 18 X 5/8 LG	. 6
6			
7	71071-G02	COWL	. 1
8	71030-G01	COWL CAP	1
9	71101-G01	BRACKET, COWL SUPPORT	. 1
10	19817-G1	NAMEPLATE, E-Z-GO	. 1
11			
12	·		
13	12064-G3	PUSHNUT, 3/16	. 3
14	71071-G01	COWL, FRONT	. 1
15	71076-G01	TAB, RETAINING	2
16			
17	71036-G01	FENDER FLANGE, DRIVER'S SIDE	. 1
18	71035-G01	FENDER FLANGE, PASSENGER SIDE	. 1
19	10570-G10	RIVET, STAINLESS STEEL, 5/32 X 1/2 LG	. 2
20	14601-G10	RIVET, 5/32 X 7/16 LG	16
21	10570-G10	RIVET, 5/32 X 9/16 LG	2
22	16469-G7	WASHER, 1/4	. 1
23	71102-G02	BOLT, 1/4 - 20 X 1/2 LG	. 4
24	15121-G3	WASHER, 1 1 / 4 O.D. X 7 / 32 I.D.	. 2
25			
26	71117-G01	PANEL, SPLASH, FRONT COWL	. 1
27	71056-G01	BOLT, 5/16 - 18 X 5/8 LG	. 4
28			
29	16816-G2	RATCHET FASTENER	. 4
30	71115-G01	TRIM, VINYL	. 2

# **BODY AND ASSOCIATED PARTS**

## **Electric / Gasoline Vehicle**

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
31	27826-G01	LABEL, SAFETY (GASOLINE VEHICLE)	. 1
32	27647-G01	LABEL, SAFETY (ELECTRIC VEHICLE)	. 1
33	14601-G13	RIVET, 5/32 X 9/16 LG	. 2
34	14601-G11	RIVET, 3/16 X 9/16 LG	. 10
35			
36	70047-G01	UPPER FLOORPAN	. 1
37	70132-G01	LOWER FLOORPAN	. 1
38	70164-G01	COVER, SWITCH ACCESS	1
39			
40	14601-G11	RIVET, 3/16 X 9/16 LG	. 7
41	18391-G1	NOISE SUPPRESSOR STRIP	. 2
42	72113-G01	NOISE SUPPRESSOR, TRUNK LID	. 1
43	22744-G1	NOISE SUPPRESSOR, BAGWELL	1
44	72112-G01	NOISE SUPPRESSOR, SEAT WRAP (GASOLINE VEHICLE)	. 1
45			
46			
47	71401-G02	BAGWELL	. 1
48	20271-G2	PLUG HOLE, BUMPER	. 2
49	73053-G01	CLAMP (DCS MODEL ONLY)	. з
50	10570-G10	RIVET, STAINELESS STEEL, 5/32 X 9/16 LG	. 8
51	00559-G4	WASHER, #8 (DCS MODEL ONLY)	. 3
52	18436-G1	RIVET, 1/4 X 5/8 LG	. 4
53		:	
54	71551-G04	FENDER LINER, PASSENGER SIDE	. 1
55	71552-G04	FENDER LINER, DRIVER'S SIDE	. 1
56	16816-G2	RATCHET FASTENER	. 12
57	71055-G01	RIVET, 3/16 X 3/8 LG	. 4
58	71552-G02	FENDER LINER, DRIVER'S SIDE (FREEDOM)	. 1
59	71551-G02	FENDER LINER, PASSENGER SIDE (FREEDOM)	. 1
60	10570-G11	RIVET, STAINLESS STEEL, 3/16 X 11/16 LG.	. 4

### **BODY AND ASSOCIATED PARTS**

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
61	71616-G01	PLATE, SEAT HINGE (VEHICLES PRIOR TO SERIAL NO. 895713)	. 2
62	71609-G01	PLATE, SEAT HINGE (VEHICLES AFTER SERIAL NO. 895713)	. 2
63	71353-G01	ACCESS PANEL	. 1
64	71002-G01	SCREW, #8 X 1/2 LG	. 6
65	71347-G01	FILLER PANEL, PASSENGER SIDE	1
66	71348-G01	FILLER PANEL, DRIVER SIDE	1
67			
68	10570-G12	RIVET, 1/4 X 1/2 LG	. 4
69	71003-G01	SPEED NUT, #8	. 4
70	14601-G13	RIVET, 5/32 X 9/16 LG	2
71	16816-G2	RATCHET FASTENER	. 2
72	14601-G10	RIVET, 5/32 X 7/16 LG	. 8
73	71377-G01	SEATWRAP SCUFFGUARD	. 1
74			
75	75017-G01	ACCESS PANEL, SCUFFGUARD	. 1
76			
77			
78	71341-G**	FENDER, PASSENGER SIDE	ļ <sub>1</sub>
79	71345-G01	FENDER POCKET, PASSENGER SIDE	1
80	71355-G01	FENDER CAP, PASSENGER SIDE	. 1
81			
82	71373-G02	SCUFF GUARD, PASSENGER SIDE	. 1
83	71342-G**	FENDER, DRIVER'S SIDE	. 1
84	71346-G01	FENDER POCKET, DRIVER'S SIDE	1
85	74354-G02	FENDER CAP, PASSENGER SIDE (FREEDOM)	. 1
86	71356-G01	FENDER CAP, DRIVER'S SIDE	. 1
87	71373-G01	SCUFF GUARD, DRIVER'S SIDE	ļ <sub>1</sub>
88	74354-G01	FENDER CAP, DRIVER'S SIDE (FREEDOM)	. 1
89	00228-G4	SCREW, #10 - 24 x 1/2 LG.	. з
90			

#### THE USE OF NON UL PARTS WILL VOID ANY ULLISTING.

When ordering parts, please specify the model and serial number of the product.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
91	14601-G10	RIVET, 5/32 X 7/16 LG	. 5
92	16816-G2	RATCHET FASTENER	4
93			
94	71003-G03	SPEED NUT, #8	. 4
95	71004-G01	SCREW, #8 X 3/8 LG	4
96	11027-G3	NUT, LOCK, 10 - 24	3
97			
98	70245-G01	BATTERY TRAY (GASOLINE VEHICLE)	. 1
99	00715-G2	BOLT, 5/16 - 18 X 13/16 LG.	4
100			
101	23676-G1	DECAL, FREEDOM	AR
102	27504-G01	DECAL, FREEDOM HP	AR
103	75178-G01	DECAL, 4 CADDY	AR
104	73162-G01	DECAL, DCS	. AR
105			
106	70048-G02	FLOORMAT (FREEDOM ONLY)	1
107	70048-G01	FLOORMAT	. 1
108	23850-G1	SILL PLATE, ROCKER PANEL, PASSENGER SIDE	1
109	23850-G2	SILL PLATE, ROCKER PANEL, DRIVER'S SIDE	1
110			
111	16705-G1	SCREW, STAINLESS STEEL, 1/4 - 20 X 1 LG	. 4
112	23726-G4	SPACER	. 4
113	00891-G2	NUT, LOCK, 1/4 - 20	. 4
114	71501-G01	ROCKER PANEL, PASSENGER SIDE	. 1
115	71502-G01	ROCKER PANEL, DRIVER'S SIDE	. 1
116			
117			
118	71379-G**	SEATWRAP (DCS MODEL ONLY)	. 1
1 <b>1</b> 9	71361-G**	SEATWRAP	. 1
120	70317-G01	SEAT FRAME (GASOLINE VEHICLE)	1

## **BODY AND ASSOCIATED PARTS**

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
121	70200-G01	SCREW, 3/8 - 16 X 1/4 LG	. 2
122			
123	70318-G01	SEAT FRAME (ELECTRIC VEHICLE)	, 1
124	70046-G01	BATTERY RACK (ELECTRIC VEHICLE)	1
125			
126			
127	00715-G2	BOLT, 5/16 - 18 X 13/16 LG	. 5
128	00438-G6	SCREW, 5/16 - 18 X 3/4 LG	. 2
129	11098-G6	NUT, LOCK, 5/16 - 18	. 2
130	00559-G8	WASHER, 5/16	. 2
131			
132			
133			
134			
135			
136	11027-G01	NUT, ŁOCK, 5/16 - 18	. 2
137			
138			
139	70244-G02	PANEL, SPLASH (ELECTRIC VEHICLE)	. 2
140	70244-G01	PANEL, SPLASH (GASOLINE VEHICLE)	. 1
141	71158-G01	INSERT, 4 CUP INSTRUMENT PANEL	1
142			
143			
144			
145			
146			
147			
148			
149			
150			

### **BODY AND ASSOCIATED PARTS**


## **Electric / Gasoline Vehicle**


#### THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.


When ordering parts, please specify the model and serial number of the product.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
151	74126-G01	FRAME SUPPORT, VERTICAL, PASSENGER SIDE	. 1
152	74126- <b>G</b> 02	FRAME SUPPORT, VERTICAL, DRIVER'S SIDE	. 1
153	00426-G8	BOLT, 3/8 - 16 X 1 LG.	. 2
154	00560-G1	WASHER, 3/8	. 8
155	11098-G5	NUT, LOCK, 3/8 - 16	. 4
156	00427-G4	BOLT, 3/8 - 16 X 1 1/2 LG	. 2
157	74127-G01	PANEL, VALANCE	. 1
158	74128-G01	REFLECTOR	. 2
159	16816-G2	RIVET, PLASTIC	. 6
160	19853-G1	PLUG, END	. 2
161	74105-G01	FOOT REST ASSEMBLY (INCLUDES ITEMS 162 - 164)	. 1
162	74129-G01	REFLECTOR	. 1
163	74132-G01	LABEL, WARNING	. 1
164	74107-G01	MAT, FLOOR	. 1
165			
166	00769-G2	BOLT, CARRIAGE, 3/8 - 16 X 1 1/4 LG	. 2
167	00560-G1	WASHER, 3/8	. 2
168	11098-G5	NUT, LOCK, 3/8 - 16	. 2
169			
170	00114-G6	SCREW, 1/4 - 14 X 3/4 LG	4
171	16816-G2	FASTENER	. 2
172			
173	27166-G02	FRONT SHIELD	. 1
174	71015-G01	BRACE, FRONT SHIELD	. 2
175	16469-G7	WASHER, 1/4	. 2
	ļ		
	i		

**BODY AND ASSOCIATED PARTS** 







### **BRAKE LINKAGE**

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

2 3 4 5 6	70263-G01  *  *  70274-G01  *  *  15766-G1  *	VEHICL PEC PEC BRA	.ES WI DAL, B DAL, P. AKE/PA PAD, I PAD, I RIVET	ITH BF RAKE ARK B ARK B BRAKE PARK	EMBLY (INCLUDES ITEMS 2 - 27) RAKE LIGHTS  RAKE  RAKE  RAKE PEDAL PAD KIT (INCLUDES ITEMS 5 - 7)  E PEDAL  BRAKE  15/32 LG.	. 1 . 1 . 1 . 1
3 4 5 6 7 8	* 15766-G1 *	PEC BRA	DAL, P. AKE/P. PAD, I PAD, I RIVET	ARK B ARK B BRAKE PARK	RAKE	. 1
4 5 6 7 8	* 15766-G1 *	BR/	AKE/PA PAD, I PAD, I RIVET	ARK B Brake Park	RAKE PEDAL PAD KIT (INCLUDES ITEMS 5 - 7) E PEDAL	. 1
5 6 7 8	* 15766-G1 *		PAD, I PAD, I RIVET	BRAKI PARK	BRAKE	. 1
6 7 8	*		PAD, I RIVET	PARK	BRAKE	. 1
7	*		RIVET			
8	*			ī, 3/8 x	15/32 LG	. 9
·	* 15932-G2	PLA				
9	* 15932-G2	PLA				
· ·	15932-G2		TE, BI	RAKE	PEDAL	. 1
10	Į.	PIN	, PARK	( BRAI	KE PEDAL	. 1
11	11737-G1	SPF	RING, 1	TORSI	ON, PARK BRAKE	. 2
12	12064-G1	PUS	TUNHE	Γ <b>,</b> 5/16.		. 1
13 (	00737-G8	SCF	REW, #	‡10 - 2·	4 X 1 LG	4
14 (	00739-G1	NUT	r, RUB	BER, i	¥10 - 24	. 2
15 2	22362-G3	STA	NDOF	F, BR/	AKE PEDAL	. 2
16	27137-G01	SPF	RING, (	CONIC	AL	. 2
17	11098-G7	NUT	r, Loc	<b>K</b> , #10	- 24	. 2
18	10606-G8	SWI	ІТСН, І	MICRO	)	. 1
19 (	00645-G2	SCF	REW, #	ŧ6 - 32	X 1 1/4 LG	. 2
20 (	00559-G3	WAS	SHER,	#6		. 2
21 (	00565-G3	WAS	SHER,	LOCK	ī, #6	2
22 (	00525-G5	NUT	Г, #6 - 3	32		. 2
23	*	SCF	REW, E	BRASS		. 2
24 (	00567-G3	WAS	SHER,	LOCK	(, #6	6
25	14628-G1	TAB	, FAST	TON, 5	/16 X 5/16 LG	. 2
26						
27	17618-G1	NYL	ON C	LAMP.		. 3
28						
29						

## **BRAKE LINKAGE**

## **Electric / Gasoline Vehicle**

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

ПЕМ	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
30	70096-G01	BOLT, SHOULDER, 3/8 - 16 X 3 LG	1
31	11079-G1	BUSHING, FLANGED	2
32	70138-G01	SPRING, TORSION	1
33	11098-G5	NUT, 3/8 - 16	1
34	00643-G1	WASHER, 3/8	1
35	11027-G2	NUT, LOCK, 1/4 - 20	2
36	70080-G01	CATCH BRACKET, PARK BRAKE	1
37	00414-G6	BOLT, 1/4 - 20 X 3/4 LG.	2
38			
39			
40	70272-G04	COMPENSATOR ASSEMBLY (INCLUDES ITEMS 42 - 54)	1
41			
42	25882-G04	ROD, LINK	1
43	00532-G4	NUT, 5/16 - 24	2
44	11098-G9	NUT, LOCK, 5/16 - 24	1
45			
46	27330-G01	YOKE, BRAKE	1
47	15121-G1	WASHER, 3/8	2
48	23061-G2	TUBE	1
49	23463-G1	SPRING, COMPRESSION	1
50		·	
51	17979-G1	BUSHING, ACCELERATOR ROD	1
52			
53			ĺ
54	00963-G01	NUT, SPHERICAL, 5/16 - 24	1
55	70273-G03	EQUALIZER AND BRAKE CABLE ASSEMBLY (INCLUDES ITEMS 56 - 59)	1
56	28082-G01	BRACKET, EQUALIZER	1
57	*	CABLE, BRAKE, PASSENGER SIDE	1
58	*	CABLE, BRAKE DRIVER'S SIDE	1

## **BRAKE LINKAGE**

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
59	28083-G01	BUMPER, BRAKE COMPENSATOR	. 2
60			
61	12305-G1	RING, RETAINING	4
62			
63	10097-G6	BEARING, FLANGED	2
64	25103-G1	CAM, KICK-OFF	1
65			
66	14134-G4	SPACER	. 1
67	00491-G4	SET SCREW, 1/4 - 20 X 1/2 LG	. 2
68			
69			
70			
71			
72	11027-G1	NUT, LOCK, 5/16 - 18	. 1
73	70113-G01	ADJUSTABLE BUMPER	1
74	10386-G3	PIN, CLEVIS, 5/16 X 15/16 LG	. 3
75	10387-G3	PIN, COTTER, 3/32 X 3/4 LG	. 5
76	12416-G1	NYLON CLAMP	. 2
77	70264-G01	BRAKE PEDAL ASSEMBLY (INCLUDES ITEMS 78 - 88) VEHICLES WITHOUT BRAKE LIGHTS	, 1
78	11737-G1	SPRING, TORSION PARK BRAKE	2
79	12064-G1	PUSHNUT, 5/16	1
80			
81	15932-G2	PIN, PARK BRAKE	. 1
82	70259-G01	BRAKE PEDAL	. 1
83			
84	70274-G01	BRAKE/PARK BRAKE PEDAL PAD KIT (INCLUDES ITEMS 85 - 87)	. 1
85	*	PAD, BRAKE PEDAL	. 1
86	*	PAD, PARK BRAKE PEDAL	. 1
87	16409-G1	RIVET, 3/8 X 15/32 LG	. 9

## **BRAKE LINKAGE**

## **Electric / Gasoline Vehicle**

#### THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.


When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.


G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
88	70254-G01	PARK BRAKE PEDAL	1
89	70098-G01	PIVOT, KICK OFF CAM	1
90			
91	10387-G3	PIN, COTTER, 3/32 X 3/4 LG.	2
92	00559-G8	WASHER, 5/16	2
93	20835-G1	WASHER, TEFLON	2
94			
95	17838-G1	BEARING	2
96	70097-G01	LINK, PARK BRAKE KICK-OFF	1
		<u> </u>	
		•	
		·	


# **BRAKE LINKAGE**




ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	26645-G01	CARBURETOR ASSEMBLY (INCLUDES ITEMS 3 - 16)	. 1
2			
3	26847-G01	NUT, PILOT SCREW	. 2
4	26835-G01	SCREW, PILOT	. 1
5	26838-G01	GASKET, BOWL SCREEN	. 1
6	26839-G01	SCREW, BOWL	1
7	26647-G01	VALVE, NEEDLE	1
8	26840-G01	PIN, FLOAT	. 1
9	26648-G01	FLOAT	. 1
10	26649-G01	JET, PILOT (#48)	. 1
11	26843-G01	GASKET, FLOAT BOWL	. 1
12			
13	26650-G01	TUBE, CARBURETOR VENT	. 2
14			
15	26646-G02	JET, MAIN (#84)	. 1
16	26646-G03	JET, MAIN (#76) HIGH ALTITUDE - ABOVE 5,000 FEET	. 1
17	26637-G01	INSULATOR, CARBURETOR	. 1
18	26725-G01	GASKET, CARBURETOR MOUNT	. 1
19	26726-G01	GASKET, CARBURETOR MOUNT	. 1




ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	26952-G01	DRIVE CLUTCH	1
2	23213-G1	WASHER, PILOT	1
3			
4			
5	00566-G2	WASHER, LOCK, 7/16	. 1
6	00473-G9	BOLT, 7/16 - 20 X 6 1/2 LG.	1
7	26414-G01	BELT, STARTER / GENERATOR	1
8			
9	26301-G02	DRIVEN CLUTCH ASSEMBLY (INCLUDES ITEMS 10 - 19)	. 1
10	27270-G01	RETAINING RING, HEAVY DUTY	1
11	26304-G01	SPRING, COMPRESSION	1
12			
13	00979-G01	SCREW, #10 - 24	. З
14	26479-G01	RAMP BUTTON	. з
15			
16	24600-G1	WASHER, SPACER	. 1
17	*	CAM	. 1
18	*	SHEAVE, MOVABLE	. 1
19	*	SHEAVE AND POST	1
20	22496-G1	WASHER, RETAINING	. 1
21	00565-G8	WASHER, LOCK, 5/16	. 1
22	00441-G8	BOLT, 5/16 - 18 X 4 LG.	. 1
23	72024-G01	BELT, DRIVE	. 1
24	**	PULLER, DRIVE CLUTCH	AR
·		** SEE SERVICE ACCESSORIES AND SPECIAL TOOLS	









BUZZER ASSEMBLY INSTALLATION

### THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

1       73036-G01       DIRECTION SELECTOR ASSEMBLY (INCLUDES ITEMS 2 - 46)	ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
3 00139-GB SCREW, #6 - 32 X 2 LG	1	73036-G01	DIRECTION SELECTOR ASSEMBLY (INCLUDES ITEMS 2 - 46)	1
4       00414-G8       BOLT, 1/4 - 20 X 1 LG.       2         5       00525-G5       NUT, #6 - 32       8         7       00532-G1       NUT, 1/4 - 20       2         8       9         10       00559-G7       WASHER, 1/4       4         11       00560-G1       WASHER, 3/8       1         12       13       00565-G3       WASHER, LOCK, #6       8         14       00565-G7       WASHER, LOCK, 1/4       2         15       16         17       00587-G3       WASHER, LOCK, #6       4         18       19       10606-G2       SWITCH LIMIT, MS2 AND MS4       2         20       21         21       122       11098-G9       NUT, LOCK, 5/16 - 24       1         24       25       12835-G1       CAM       1         26       27       SCREW       4         28       14390-G1       NUT, LOCK, 3/6 - 24       2         29       14628-G1       TAB, FASTON, 5/16 X 5/16       4	2	00138-G4	SCREW, #6 - 32 X 1/2 LG	3
5       6       00525-G5       NUT, #6 - 32	3	00139-G8	SCREW, #6 - 32 X 2 LG	4
6       00525-G5       NUT, #6 - 32	4	00414-G8	BOLT, 1/4 - 20 X 1 LG	2
7       00532-G1       NUT, 1/4 - 20       2         8       9       10       00559-G7       WASHER, 1/4       4         11       00560-G1       WASHER, 3/8       1         12       13       00565-G3       WASHER, LOCK, #6       8         14       00565-G7       WASHER, LOCK, 1/4       2         15       16       17       00567-G3       WASHER, LOCK, #6       4         18       19       10606-G2       SWITCH LIMIT, MS2 AND MS4       2         20       21         21       22       11098-G9       NUT, LOCK, 5/16 - 24       1         23       12806-G1       SPACER       4         24       25       12835-G1       CAM       1         26       27       SCREW       4         28       14390-G1       NUT, LOCK, 3/8 - 24       2         29       14628-G1       TAB, FASTON, 5/16 X 5/16       4	5			
8 9 10 00559-G7 WASHER, 1/4	6	00525-G5	NUT, #6 - 32	8
9 10 00559-G7 WASHER, 1/4	7	00532-G1	NUT, 1/4 - 20	2
10       00559-G7       WASHER, 1/4       4         11       00560-G1       WASHER, 3/8       1         12       13       00565-G3       WASHER, LOCK, #6       8         14       00565-G7       WASHER, LOCK, 1/4       2         15       16       17       00567-G3       WASHER, LOCK, #6       4         18       19       10606-G2       SWITCH LIMIT, MS2 AND MS4       2         20       21       22       11098-G9       NUT, LOCK, 5/16 - 24       1         23       12806-G1       SPACER       4         24       25       12835-G1       CAM       1         26       27       *       SCREW       4         28       14390-G1       NUT, LOCK, 3/8 - 24       2         29       14628-G1       TAB, FASTON, 5/16 X 5/16       4	8			
11       00560-G1       WASHER, 3/8       1         12       13       00565-G3       WASHER, LOCK, #6       8         14       00565-G7       WASHER, LOCK, 1/4       2         15       16       2       17         18       19       10606-G2       SWITCH LIMIT, MS2 AND MS4       2         20       21       22       11098-G9       NUT, LOCK, 5/16 - 24       1         23       12806-G1       SPACER       4         24       25       12835-G1       CAM       1         26       27       *       SCREW       4         28       14390-G1       NUT, LOCK, 3/8 - 24       2         29       14628-G1       TAB, FASTON, 5/16 X 5/16       4	9			
12       13       00565-G3       WASHER, LOCK, #6	10	00559-G7	WASHER, 1/4	4
13 00565-G3 WASHER, LOCK, #6	11	00560-G1	WASHER, 3/8	1
14       00565-G7       WASHER, LOCK, 1/4       2         15       16       4         17       00567-G3       WASHER, LOCK, #6       4         18       19       10606-G2       SWITCH LIMIT, MS2 AND MS4       2         20       21         22       11098-G9       NUT, LOCK, 5/16 - 24       1         23       12806-G1       SPACER       4         24       25       12835-G1       CAM       1         26       27       *       SCREW       4         28       14390-G1       NUT, LOCK, 3/8 - 24       2         29       14628-G1       TAB, FASTON, 5/16 X 5/16       4	12			
15 16 17 00567-G3 WASHER, LOCK, #6	. 13	00565-G3	WASHER, LOCK, #6	8
16       17       00567-G3       WASHER, LOCK, #6       4         18       19       10606-G2       SWITCH LIMIT, MS2 AND MS4       2         20       21         22       11098-G9       NUT, LOCK, 5/16 - 24       1         23       12806-G1       SPACER       4         24       25       12835-G1       CAM       1         26       27       *       SCREW       4         28       14390-G1       NUT, LOCK, 3/8 - 24       2         29       14628-G1       TAB, FASTON, 5/16 X 5/16       4	14	00565-G7	WASHER, LOCK, 1/4	2
17       00567-G3       WASHER, LOCK, #6       4         18       19       10606-G2       SWITCH LIMIT, MS2 AND MS4       2         20       21         22       11098-G9       NUT, LOCK, 5/16 - 24       1         23       12806-G1       SPACER       4         24       25       12835-G1       CAM       1         26       27       *       SCREW       4         28       14390-G1       NUT, LOCK, 3/8 - 24       2         29       14628-G1       TAB, FASTON, 5/16 X 5/16       4	15		•	
18       19       10606-G2       SWITCH LIMIT, MS2 AND MS4	16			
19       10606-G2       SWITCH LIMIT, MS2 AND MS4	17	00567-G3	WASHER, LOCK, #6	4
20	18			
21	19	10606-G2	SWITCH LIMIT, MS2 AND MS4	2
22       11098-G9       NUT, LOCK, 5/16 - 24       1         23       12806-G1       SPACER       4         24       25       12835-G1       CAM       1         26       27       *       SCREW       4         28       14390-G1       NUT, LOCK, 3/8 - 24       2         29       14628-G1       TAB, FASTON, 5/16 X 5/16       4	20			
23       12806-G1       SPACER       4         24       25       12835-G1       CAM       1         26       27       *       SCREW       4         28       14390-G1       NUT, LOCK, 3/8 - 24       2         29       14628-G1       TAB, FASTON, 5/16 X 5/16       4	21			
24         25       12835-G1       CAM	22	11098-G9	NUT, LOCK, 5/16 - 24	1
25       12835-G1       CAM	23	12806-G1	SPACER	4
26       27       *       SCREW	24			
27       *       SCREW	25	12835-G1	CAM	1
28 14390-G1 NUT, LOCK, 3/8 - 24	26			
29 14628-G1 TAB, FASTON, 5/16 X 5/16	27	*	SCREW	4
	28	14390-G1	NUT, LOCK, 3/8 - 24	2
30	29	14628-G1	TAB, FASTON, 5/16 X 5/16	4
]	30			

### **DIRECTION SELECTOR**

THE USE OF NON UL PARTS WILL VOID ANY ULLISTING.

When ordering parts, please specify the model and serial number of the product.


ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
31	14651-G1	CONTACT BOARD ASSEMBLY (INCLUDES ITEMS 32 - 34)	. 1
32	24940-G1	STOP	. 2
33	00565-G7	WASHER, LOCK, 1/4	. 2
34	00414-G6	BOLT, 1/4 - 20 X 3/4 LG.	. 2
35			
36	15461-G1	BRACKET, MOUNTING SUPPORT	. 1
37	15944-G3	BALL, BALL JOINT	. 1
38			
39			
40	73048-G01	BRACKET, COVER	1
41			
42	70232-G01	ARM, SHIFT LINKAGE	. 1
43		·	
44	73027-G01	SHAFT, DIRECTION SELECTOR	. 1
45	73031-G01	BRACKET, DIRECTION SELECTOR MOUNTING	. 1
46	73037-G01	BUZZER, REVERSE WARNING	. 1
47			
48	00438-G8	BOLT, 5/16 - 18 X 3/4 LG.	. 2
49	11098-G9	NUT, LOCK, 5/16 - 24	. 2
50	14444-G3	SOCKET, BALL JOINT	. 2
51		•	
52	00544-G4	NUT, 5/16 - 24	. 2
53	10697-G8	ROD, LINKAGE	1
54	15944-G3	STUD, JOINT BALL	1
55	70232-G02	ARM, SHIFT LINKAGE	. 1
56			
57	25664-G2	BEARING	. 1
58	14390-G1	NUT, LOCK, 3/8 - 24	. 1
59	70233-G01	SHAFT, DIRECTION SELECTOR	. 1
60			

#### THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

LE, DIRECTION SELECTOR  N, STAINLESS STEEL, #10 - 32 X 1/2 LG.  ER, 5/16  ER, FENDER, STAINLESS STEEL  R, DIRECTION SELECTOR  N, 1/4 - 14 x 3/4 LG.  5/32 (ITEMS 69 - 86 FOR USE ON DCS MODEL ONLY)  ER.  KET, BUZZER  ER, LOCK, #6  6 - 32  N, #6 - 32 X 1/2 LG.	1 1 1 1 1 2 2 2 2
ER, 5/16 ER, FENDER, STAINLESS STEEL R, DIRECTION SELECTOR N, 1/4 - 14 x 3/4 LG.  5/32 (ITEMS 69 - 86 FOR USE ON DCS MODEL ONLY) ER ER, LOCK, #6 6 - 32	1 1 1 1 2 1 1 2 2
ER, FENDER, STAINLESS STEEL  R, DIRECTION SELECTOR  N, 1/4 - 14 x 3/4 LG.  5/32 (ITEMS 69 - 86 FOR USE ON DCS MODEL ONLY)  R  KET, BUZZER  ER, LOCK, #6  6 - 32	1 1 1 2 1 1 2 2
ER, FENDER, STAINLESS STEEL  R, DIRECTION SELECTOR  N, 1/4 - 14 x 3/4 LG.  5/32 (ITEMS 69 - 86 FOR USE ON DCS MODEL ONLY)  R  KET, BUZZER  ER, LOCK, #6  6 - 32	1 1 1 2 1 1 2 2
R, DIRECTION SELECTOR	1 1 2 1 1 2 2
V, 1/4 - 14 x 3/4 LG	1 2 1 1 2 2
5/32 (ITEMS 69 - 86 FOR USE ON DCS MODEL ONLY)  R  KET, BUZZER  ER, LOCK, #6  6 - 32	2 1 1 2 2
ER, LOCK, #6	1 1 2 2
ER, LOCK, #6	1 1 2 2
ET, BUZZER	1 2 2
ER, LOCK, #6	2
6 - 32	2
V, #6 - 32 X 1/2 LG	2
	-
, DIRECTION SELECTOR	1
ER, SEAT WRAP	1
ER, DIRECTION SELECTOR SWITCH	1
, NYLON	1
, NYLON	2
RUBBER	1
DIRECTION SELECTOR (INCLUDES ITEMS 85 - 86)	1
OB, DIRECTION SELECTOR	1
OCK, CONTACT SWITCH	1
(	DIRECTION SELECTOR (INCLUDES ITEMS 85 - 86)

**Electric Vehicle** 

# **DIRECTION SELECTOR**



# **Electric Vehicle**

## **DIRECTION SELECTOR**

### THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	73036-G01	DIRECTION SELECTOR ASSEMBLY (INCLUDES ITEMS 2 - 46)	. 1
2	00138-G6	SCREW, #6 - 32 X 3/4 LG.	
3	00139-G8	SCREW, #6 - 32 X 2 LG	
4	00414-G8	BOLT, 1/4 - 20 X 1 LG	. 2
5			
6	00525-G5	NUT, #6 - 32	. 8
7	00532-G1	NUT, 1/4 - 20	. 2
8			
9			
10	00559-G7	WASHER, 1/4	. 4
11	00560-G1	WASHER, 3/8	. 1
12			
13	00565-G3	WASHER, LOCK, #6	. 8
14	00565-G7	WASHER, LOCK, 1/4	. 2
15			
16			
17	00567-G3	WASHER, LOCK, #6	. 4
18			
19	10606-G2	SWITCH LIMIT, MS2 AND MS4	2
20			
21		·	
22			
23	12806-G1	SPACER	. 4
24			
25	12835-G1	CAM	. 1
26			
27	*	SCREW	4
28			
29	14628-G1	TAB, FASTON, 5/16 X 5/16	4
30			

#### THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.


ITEM	PART NO.	1 2 3 4 5 DESCRIPTION C	QTY.
31	14651-G1	CONTACT BOARD ASSEMBLY (INCLUDES ITEMS 32 - 34)	1
32	24940-G1	STOP	2
33	00565-G7	WASHER, LOCK, 1/4	2
34	00414-G6	BOLT, 1/4 - 20 X 3/4 LG	2
35			
36	15461-G1	BRACKET, MOUNTING SUPPORT	1
37			
38			
39			
40	73048-G03	BRACKET, COVER	1
41			
42	70232-G01	ARM, SHIFT LINKAGE	1
43			
44	73027-G01	SHAFT, DIRECTION SELECTOR	1
45	73031-G01	BRACKET, DIRECTION SELECTOR MOUNTING	1
46	73037-G01	BUZZER, REVERSE WARNING	1
47			
48	00438-G6	BOLT, 5/16 - 18 X 3/4 LG.	2
49	11098-G6	NUT, LOCK, 5/16 - 18	2
50	00571-G2	WASHER, 5/16	2
51		· 1	
52			
53	70313-G01	ROD, LINKAGE	1
54	22754-G3	BUSHING	1
55	70334-G01	ARM, BENT SHIFT LINKAGE	1
56			
57	25664-G2	BEARING	1
58	14390-G1	NUT, LOCK, 3/8 - 24	2
59	70233-G01	SHAFT, DIRECTION SELECTOR	1
60			

## **Electric Vehicle**

### **DIRECTION SELECTOR**

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
61	71905-G01	HANDLE, DIRECTION SELECTOR	1
62	00740-G4	SCREW, STAINLESS STEEL, #10 - 32 X 1/2 LG	1
63			
64			
65	16469-G7	WASHER, FENDER, STAINLESS STEEL	1
66	73049-G01	COVER, DIRECTION SELECTOR	1
67	00114-G6	SCREW, 1/4 - 14 x 3/4 LG	1





ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	25700-G03	DIRECTION SELECTOR ASSEMBLY (INCLUDES ITEMS 2 - 29)	1
2	25684-G01	BRACKET, DIRECTION SELECTOR	1
3	25664-G1	BUSHING	1
4			
5	27537-G01	SHAFT, DIRECTION SELECTOR	. 1
6	25745-G01	CAM, DIRECTION SELECTOR	1
7			
8	14390-G1	NUT, LOCK, 3/8 - 24	1
9			
10			
11			
12			
13	10606-G1	MICRO SWITCH	. 1
14	·		
15	27151-G1	SPACER, MICRO SWITCH	. 1
16	00645-G2	SCREW, #6 - 32 X 1 1/4 LG.	2
17	00565-G3	WASHER, LOCK, #6	. 4
18			
19	00525-G5	NUT, #6 - 32	4
20	14628-G1	TAB, FASTON	. 1
21	*	SCREW AND WASHER ASSEMBLY	. 2
22		•	
23	17818-G1	BUZZER, REVERSE WARNING	. 1
24	00138-G5	SCREW, #6 - 32 X 5/8 LG	. 2
25	00567-G3	WASHER, LOCK, #6	. 2
26	00559-G7	WASHER, 1/4	. 2
27			
28	00414-G6	SCREW, 1/4 - 20 X 3/4 LG	. 2
29	11027-G2	NUT, LOCK, 1/4 - 20	, <sub>2</sub>
30	27170-G01	CABLE KIT (INCLUDES ITEMS 31 - 39)	. 2

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
31	25727-G01	WASHER, CUP	4
32	27764-G01	SPRING	2
33	11098-G7	NUT, #10 - 24	2
34	10387-G8	PIN, COTTER, 1/16 X 3/4 LG	2
35	25691-G01	SHIFTER CONTROL CABLE	2
36			
37	23726-G5	SPACER	2
38	23176-G1	PIN, CLEVIS, 5/16 X 1/2 LG	2
39	17618-G1	NYLON CLAMP	1
40	26830-G01	NUT, SHIFTER LEVER, M8 X 1.25 MM	1
41			
42	71905-G01	HANDLE, DIRECTION SELECTOR	1
43	00740-G4	SCREW, STAINLESS STEEL, #10 - 32 X 1/2 LG	1
44	25946-G01	PIVOT ARM	1

# **DIRECTION SELECTOR**







THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.


ПЕМ	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	18724-G1	RECEPTACLE HOLDER	1
2	00645-G2	SCREW, #6 - 32 X 1 1/4 LG.	2
3	00559-G3	WASHER, #6	2
4	14390-G9	NUT, LOCK, #6 - 32	2
5			
6	00702-G2	NUT, 5/16 - 24	12
7	25972-G32	WIRE	1
8	25972-G40	WIRE	4
9			
10	00567-G8	WASHER, LOCK, 5/16	8
11	00532-G3	NUT, 5/16 - 18	8
12			
13	27327-G01	CLAMP, TWISTED	2
14	10570-G11	RIVET, STAINLESS STEEL, 5/16	1
15			
16	73145-G01	HARNESS, KEY SWITCH (DCS MODEL ONLY)	1
17	73041-G01	HARNESS, KEY SWITCH (FLEET)	1
18	00568-G6	WASHER, LOCK, 3/4	1
19	17062-G1	KEY, IGNITION (SET)	AR
20	17137-G1	NUT, FACE	1
21			
22	17618-G1	CLAMP, NYLON	1
23	17421-G1	IGNITION SWITCH KIT, INCLUDES ALL MOUNTING HARDWARE (FOR FREEDOM SEE SECTION S - HORN AND LIGHTING)	1
24	33623-G02	RIVET, DRIVE	2
25	71145-G01	DECAL, CONSOLE INSERT PLATE	1
26	73030-G01	PLATE, CONSOLE INSERT (KEY ONLY)	1
27	70045-G01	RETAINER, BATTERY	1
28	70046-G01	BATTERY RACK	1
29	11027-G1	NUT, LOCK, 5/16 - 18	2


### **Electric Vehicle**

#### **ELECTRICAL SYSTEM**


THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
30	XXXXX-G**	BATTERY, 6 VOLT	. 6
31			
32	70121-G01	BOLT, HOLD DOWN	. 2
33	17618-G1	CLAMP, NYLON	. 1
34	24605-G1	WIRE HARNESS, BRAKE	. 1
35	73063-G01	WIRE HARNESS, STANDARD CHARGER RECEPTACLE (COMPLETE)	. 1
36	73149-G01	WIRE HARNESS, CHARGER RECEPTACLE (ITEMS 36 - 38 ARE FOR USE ON DCS MODEL ONLY)	. 1
37	14601-G10	RIVET, 5/32	. 4
38	17618-G1	CLAMP, NYLON	3
39	25972-G32	WIRE, BL- TO B	. 1





Service Parts Manual




### **ELECTRICAL SYSTEM**

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	26651-G01	IGNITION PICKUP ASSEMBLY (INCLUDES ITEM 2)	1
2	26707-G01	BOLT AND WASHER ASSEMBLY, M5 X .8 X 10 MM LG	1
3			
4	26676-G01	SCREW, M6 X 1 X 23 MM LG	1
5	26652-G01	IGNITION COIL ASSEMBLY (INCLUDES ITEMS 6 - 10)	1
6	*	COIL, IGNITION	1
7	*	SPACER	. 1
8	*	WASHER, LOCK	1
9	*	NUT	1
10	*	SCREW	1
11			
12	13632-G1	NUT, M6 X 1 LG	2
13	xxxxx-xx	STARTER / GENERATOR (SEE SECTION AA FOR PARTS LIST AND QUANTITY)	. ×
14	25887-G01	WIRE, F1 - A2	1
15	25682-G1	COVER, TERMINAL	. з
16			
17	00715-G3	BOLT, 5/16 - 18 X 1 1/4 LG.	. 1
18	20294-G3	CABLE, GROUND	. 1
19	25972-G12	WIRE, B- GRD	1
20			
21	27778-G01	KEY SWITCH HARNESS	1
22	27777-G01	CONTROL HARNESS	1
23	27740-G03	ELECTRICAL PLATE ASSEMBLY (INCLUDES ITEMS 25 - 42)	. 1
24			
25	00532-G1	NUT, 1/4 - 20	. 5
26			
27	*	NUT, 5/16 - 24	. 2
28	00565-G7	WASHER, LOCK, 1/4	. 6
29	*	WASHER, LOCK, #10	. 2

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
30	*	NUT, #10 - 32	2
31			
32	00650-G7	WASHER, 1/4	6
33	12914-G1	TAB, FASTON, 5/16 x 5/16	2
34	12914-G2	TAB, FASTON, 3/8 x 13/32	2
35	*	WASHER, LOCK, 5/16	2
36	25978-G56	WIRE, 5 3/4" LG	1
37	27153-G0 <b>1</b>	SOLENOID	1
38			
39	27738-G01	PLATE, ELECTRONIC	1
40	27739-G01	VOLTAGE REGULATOR	1
41	27746-G01	IGNITOR ASSEMBLY	1
42	*	SPACER, COVER	1
43			
44	11027-G2	NUT, LOCK, 1/4 - 20	3
45	25972-G13	WIRE, SOL - F2	1
46	72004-G01	COVER, ELECTRICAL PLATE	1
47	25972-G33	WIRE, B+ - SOL	1
48			
49	•	BOLT, 5/16 X 3/4 LG	2
50	*	NUT, 5/16	2
51	*	WASHER, LOCK, 5/16	2
52			
53	73030-G01	PLATE, CONSOLE INSERT	1
54	71133-G01	DECAL, IGNITION SWITCH	1
55			Į
56	33623-G02	RIVET, DRIVE	2
57	17421-G1	IGNITION SWITCH KIT, INCLUDES ALL MOUNTING HARDWARE (FOR FREEDOM SEE SECTION S - HORN AND LIGHTING)	1
58	00568-G6	WASHER, LOCK, 3/4	1

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
59	17137-G1	NUT, FACE	1
60	17063-G1	KEY, IGNITION	. AR
61			
62			
63	00565-G8	WASHER, ŁOCK, 5/16	. 1
64	00571-G2	WASHER, 5/16	1
65			
66	00952-G6	BOLT, 5/16 - 18 X 3/4 LG.	. 1
67			
68	XXXXX-G**	BATTERY, 12 VOLT	1
69			
70	72101-G01	HOLD DOWN, BATTERY	1
71	25976-G11	WIRE	1
72	17618-G1	NYLON CLAMP	2
73	24605-G01	WIRE HARNESS, BRAKE	. 1



#### **ENGINE AND MUFFLER**


ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	26700-G01	ENGINE	. 1
2			
3	26631-G01	GROMMET, TIMING BELT COVER	1
4	26727-G01	GASKET, CARBURETOR / AIR BOX	1
5	26667-G01	STUD	2
6	25523-G3	SPARK PŁUG, RESISTIVE	AR
7	25523-G2	SPARK PLUG, NGK BP4ES	2
8	26733-G01	SPARK PLUG WIRE SET (2 WITH BOOTS)	1
9			
10	26657-G01	BRACKET, IGNITION COIL	. 1
11			
12	xxxxx-xx	CARBURETOR (SEE SECTION F FOR PART NUMBER AND QUANTITY	×
13	26719-G01	GASKET, VALVE COVER	. 1
14			
15	26676-G01	BOLT, FLANGED, M6 X 1 X 23 MM LG.	. 6
16	26601-G01	CAP, OIL FILLER	. 1
17	26720-G01	"O" RING	. 1
18			
19	26600-G01	COVER, VALVE	. 1
20	25532-G1	BOLT AND WASHER, M8 X 1.25 X 18 MM LG	. 2
21	72019-G01	MUFFLER	] 1
22			
23	25532-G1	BOLT AND WASHER, M8 X 1.25 X 18 MM LG.	. 2
24	25531-G1	GASKET, EXHAUST	. 1
25	00438-G8	BOLT, 5/16 - 18 X 1 LG.	1
26			
27			
28	00565-G8	WASHER, LOCK, 5/16	. 1
29	00642-G8	WASHER, 5/16	. 1

When ordering parts, please specify the model and serial number of the product.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
30			
31	25655-G01	BRACKET, PIVOT	1
32	00565-G8	WASHER, LOCK, 5/16	2
33			
34	00276-G6	SCREW, 5/16 - 24 X 3/4 LG.	2
35	26630-G01	COVER, TIMING BELT	1
36	26626-G01	TIMING BELT	1
37	26678-G01	BOLT, M6 X 1 X 12 MM LG	3
38			
39			
40			
41			
42	26591-G01	FILTER, OIL	1
43			
44	26680-G01	BOLT AND WASHER, M6 X 1 X 12 MM LG	3
45	26710-G01	"O" RING, OIL FILTER	1

# **ENGINE AND MUFFLER**





# **ENGINE AND STARTER MOUNTING**


ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	00430-G4	SCREW, 3/8 - 16 X 4 1/2 LG	1
2	72050-G01	WASHER, PLASTIC	. 4
3			
4	11098-G5	NUT, LOCK, 3/8 - 16	. 1
5	72015-G01	MOUNT, ISOLATION	. 1
6	72010-G01	FRONT MOUNT CASTING	. 1
7	72018-G01	BRACKET, MOUNT	. 1
8			
9	27432-G02	ENGINE GUARD	. 1
10	00463-G4	SCREW, 7/16 - 14 X 1 1/2 LG	. 6
11	00566-G2	WASHER, LOCK, 7/16	6
12	00922-G3	WASHER, 7/16	6
13			
14	00428-G6	SCREW, 3/8 - 16 X 2 3/4 LG	. 2
15	12262-G1	NUT, LOCK, 3/8 - 16	. 2
16	72011-G01	REAR ENGINE MOUNT CASTING	. 1
17			
18	72035-G01	"U" - BOLT	2
19	00734-G1	NUT, LOCK, 7/16 - 14	4
20			
21	72051-G02	WASHER, 2.50 X .390 X .134	. 2
22	72051-G01	WASHER, 2.50 X .641 X .134	2
23			
24	70269-G01	BRACE, CROSSMEMBER	1
25	00715-G3	SCREW, 5/16 - 18 X 1 1/4 LG	. 2
26			
27	11027 <b>-</b> G1	NUT, FLANGED LOCK, 5/16 - 18	. 2
28			
29	72016-G01	SPACER, ISOLATOR	. 2
30	00938-G4	SCREW, 1/2 - 13 X 8 LG	. 1

When ordering parts, please specify the model and serial number of the product.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
31	00560-G3	WASHER, 1/2	2
32	00566-G3	WASHER, LOCK, 1/2	1
33			
34	00533-G1	NUT, 1/2 - 13	1
35	27065-G01	STARTER / GENERATOR	1
36	72045 <b>-G</b> 01	STARTER / GENERATOR ADJUSTER	1
37	00544-G5	NUT, 3/8 - 16	1
38			
39	00532-G5	NUT, 3/8 - 16	1
40	00560-G1	WASHER, 3/8	1
41	12064-G1	NUT, PUSH, 5/16	1
42			
43	xxxxx-xx	DIFFERENTIAL (SEE REAR AXLE SECTION V FOR PART NUMBER AND QUANTITY)	х
44	00438-G8	BOLT, 5/16 - 18 X 1 LG	1
45	11098-G6	NUT, LOCK, 5/16 - 18	1

## **ENGINE AND STARTER MOUNTING**






#### **FILTERED AIR SYSTEM**

When ordering parts, please specify the model and serial number of the product.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	72146-G01	INLET COVER	. 1
2	00614-G5	SCREW, #8 - 18 X 5/8 LG	
3	72143-G01	COVER, AIR FILTER	
4		·	
5	72148-G01	LATCH, AIR FILTER	. з
6	72144-G01	ELEMENT, AIR FILTER	. 1
7	72142-G01	HOUSING, AIR FILTER	. 1
8			
9	26676-G01	BOLT, M6 X 30 MM LG	. 2
10	13632-G1	NUT, M6 X 1	. 2
11	51400-G1	WASHER, LOCK, 6 MM	. 2
12			
13	23726-G6	SPACER, CARBURETOR MOUNT	4
14	72151-G01	HOSE, PCV	. 1
15			
16	72147-G01	GROMMET, HOUSING MOUNT	. 2
17	23726-G7	SPACER, HOUSING MOUNT	. 2
18	26671-G01	BOLT, WASHER, M6 X 1 X 30 MM LG.	. 2
19	26701-G01	WASHER, 6.5 X 20 X 1.6	2
			Į
			· ·



### **Electric / Gasoline Vehicle**

#### FRONT SUSPENSION

THE USE OF NON UL PARTS WILL VOID AND UL LISTING.

When ordering parts, please specify the model and serial number of the product.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	70001-G01	FRONT AXLE	. 1
2	10194-G1	BUSHING, RUBBER SHOCK ABSORBER	. 8
3	10435-G1	WASHER, SHOCK ABSORBER	. 8
4	00532-G6	NUT, 3/8 - 24	4
5	00463-G6	BOLT, 7/16 - 14 X 1 3/4 LG.	6
6	00734-G1	NUT, LOCK, 7/16 - 14	12
7			
8	70163-G02	PLATE, SPRING	4
9	10387-G2	PIN, COTTER, 3/32 X 1 LG	2
10			
11	70220-G01	SPINDLE ASSEMBLY, DRIVER'S SIDE (INCLUDES ITEMS 12 - 25)	. 1
12	*	SPINDLE, DRIVER'S SIDE	1
13	16623-G1	BEARING	. 2
14	18456-G1	GREASE FITTING	. 1
15	19058-G2	HUB, WHEEL	. 1
16			
17	19862-G1	WHEEL BOLT, 1/2 - 20	. 4
18	50892-G1	BEARING AND RACE ASSEMBLY (COMPLETE)	. 1
19			
20			
21	25146-G1	SEAL, GREASE	. 1
22			
23	12093-G1	NUT, SLOTTED, 17/32	. 1
24			
25	00798-G8	PIN, COTTER, 5/32 X 1 3/4 LG	. 1
26	70220-G02	SPINDLE ASSEMBLY, PASSENGER SIDE (INCLUDES ITEMS 13 - 25 AND 27)	. 1
27	*	SPINDLE, PASSENGER SIDE	. 1
28			
29	70327-G01	PIN, SPINDLE, 1/2 - 13 X 5 1/2 LG	. 2

### FRONT SUSPENSION

### **Electric / Gasoline Vehicle**

THE USE OF NON UL PARTS WILL VOID AND UL LISTING.


When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.


ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
30	16982-G1	WASHER, THRUST	2
31	70328-G01	TUBE, SPINDLE PIN	2
32			
33	00571-G5	WASHER, 1/2	4
34			
35	14390-G6	NUT, LOCK, 1/2 -13	2
36	70049-G01	SPRING, LEAF	2
37			
38	00463-G4	BOLT, 7/16 - 14 X 1 1/2 LG	6
39	70324-G01	SHOCK ABSORBER	2
40	12091-G1	CAP, SPINDLE	2
41	14723-G1	NUT, LUG, 1/2 - 20	8
			Ì
		·	
		<u> </u>	








When ordering parts, please specify the model and serial number of the product. \* Indicates a component that is not available as an individual part.


ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	72092-G01	FUEL TANK, STANDARD	. 1
2	27184-G06	PULSE TUBE, 16" LG	1
3	14099- <b>G</b> 2	FUEL TANK CAP, STANDARD (WITH GAUGE)	. 1
4	20039-G1	FUEL TANK CAP, FREEDOM ONLY (WITHOUT GAUGE)	. 1
5	00438-G8	BOLT, 5/16 - 18 X 1 LG.	. 2
6	00559-G8	WASHER, 5/16	. 4
7	11098-G6	NUT, LOCK, 5/16 - 18	. 2
8	72092-G02	FUEL TANK (FREEDOM)	. 1
9	11027-G2	NUT, LOCK, 1/4 - 20	. 2
10	72021-G01	FUEL PUMP	. 1
11	72084-G01	FILTER, FUEL	. 1
12	17470-G**	FUEL SYSTEM TUBE, 3 1/4 LG. (CUT TO LENGTH)	AR
13			
<b>1</b> 4	17470-G**	FUEL SYSTEM TUBE, 16 LG. (CUT TO LENGTH)	AR
15	11391-G4	CLAMP, HOSE	3
16			
17	17618-G1	CLAMP, NYLON	. 1
18	18292-G1	CLAMP, TUBING	. 5
19			
20	32372-G6	VINYL TRIM, 6 1/4 LG	. 1
21	72229-G01	ADAPTER, FUEL LEVEL SENDER (FREEDOM)	. 1
22	72230-G01	SCREW, #6 - 32 X 1/4 LG. (FREEDOM)	. 2
23			
24	20048-G2	SENDER, FUEL LEVEL, FREEDOM (INCLUDES ITEMS 25, 26)	. 1
25	*	SCREW	. 5
26	*	GASKET	. 1

















# **Electric / Gasoline Vehicle**

#### **HORN AND LIGHTING**

#### THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	22674-G1	FUSE BLOCK	1
2	71010-G01	RIVET, 5/32 X 3/8 LG	. 2
3	18392-G1	FUSE, 15 AMP	. з
4	19344-G1	TAPE, VINYL	. AR
5	20965-G3	COVER, STEERING COLUMN (VEHICLES WITH TURN SIGNALS)	. 1
6	17318-G2	CAP AND NUT, HORN SWITCH	. 1
7	32860-G1	HORN (WITH MOUNTING HARDWARE)	. 1
8	00559-G8	WASHER, 5/16	1
9			
10			
11	17318-G1	SWITCH, HORN	. 1
12	27068-G01	BOOT, HORN SWITCH	, 1
13	19233-G1	PLATE, HORN SWITCH	. 1
14	14601-G7	RIVET, STAINLESS STEEL, 9/16.	. 2
15	17618-G1	CLAMP, NYLON	. 2
16			
17	17867-G1	TURN SIGNAL (WITH MOUNTING HARDWARE)	. 1
18	21640-G1	FLASHER, TURN SIGNAL	. 1
19	00414-G6	SCREW, 1/4 - 20 X 3/4 LG	. 2
20	11027-G2	NUT, LOCK, 1/4 - 20	. 2
21	74001-G01	LIGHTBAR	. 1
22	74002-G02	BRACKET, LIGHTBAR, DRIVER'S SIDE	. 1
23	74002-G01	BRACKET, LIGHTBAR, PASSENGER SIDE	. 1
24	00114-G6	SCREW, 1/4 - 14 X 3/4 LG	. 8
25			
26	21553-G1	FUEL GAUGE (COMPLETE WITH HARDWARE)	. 1
27			
28	25978-G74	WIRE	. 1
29			
30			

### **HORN AND LIGHTING**

## **Electric / Gasoline Vehicle**

#### THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
31			
32			
33	33633-G01	HOUR METER	1
34	33636-G01	STATE OF CHARGE METER	1
35			
36			
37	25977-G27	WIRE	1
38	74358-G01	BEZEL, TAILLIGHT, DRIVER'S SIDE	1
39	74358-G02	BEZEL, TAILLIGHT, PASSENGER SIDE	1
40	22288-G1	TAILLIGHT ASSEMBLY, COMPLETE	1
41	14601-G11	RIVET, 3/16 X 5/8 LG	2
42	21759-G1	BULB, REPLACEMENT, TAILLIGHT	AR
43	23474-G1	LOW OIL / FUEL LIGHT INDICATOR	1
44	73043-G01	HARNESS, ACCESSORY (ELECTRIC)	1
45	72228-G01	HARNESS, ACCESSORY (GAS)	1
46			
47	00568-G6	WASHER, LOCK, 3/4	1
48	17063-G1	KEY, IGNITION	2
49	17137-G1	NUT, FACE	1
50	00891-G2	NUT, LOCK,1/4 - 20	1
51	00414-G5	BOLT, 1/4 - 20 x 5/8 LG	1
52	00559-G8	WASHER, 5/16	1
53	18602-G1	SWITCH, IGNITION	1
54	33639-G01	SWITCH, IGNITION (WITH LIGHTS)	1
55			
56			
57	74004-G01	BULB, REPLACEMENT, HEADLIGHT	AR
58	74005-G01	BULB, REPLACEMENT, MARKER LIGHT	AR
59	74006-G01	BULB, REPLACEMENT, TURNLIGHT	AR
60			


# **Electric / Gasoline Vehicle**

#### **HORN AND LIGHTING**

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.


ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
61		·	
62			
63			
64	73030-G02	PLATE, CONSOLE INSERT, STATE OF CHARGE METER	1
65	71123-G01	DECAL, CONSOLE PLATE, STATE OF CHARGE METER	1
66	71129-G01	DECAL, CONSOLE PLATE, STATE OF CHARGE METER WITH LIGHTS	1
67			
68			
69	73030-G03	PLATE, CONSOLE INSERT, LOW FUEL / OIL LIGHTS	1
70	71125-G01	DECAL, CONSOLE PLATE, LOW FUEL / OIL LIGHTS	1
71			
72	73030-G04	PLATE, CONSOLE INSERT, FUEL GAUGE	1
73	71127-G01	DECAL, CONSOLE PLATE, FUEL GAUGE	1
74	71131-G01	DECAL, CONSOLE PLATE, FUEL GAUGE	
		WITH LIGHTS	1
į			
		·	
•			



THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.


When ordering parts, please specify the model and serial number of the product.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	73124-G01	MOTOR, COMPLETE (DCS MODEL ONLY)	. 1
2	27045-G01	MOTOR, 2.0 HP, COMPLETE (INCLUDES ITEMS 6 - 25)	. 1
3			
4	73172-G01	MOTOR, 2.7 HP, COMPLETE (INCLUDES ITEMS 6 - 25)	. 1
5			
6	27630-G01	END SHIELD	1
7	*	ARMATURE	. 1
8	*	STATOR COMPLETE (INCLUDES ITEMS 10 AND 17)	1
9			
10	*	STATOR SHELL AND WINDING	1
11			
12	27630-G05	BRUSH (WITH TERM SCREW)	2
13	27630-G06	NUT, 1/4 - 20	4
14	27630-G0 <b>7</b>	WASHER, 1/4	4
15	27630-G08	BUSHING, INSULATED	2
16			
17	27630-G09	BRUSH, RIGGING	1
18	27630-G10	SCREW, BRUSH HOLDER	. 2
19	27630-G11	BUSHING, INSULATED	. 2
20	27630-G12	RETAINER, BEARING	. 1
21	27630-G13	BALL BEARING	. 1
22			
23	27630-G14	END SHIELD	1
24	27630-G15	SCREW, CLAMP	. 4
25	27630-G16	SCREW, BEARING RETAINER	. 2



#### THE USE OF NON UL PARTS WILL VOID ANY ULLISTING.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1			<del>                                     </del>
2	28095-G01	MOLY LUBE, 2 OZ.	AR
3			
4			
5	00559-G7	WASHER, 1/4	з
6	00565-G7	WASHER, LOCK, 1/4	з
7	00797-G2	BOLT, 1/4 - 20 X 1 1/4 LG.	з
8			
9	73069-G01	REAR AXLE ASSEMBLY (INCLUDES ITEMS 10 - 21)	1
10	24261-G1	BUMPER SPLINE	1
11			
12	25227-G1	WASHER	1
13	25226-G1	PLUG, FILL/CHECK	1
14	73050-G01	VENT ASSEMBLY (PUSH IN)	1
15			
16	72036-G01	BRACKET, BRAKE CABLE, PASSENGER SIDE	1
17	72036-G02	BRACKET, BRAKE CABLE, DRIVER'S SIDE	1
18	25228-G1	COVER, DIFFERENTIAL	1
19	20377-G12	AXLE SHAFT, PASSENGER SIDE	1
20	20377-G11	AXLE SHAFT, DRIVER'S SIDE	1
21	15558-G1	SCREW, 5/16 - 18 X 3/4 LG	10




ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	72031-G01	REAR AXLE, (13.32:1), STANDARD (INCLUDES ITEMS 4 - 35)	. 1
2	72031-G02	REAR AXLE, HP (10.67:1) INCLUDES ITEMS 4 - 35 FOR USE ON FREEDOM HP VEHICLES ONLY	. 1
3			
4	26766-G01	SEAL, AXLE SHAFT	1
5	26828-G01	WASHER, 10 MM	. 10
6	26829-G01	NUT, 10 MM X 1.5 MM	. 10
7	26667-G01	STUD, M10 X 1.5 X 40 MM LG	. 5
8	26761-G01	SEAL, INPUT SHAFT	. 1
9	26815-G01	BRACKET, SHIFTER CABLE	. 1
10	26823-G01	BOLT, FLANGE, M8 X 1.25 X 100 MM LG	. 8
11	26762-G01	SEAL, SHIFTER SHAFT	. 1 ;
12			
13	72017-G01	BRACKET, TRANSAXLE	. 1
14	26826-G01	WASHER, LOCK, M8	. 4
15	26827-G01	NUT, M8 X 1.25 MM	4
16			
17			
18			
19	75048-G01	SPACER	. 1
20	26814-G01	RING, RETAINING	4
21	26811-G01	BALL BEARING	2
22	72056-G01	AXLE SHAFT, DRIVER SIDE	1
23	72057-G01	AXLE SHAFT, PASSENGER SIDE	1
24			
25	72115-G01	TUBE, AXLE, DRIVER'S SIDE	1
26	72116-G01	TUBE, AXLE, PASSENGER SIDE	1
27	26824-G01	BOLT, FLANGE, M8 X 1.25 X 110 MM LG.	1
28	72053-G01	BOLT, FLANGE, M8 X 1.25 X 120 MM LG	1
29			

When ordering parts, please specify the model and serial number of the product.

PART NO.		YTY.
26770-G01	•	1
26771-G01	GASKET, 14 MM	1
26768-G01		1
26769-G01		1
26772-G01	PLUG, OIL FILLER	1
	26770-G01 26771-G01 26768-G01 26769-G01	26770-G01 DRAIN PLUG, OIL

**Gasoline Vehicle** 

**REAR AXLES** 




## **Electric Vehicle**


#### **REAR SUSPENSION**


THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.


ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	70247-G01	SPRING, LEAF	. 2
2	74135-G01	SPRING, LEAF (USE ON 4 CADDY ONLY)	2
3	72029-G01	"U" BOLT, 3/8 - 16	4
4	74124-G01	"U" BOLT, 3/8 - 16 (USE ON 4 CADDY ONLY)	4
5	00560-G1	WASHER, 3/8	8
6	11098-G5	NUT, LOCK, 3/8 - 16	. 12
7	70291-G01	BUSHING, RUBBER (LEAF SPRING)	. 12
8	70290-G01	SHACKLE PLATE	. 4
9			
10	70289-G02	SPACER	. 4
11			
12	00429-G2	SCREW, 3/8 - 16 X 3 1/4 LG	. 4
13	00643-G1	WASHER, 3/8	2
14	11098-G5	NUT, 3/8 - 16	. 2
15	14158-G1	BOLT, SHOULDER, 7/16 - 14 X 3 1/4 LG	. 2
16			
17	70324-G01	SHOCK ABSORBER	. 2
18		·	
19	10194-G1	BUSHING, RUBBER, SHOCK ABSORBER	. 8
20	10435-G1	WASHER, SHOCK ABSORBER	. 8
21			
22	00532-G6	NUT, 3/8 - 24	. 4
		<u></u>	




ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	70291-G01	BUSHING, RUBBER (LEAF SPRING)	12
2			
3	70289-G02	SPACER	4
4	14158-G1	BOLT, SHOULDER, 3/16 x 3 1/4 LG	2
5	11098-G5	NUT, 3/8 - 16	. 2
6	10194-G1	BUSHING, RUBBER (SHOCK ABSORBER)	. 8
7	10435-G1	WASHER (SHOCK ABSORBER)	. 8
8	00532-G6	NUT, 3/8 - 24	4
9	72029-G01	U-BOLT, 3/8 - 16	4
10	74124-G01	U-BOLT, 3/8 - 16 (USE ON 4 CADDY ONLY)	4
11	74135-G01	SPRING, LEAF (USE ON 4 CADDY ONLY)	2
12	70247-G01	SPRING, LEAF	2
13	70324-G01	SHOCK ABSORBER	. 2
14	72028-G01	BASE PLATE, ISOMOUNT	. 2
15	72117-G01	BUSHING, ISOMOUNT	. 2
16			
17	72037-G01	CAP, ISOMOUNT	. 2
18	11098-G5	NUT, LOCK, 3/8 - 16	. 8
19	00560-G1	WASHER, 3/8	. 8
20			
21	70290-G01	SHACKLE PLATE	4
22			
23	00429-G2	SCREW, 3/8 - 16 X 3 1/4 LG	. 4
24	11098-G5	NUT, LOCK, 3/8 - 16	. 1
25	00643-G1	WASHER, 3/8	. 2









### **SEATING AND BAGRACK**

## **Electric / Gasoline Vehicle**

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	71611-G**	SEAT BOTTOM ASSEMBLY (INCLUDES ITEMS 3 - 17)	1
2			
3	*	NUT, TEE	8
4			
5	17074-G1	BUMPER, SEAT	2
6	:		
7			
8	*	STAPLE, FLAT	110
9	*	STAPLE, FLAT	46
10			
11			
12	71012-G01	VINYLTRIM, SEAT BOTTOM	1
13	71602-G**	VINYL SEAT BOTTOM COVER	1
14	71603-G02	FOAM PADDING, SEAT BOTTOM	1
15	71604-G01	SEAT BOTTOM, WOOD	1
16			
17	71608-G01	REAR TRIM, SEAT	1
18			
19			
20			
21	00414-G8	BOLT, 1/4 - 20 X 1 LG.	4
22	00565-G7	WASHER, LOCK, 1/4	4
23	11027-G2	NUT, LOCK, 1/4 - 20	2
24	16816-G1	FASTENER, PLASTIC RATCHET	2
25	71751-G**	SEAT BACK ASSEMBLY (INCLUDES ITEMS 26 - 34)	1
26	*	STAPLE, FLAT	95
27			
28	71752-G01	PLASTIC, REAR COVER SEAT BACK	1
29	71753-G**	VINYL SEAT BACK COVER	1
30	71754-G01	FOAM PADDING, SEAT BACK	1

## **Electric / Gasoline Vehicle**

#### **SEATING AND BAGRACK**

#### THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
31			
32	71755-G01	SEAT BACK, WOOD	1
33	71002-G01	SCREW, #8 X 1 LG	4
34	*	NUT, TEE	. 4
35			
36			
37			
38	71802-G01	BOLT, 3/8 - 16 X 2 1/4 LG.	4
39	71803-G02	BRACKET, SEAT SUPPORT	2
40	71821-G01	BOLT, CARRIAGE, 1/4 - 20 X 1 1/2 LG	2
41	71851-G01	BRACKET, BAG HOLDER	. 1
42	71853-G01	STRAP, BAG RETAINER	. 1
43	71856-G01	BAG RETAINER CLAMP	. 2
44			
45	00720-G08	SCREW, #12 - 14 X 1 LG	. 4
46	00414-G8	BOLT, 1/4 - 20 X 1 LG	. 8
47			
48	00559-G7	WASHER, 1/4	. 8
49	71701-G01	HIP RESTRAINT, PASSENGER SIDE	. 1
50	71702-G01	HIP RESTRAINT, DRIVER'S SIDE	. 1
51			
52	71615-G01	HINGE, SEAT (VEHICLES PRIOR TO SERIAL NO. 895713)	. 2
53	71610-G01	HINGE, SEAT (VEHICLES AFTER SERIAL NO. 895713)	. 2
54			
55	74111-G01	SUPPORT, SEAT BACK	. 2
56	00414-G8	BOLT, 1/4 - 20 X 1 LG.	. 4
57	00565-G7	WASHER, LOCK, 1/4	. 4
58	00559-G7	WASHER, 1/4	. 4
59	70113-G01	BUMPER, RUBBER	. 4
60	11027-G1	NUT, LOCK, 5/16 - 18	. 6

### **SEATING AND BAGRACK**

### **Electric / Gasoline Vehicle**


THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.


ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
61	01006-G01	BOLT, 3/8 - 16 X 1 1/4 LG.	. 4
62	00560-G1	WASHER, 3/8	4
63	•		i
64	74131-G**	SEAT ASSEMBLY (INCLUDES ITEMS 65 - 79)	. 1
65	74139-G**	SEAT BOTTOM ASSEMBLY (INCLUDES ITEMS 66 - 77)	. 1
66	71602-G**	VINYL COVER, SEAT BOTTOM	. 1
67	71603-G02	FOAM, SEAT BOTTOM	. 1
68	74141-G01	WOOD, SEAT BOTTOM	. 1
69	*	NUT, TEE	16
70	74140-G01	TRIM, SEAT, FRONT	1
71	*	STAPLE, FLAT	110
72	*	STAPLE, FLAT	48
73	71702-G01	HIP RESTRAINT, DRIVER'S SIDE	1
74	71701-G01	HIP RESTRAINT, PASSENGER SIDE	1
75	00414-G8	BOLT, 1/4 - 20 X 1 LG	8
76	71608-G01	TRIM, SEAT, REAR	1
77	00559-G7	WASHER, 1/4	8
78			
79	71751-G**	SEAT BACK ASSEMBLY (INCLUDES ITEMS 26 - 34)	1
80	74117-G01	BRACKET, REAR SEAT SUPPORT	2
81	00414-G8	BOLT, 1/4 - 20 X 1 LG.	12
82	00565-G2	WASHER, LOCK, #5	12
83	00559-G7	WASHER, 1/4	12
84	17838-G1	BUSHING, NYLON	4
85	74134-G01	PIN, HITCH	2

**Electric / Gasoline Vehicle** 

**SEATING AND BAGRACK** 



## **SOLID STATE SPEED CONTROL**



#### THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	73056-G01	ELECTRONIC SPEED CONTROL ASSEMBLY (INCLUDES ITEMS 2 - 31)	1
2	*	WASHER, LOCK, #10	
3	*	NUT, 10 - 32	
4			i
5	30353-G1	DIODE	1
6	21764-G1	RESISTOR	1
7	73042-G01	WIRE HARNESS, CHARGER CONNECTOR	1
8	*	NUT, 5/16 - 24	2
9			
10	*	WASHER, LOCK, 5/16	2
11	25972-G02	WIRE, SOL - B+	
12	25978-G10	WIRE, SOL - B	1
13	11027-G2	NUT, 1/4 - 20	2
14			
15	27855-G01	SOLENOID	1
16	73026-G01	HEATSINK	1
17	25864-G02	ELECTRONIC SPEED CONTROLLER	1
18	73190-G01	PAD, THERMAL MOUNTING	1
19	71102-G01	BOLT, 1/4 - 20 X 3/4 LG	5
20	73028-G01	COVER	1
21	31539-G1	WIRE TIE	1
22	73053-G01	MOUNT	1
23			
24	71102-G03	BOLT, 1/4 - 20 X 1 1/4 LG	4
25	73039-G01	WIRE HARNESS, POWER	1
26	73040-G01	WIRE HARNESS, CONTROL	1
27	00270-G5	BOLT, 5/16 - 18 X 5/8 LG	4
28			
29	11027-G1	NUT, 5/16 - 18	4

### **Electric Vehicle**

#### SOLID STATE SPEED CONTROL


THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.


When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3	4 5	DESCRIPTION	QT	Υ.
30				· - n		
31	25866-G01	BRACE	KET, SOLEN	NOID		1
32					ļ	
33	71102-G01	BOLT, 1/4 -	20 X 3/4 L	G		4
				•		





# **SOLID STATE SPEED CONTROL - DCS**

#### **Electric Vehicle**

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	73121-G01	SPEED CONTROL ASSEMBLY (INCLUDES ITEMS 2 - 41)	1
2	*	WASHER, LOCK, #10	2
3	*	NUT, 10 - 32	2
4			
5	12914-G1	TAB, TERMINAL	1
6	73150-G01	RESISTOR	1
7			
8	*	NUT, 5/16 - 24	2
9			
10	*	WASHER, LOCK, 5/16	2
11	25972-G56	WIRE, C - B+	1
12			
13	11027-G2	NUT, 1/4 - 20	2
14		·	
15	27855-G01	SOLENOID	1
16	73026-G01	HEATSINK	1
17	73144-G01	SPEED CONTROLLER	1
18	73190-G01	PAD, THERMAL MOUNTING	1
19	71102-G01	BOLT, 1/4 - 20 X 3/4 LG	5
20			
21	31539-G1	WIRE TIE	1
22	73053-G01	MOUNT	1
23			
24	71102-G03	BOLT, 1/4 - 20 X 1 1/4 LG	4
25	73152-G01	WIRE HARNESS, POWER	1
26	73153-G01	WIRE HARNESS, CONTROL	1
27	00270-G5	BOLT, 5/16 - 18 X 5/8 LG	3
28			
29	11027-G1	NUT, 5/16 - 18	3
30			

### **Electric Vehicle**

#### **SOLID STATE SPEED CONTROL - DCS**


THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

		1 2 3 4 5 DESCRIPTION	QTY.
31	25866-G01	BRACKET, SOLENOID	1
32	73137-G01	COVER ASSEMBLY (INCLUDES ITEMS 33 - 41)	1
33	73028-G02	COVER (WITH GASKET)	1
34	73132-G01	LABEL, TOW SWITCH	1
35			
36	73125-G01	SWITCH, TOGGLE WITH SEAL (INCLUDES ITEMS 37, 38)	1
37	*	SCREW, #5 - 40	4
38	*	NUT, 15/32 - 32	4
39	73139-G01	NUT, SEAL	1
40	73138-G01	HARNESS, TOW SWITCH	1
41	17618-G1	CLAMP, NYLON	1
42			
43	71102-G01	BOLT, 1/4 - 20 X 3/4 LG.	4
44	25972-G22	WIRE, BL+ TO SOL	1




ITEM	PART NO.	1 2 3 4 5 DESCRIPTION Q	QTY.
1	27065-G01	STARTER / GENERATOR, COMPLETE (INCLUDES ITEMS 2 - 43)	1
2	26870-G01	ARMATURE ASSEMBLY (INCLUDES ITEMS 3 - 5)	1
3	26871-G01	BALL BEARING, REAR	1
4	26872-G01	BALL BEARING, FRONT	1
5	26873-G01	HOLDER, BEARING	1
6			
7			
8	26875-G01	COIL, FIELD	1
9	26876-G01	"F" INSULATING BRUSH ASSEMBLY (INCLUDES ITEMS 10 - 13)	2
10	**	NUT	2
11	*	WASHER, LOCK	2
12	*	WASHER	2
13	*	INSULATOR	1
14	26877-G01	SCREW, POLE CORE SET	4
15	26878-G01	COVER, FRONT	1
16	26879-G01	COVER, REAR	1
17	26880-G01	"A" TERMINAL ASSEMBLY (INCLUDES ITEMS 18 - 23)	2
<b>1</b> 8	*	TERMINAL	2
19	*	INSULATOR	2
20	*	INSULATOR	2
21	*	WASHER	4
22	*	WASHER, LOCK	4
23	*	NUT	4
24			
25	26881-G01	BRUSH HOLDER ASSEMBLY (INCLUDES ITEMS 26 - 28)	1
26	26658-G01	BRUSH	4
27	26882-G01	BRUSH SPRING	4
28	26883-G01	BRUSH CONNECTOR	2
29			
30	26884-G01	KEY	1

ITEM PART NO.	1 2 3 4 5 DESCRIPTION Q1
31 26885-G01	PULLEY1
32 26886-G01	PULLEY ASSEMBLY (INCLUDES ITEMS 33 - 37) 1
33 *	NUT 1
34 *	WASHER, LOCK1
35 *	SCREW
36 *	SCREW4
37 *	SCREW
38 26887-G01	BRUSH 1 COVER
39 26888-G01	BRUSH 2 COVER
40 26889-G01	BOLT AND WASHER ASSEMBLY (INCLUDES ITEMS 41, 42)
41 *	WASHER 2
42 *	WASHER, LOCK
43 16896-G1	TERMINAL COVER 4

**Gasoline Vehicle** 

**STARTER / GENERATOR** 

Service Parts Manual Page AA-4



THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	70314-G01	STEERING BOX ASSEMBLY, COMPLETE	1
2	00462-G7	SCREW, 7/16 - 14 X 7/8 LG	4
3	18325-G1	STEERING WHEEL (INCLUDES ITEM 4)	1
4	*	HUB COVER, EXTENSION	1
5	00566-G2	WASHER, LOCK, 7/16	. 4
6	00999-G01	BOLT, #8 - 18 X 7/8 LG	. 2
7	*	DECAL, SCORECARD	AR
8	14390-G2	NUT, LOCK, 5/8 - 18	. 1
9	27102-G01	SCORECARD HOLDER	. 1
10	00922-G3	WASHER, 7/16	. 1
11			
12			
13			
14			
15			
16			
17			
18	70074-G01	TIE ROD ASSEMBLY (INCLUDES ITEMS 19 - 22)	. 2
19	18434-G2	NUT, 9/16 - 18	. 2
20	10387-G2	PIN, COTTER, 3/32 X 1 LG	. 2
21	50209-G1	NUT, SLOTTED, 7/16 - 20	. 2
22	50641-G1	BOOT, RUBBER	. 2
23			
24	10389-G3	FITTING, GREASE	4
25	50209-G1	NUT, SLOTTED, 7/16 - 20	1
26			
27			
28		·	
29			
30			

### **Electric / Gasoline Vehicle**

### THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
31			
32			
33	10387-G2	PIN, COTTER, 3/32 X 1LG.	3
34			
35			
36			
37			
38			
39			
40			
41	70299-G01	STEERING GEAR KIT (INCLUDES ITEMS 42 - 52)	1
42	*	PINION, GEAR	1
43	*	BALL BEARING	1
44			
45	*	RING, RETAINING, EXTERNAL	1 1
46	*	RACK, STEERING	1
47	*	RACK BALL END (WITH NUT)	1
48	*	NUT, 7/16 - 20	1
49			
50	*	GREASE FITTING, 90°	2
51			
52	*	RING, RETAINING, INTERNAL	1
53			
54	70184-G01	IDLER	1
55	70185-G01	BEARING, FLANGED	1
56	70216-G01	WASHER, THRUST, 1 1/2 I.D	
57	70195-G01	WASHER, THRUST, 7/8	
58	00734-G6	NUT, LOCK, 7/8 - 9	1
59	00798-G8	PIN, COTTER, 5/32 X 1 3/4 LG	1
60			

### **Electric / Gasoline Vehicle**


THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
61	14322-G5	STEERING SHAFT (PRIOR TO SERIAL NUMBER 901144)	1
62	70222-G01	STEERING COLUMN (PRIOR TO SERIAL NUMBER 901144)	. 1
63			
64			1
65			
66	00470-G4	SCREW, 7/16 - 20 X 2 1/2 LG	. 1
67	00734-G3	NUT, LOCK, 7/16 - 20	. 1
68			
69	70360-G01	STEERING SHAFT/COLUMN KIT (INCLUDES ITEMS 70 - 85) (SERIAL NUMBER 901144 AND LATER)	. 1
70	14322-G3	STEERING SHAFT	1
71	70333-G01	STEERING COLUMN	. 1
72	70226-G01	COUPLING	. 1
73	00550-G1	NUT, LOCK, 1/4 - 20	_ 2
74	70227-G01	SCREW, 1/4 - 20 X 7/8 LG	2
75			
76	00118-G2	SCREW, #6 - 18 X 1/4 LG	1
77	70223-G01	GASKET, STEERING HOUSING	1
78	00876-G2	BOLT, 3/8 - 16 X 1 1/4 LG	. 3
79			
80	00878-G1	WASHER, LOCK, 3/8	. з
81	70189-G01	RING, RETAINING, INTERNAL	1
82			
83	17161-G1	BUSHING/SEAL KIT (INCLUDES ITEMS 84, 85)	1
84	*	BUSHING, STEERING COLUMN	. 1
85	*	SEAL, SHAFT	. 1



THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
1	22997-G2	BRAKE ASSEMBLY, PASSENGER SIDE (INCLUDES ITEMS 2 - 8, 14 - 30)	1
2	22518-G1	BACKING PLATE	1
3	23360-G1	ADJUSTER	1
4	23357-G1	LEVER ASSEMBLY (INCLUDES ITEMS 5 - 8, 14 - 16)	1
5	•	SPRING	1
6	*	RETAINER	1
7	*	WASHER, SHOULDER	1
8	23536-G1	TORSION SPRING, PASSENGER SIDE (SILVER)	. 1
9	22997-G1	BRAKE ASSEMBLY, DRIVER'S SIDE (INCLUDES ITEMS 10 - 30)	. 1
10	22519-G1	BACKING PLATE	. 1
11	23361-G1	ADJUSTER	. 1
12	23358-G1	LEVER ASSEMBLY (INCLUDES ITEMS 5 - 7, 13 - 16)	1
13	23537-G1	TORSION SPRING, DRIVER'S SIDE (GOLD)	1
14	23363-G1	ADJUSTER BODY	. 1
15	23382-G1	WASHER, 1/4	1
16	23362-G1	THRUST WASHER, 1/4	1
17			
18	22519-G1	DUST COVER	1
19	23356-G1	ANCHOR BLOCK	1
20	00565-G1	WASHER, LOCK, 1/4	2
21	13632-G1	NUT, 6 MM	2
22			
23	23359-G1	SPRING, BRAKE ADJUSTER	1
24	17290-G1	SPRING, BRAKE ANCHOR	. 1
25	17291-G1	CLAMP, SHOE	2
26	17292-G1	PIN, SHOE CLAMP TENSION	., 2
27			
28	23364-G1	BRAKE SHOE SET (INCLUDES ITEMS 29, 30)	1
29	23354-G1	BRAKE SHOE, TRAILING	. 1

### **Electric / Gasoline Vehicle**

### THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

ITEM	PART NO.	1 2 3 4 5 DESCRIPTION	QTY.
30	23355-G1	BRAKE SHOE, LEADING	1
31			
32			
33	17083-G2	BOLT, 5/16 - 24 X 1 LG	8
34	15126-G1	NUT, LOCK, 5/16 - 24	8
35			
36			
37	15485-G1	WASHER, INNER WHEEL RIM (ELECTRIC VEHICLE)	2
38	21809-G1	WASHER, INNER WHEEL RIM (GASOLINE VEHICLE)	2
39	21807-G1	BRAKE DRUM (GASOLINE VEHICLE) WITH LUG BOLTS	2
40	19186-G1	BRAKE DRUM (ELECTRIC VEHICLE) WITH LUG BOLTS	2
41			
42	21830-G1	WASHER, OUTER WHEEL RIM (GASOLINE VEHICLE)	2
43	15487-G1	WASHER, OUTER WHEEL RIM (ELECTRIC VEHICLE)	2
44	00518-G8	NUT, SLOTTED, 3/4 - 16 (GASOLINE VEHICLE)	2
45	10387-G1	PIN, COTTER, 1/8 X 1 1/2 LG	2
46	15483-G1	NUT, SLOTTED, 5/8 - 18 (ELECTRIC VEHICLE)	2
47	12091-G1	CAP, SPINDLE	2
48	24939-G2	ADAPTOR, SPINDLE CAP (GASOLINE VEHICLE)	2
49	24939-G1	ADAPTOR, SPINDLE CAP (ELECTRIC VEHICLE)	2
Ì			

Electric / Gasoline Vehicle WHI

**WHEEL BRAKE** 

1 - INCLUDES ITEMS 2, 11, 12 3 - INCLUDES ITEMS 4, 11, 12 7 - INCLUDES ITEMS 8, 11, 12 9 - INCLUDES ITEMS 10, 11, 12 11 12

### **Electric / Gasoline Vehicle**

### **WHEELS AND TIRES**

THE USE OF NON UL PARTS WILL VOID ANY UL LISTING.

When ordering parts, please specify the model and serial number of the product.

\* Indicates a component that is not available as an individual part.

G\*\* Indicates consult Customer Service Department for additional information.

TEM	PART NO.	1 2 3 4 5 DESCRIPTION	QT
1	27772-G01	18 X 8.5 - 8 CARLISLE TIRE AND WHEEL ASSEMBLY, LINKS (INCLUDES ITEMS 2, 11, 12)	A
2	27772-G05	18 X 8.5 - 8 CARLISLE TIRE, LINKS	A
3	27772-G02	18 X 8.5 - 8 CARLISLE TIRE AND WHEEL ASSEMBLY, TURF GLIDE (INCLUDES ITEMS 4, 11, 12)	A
4	27772-G06	18 X 8.5 - 8 CARLISLE TIRE, TURF GLIDE	A
5			
6			
7	27772-G03	18 X 8.5 - 8 CARLISLE TIRE AND WHEEL ASSEMBLY, TURF SAVER (INCLUDES ITEMS 8, 11, 12)	A
8	27772-G07	18 X 8.5 - 8 CARLISLE TIRE, TURF SAVER	A
9	27772-G04	18 X 8.5 - 8 CARLISLE TIRE AND WHEEL ASSEMBLY, FAIRWAY (INCLUDES ITEMS 10, 11, 12)	🗚
10	27772-G08	18 X 8.5 - 8 CARLISLE TIRE, FAIRWAY	A
11	15169-G1	WHEEL RIM, 4 LUG, STANDARD	A
12	11657-G1	VALVE STEM	A

### **WHEELS AND TIRES**

### **Electric / Gasoline Vehicle**

### **SPECIAL TOOLS**

### **SPECIAL TOOLS LISTING**

### **SPECIAL TOOLS**

Part No.

Part No.

**ELECTRIC** 

**GASOLINE** 

**VEHICLE** 

**VEHICLE** 

### **SPECIAL TOOLS**

BATTERY MAINTANANCE KIT	25587-G01	
SEAL INSTALLATION TOOL (REAR AXLE SHAFT SEAL)	18739-G1	
BATTERY SET DISCHARGER, 36 VOLT, 75 AMP	28251-G01	
HIGH RESISTANCE SPARK PLUG WIRE SET		
PULLER, DRIVE CLUTCH		19779-G2
PULLER, FLYWHEEL		
CAM PULLEY TOOL	***************************************	27851-G01
CURRENT INDICATOR	16489-G1	16489-G2
MULTI-METER, DIGITAL	27481-G01	27481-G01
CRIMPING TOOL	27765-G01	27765-G01
SLIDE HAMMER (AXLE/HUB REMOVAL)	15947-G1	15947-G1
SLIDE HAMMER (AXLE REMOVAL ONLY)	18753-G1	18753-G1
TACHOMETER		72526-G01
FEELER GAUGE	***************************************	72525-G01
COMPRESSION TESTER		

### OIL, 10W-30

5 GALLONS257	30-G03
12 QUART CASE	30-G04
55 GALLON DRUM	30-G05

### **PAINT**

CONTACT CUSTOMER REPRESENTATIVE FOR COLOR SPECIFICATIONS AND PART NUMBERS

### **ACCESSORIES**

### **ACCESSORIES LISTING**

### **ACCESSORIES**

### Part No.

ELECTRIC/GASOLINE VEHICLES

### **ACCESSORIES LISTING**

SUN TOP KIT	75040-G01
SUN TOP KIT (4 CADDY VEHICLE ONLY)	75123-G01
WINDSHIELD KIT (SOLID, CLEAR AND REQUIRES SUN TOP KIT) 4 CADDY VEHICLE ONLY	75133-G01
WINDSHIELD KIT (SOLID, TINTED AND REQUIRES SUN TOP KIT) 4 CADDY VEHICLE ONLY	75133-G02
WINDSHIELD KIT (2 BEND, CLEAR AND REQUIRES SUN TOP KIT)	75041-G03
WINDSHIELD KIT (2 BEND, TINTED AND REQUIRES SUN TOP KIT)	75041 <b>-</b> G04
WINDSHIELD KIT (SPLIT, CLEAR AND REQUIRES SUN TOP KIT)	750 <mark>77-G</mark> 01
WINDSHIELD KIT (SPLIT, TINTED AND REQUIRES SUN TOP KIT)	75 <b>077-G</b> 02
DIVOT REPAIR KIT (REQUIRES SIDE BASKET KIT)	23300-G1
RAKE HOLDER	75006 <b>-</b> G01
SAND RAKE	14735-G1
TOW BAR KIT (CASUAL USE)	75033-G01
TOW BAR KIT (PERMANENT USE)	75089-G01
WEATHER ENCLOSURE (3 SIDED)	75078-G01
WEATHER ENCLOSURE (4 SIDED)	75079-G01
REAR VIEW MIRROR (REQUIRES SUN TOP KIT)	
MESSAGE HOLDER KIT (REQUIRES SUNTOP KIT)	75094-G01
HOURMETER (GASOLINE VEHICLE ONLY)	75114-G02
HOURMETER (ELECTRIC VEHICLE ONLY)	
COOLER JUG / BRACKET KIT	
BAG COVER / RAIN CURTAIN KIT	75191 <b>-</b> G01
SEAT REFURBISHMENT SPRAY (WHITE)	28166-G01
TOW LINK ASSEMBLY (REQUIRES TOW BAR ADAPTER KIT)	75165-G01
TOW BAR ADAPTER KIT (REQUIRES TOW LINK ASSEMBLY)	75166-G01


### **ACCESSORIES**

### **ACCESSORIES ILLUSTRATED**


NOTE: SIDE BASKET CANNOT BE USED ON SAME SIDE OF VEHICLE WITH SAND BOTTLE KIT. 75009-G01 NOTE: TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO.

## READ ALL INSTRUCTIONS BEFORE PROCEEDING.

- PORT TO FORM CLEAN, STRAIGHT THREADS. BACK THE TAPTITE SCREW DESIGNATED HOLE (SEE ILLUSTRATION) IN THE METAL SEAT BACK SUP-1. INSTALLATION TIP: INSTALL THE 1/4-20 TAPTITE BOLT ITEM 1INTO THE OUT OF THE SEATBACK SUPPORT.
- ALIGN THE HOLES IN THE REINFORCING PLATE AND THE SAND BOTTLE HOLDER, ITEM 2 WITH THE HOLE INDICATED IN THE THE METAL SEAT BACK SUPPORT. INSERT THE TAPTITE SCREW AND SECURE FIRMLY. ٥i



MEDALIST



æ	B VAR	SAND BOTTLE INSTALL ATION INSTRUCTION KIT	TSNI NOITA	STALL		SAND BOT
		BOTTLE, SAND	27373-G01	1	3	
		HOLDER, SAND BOTTLE	27374-G01	-	8	
	o o	BOLT, TAPTITE, 1/4-20 X 3/4 LG.	71102-G01	l l	1	
		ITEM   QTY   PART NO.   DESCRIPTION	PART NO.	QTY	ITEM	

PG. 1 OF 1

75029 DRAWING NO. 7503


NOTE: TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO. 75007-G02

## READ ALL INSTRUCTIONS BEFORE PROCEEDING.

1. ALIGN HOLES ON THE SIDE BASKET, ITEM 1 WITH HOLES IN THE SEAT BACK SUPPORT BRACKET AS SHOWN IN ILLUSTRATION.

NOTE BASKET MAY BE INSTALLED ON EITHER SIDE OF VEHICLE

INSTALL THE THREAD FORMING BOLTS, ITEM 2 INTO EACH HOLE. TIGHTEN TO 80 - 85 IN. LBS. TORQUE. તં



NO	DE 0 X 1/2 LG.
DESCRIPTION	BASKET, SIDE BOLT, 1/4-20 X 1/2 LG.
PART NO.	75008-G01 71102-G02
ITEM QTY	3
ITEM	- 5

NG TO	NG TO TITLE SIDE BASKET INSTALLATION	KET INS	TALLAT	NOI			
TS. NG OF	EZETITION ORGENT	DRIN BY ORIG DATE	L WEBB 01/03/94	REV BY REV DATE	A	DRAWING NO. 750	A DRAWING NO. 75026
	E-Z-GO DIVISION OF TEX	TRON, INC.,	P.O. BOX 3	E-2-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA,GA. 30913-2699, 1-800-241-5855	1-800-7	241-58	99

PG. 10F1

REV

NOTE: TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO. 75041-GO\*

\* CONTACT SERVICE PARTS FOR AVAILABILITY.


## READ ALL INSTRUCTIONS BEFORE PROCEEDING.


- 1. INSERT THE RUBBER GROMMETS, ITEM 3 INTO THE TOP AND BOTTOM HOLES ON BOTH SIDES OF THE WINDSHIELD, ITEMS 1, 2, 9, OR 10.
- INSERT THE SPACERS, ITEM 4 INTO THE RUBBER GROMMETS.


તાં

ന്

- INSERT THE PLUG BUMPERS, ITEM 5 INTO THE CENTER HOLES OF THE WINDSHIELD, ITEMS 1, 2 OR THE TOP OF WINDSHIELD, ITEMS 9 OR 10.
- PLACE THE WINDSHIELD AGAINST THE FRONT STRUT WITH THE SMALL TAPERED END AT THE TOP.
- INSERT THE BOLTS, ITEM 6 THRU WINDSHIELD AND THE FRONT STRUT AND SECURE WITH WASHERS, ITEM 7 AND LOCK NUTS, ITEM 8.







ITEM	ΔI	PART NO.	DESCRIPTION
-	1	75021-G01	WINDSHIELD, CLEAR, 2 BEND
8	-	75021-G02	WINDSHIELD, TINTED, 2 BEND
ო	4	72147-G01	GROMMET, RUBBER
4	4	23726-G7	SPACER
ഹ	Ø	75124-G01	BUMPER, PLUG
ဖ	4	16705-G6	SCREW, 1/4-20 X 1 3/4 LG.
7	4	00660-G7	WASHER, 1/4"
œ	4	00891-G2	NUT, LOCK, 1/4-20
თ	-	75203-G01	WINDSHIELD, CLEAR, 4 BEND
9	-	75203-G02	WINDSHIELD, TINTED, 4 BEND

ဥ	6	
THE SYMBOL A REFERS TO A NOTE CORRESPONDING TO THE LETTER ENCLOSED WITHIN IT.	SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF REPLACEMENT PARTS.	
Ž	₽≅	
윤	<b>3 &amp;</b>	
Ŏ	22	
Ω.	<b>Ģ</b> ō	
뿙	ᇫ뿌	
医	♀芹	
ၓ	ŧΨ	
ш	ജ≚	
ნĿ	₩5	
Z	물질	
<b>₹</b>	ጁ፫	
먇	ညစ	
ഗ≥	ω <u>⊢</u>	
節品	W.S.	
15分		
屋光	೭ನಿತ	
℧Ⅎ	à Q L	•
<u></u>	<b>\$</b> 22	
있뜹	Q # E	
置片	크트뛰	l
S E	요물목	
ШШ	피달리	
ᇎ	SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING REPLACEMENT PARTS.	
• •		


DRAWING	A NO. 75043
•	<
J.Brand	05/31/95
REVBY	AEV DATE
L WESB REV BY	12/17/93
DRN BY	CHIG DATE
	CHIS DATE

E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA, GA. 30913-2699, 1-800-241-5855


PG. 1 OF 2

REV C


# NOTE: ALL HARDWARE SHOWN ACTUAL SIZE



ITEM 3 RUBBER GROMMET QTY. 4



ITEM 4 SPACER QTY. 4



ITEM 5 PLUG BUMPER QTY. 2





ITEM 6 1/4-20 X † 3/4" SCREW QTY. 4



ITEM 7 1/4" WASHER QTY: 4



ITEM 8 1/4-20 NUT, LOCK QTY. 4

THE SYMBOL TREFERS TO A NOTE CORRESPONDING TO THE LETTER ENCLOSED WITHIN IT.

SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS.


RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF REPLACEMENT PARTS.


TITLE	TITLE WINDSHIELD INSTALLATION	LD INST	'ALLAT	ION			
<b>E</b> 26	DEN BY ORIGINATED ORIGINATE	DAN 8Y ORIG DATE	L. WEBB 12/17/93	REV BY HEV OATE	J. BRAND 05/31/95	٧	A DRAWING NO. 75043
E-Z-GO	IVISION OF TEXT	HON, INC.,	P.O. BOX 3	88, AUGUST	E-Z-GO DIVISION OF TEXTHON, INC., P.O. BOX 388, AUGUSTA, GA. 30913-2699, 1-800-241-5855	-800	241-5855

ပ

暖

PG. 2 OF 2





NOTE: TO ORDER THIS ENTIRE FIELD KIT, REQUEST 75040-G01

# READ ALL INSTRUCTIONS BEFORE PROCEEDING.

### A. REAR STRUTS

- 1. REMOVE CENTER BASKET AND OTHER ACCESSORIES THAT MAY LIMIT ACCESS REQUIRED FOR INSTALLING REAR STRUTS.
- PLACE REAR STRUT, ITEM 2 THRU THE SQUARE HOLE IN THE TOP OF THE SEAT BACK SUPPORT.
- 3. ALIGN THE HOLES IN THE REAR STRUT WITH THE HOLES IN THE SEAT BACK SUPPORT BRACKET. PUSH THE STRUT TOWARD THE CENTER OF THE CAR TO GIVE CLEARANCE BETWEEN THE STRUT AND THE SEAT BACK SUPPORT.
- 1. PLACE WASHER, ITEM 3 ONTO BOLT, ITEM 4 AND INSERT BOLT JUST THRU SEAT BACK SUPPORT (2 3 THREADS). PLACE THE SMALL WHITE TEFLON WASHER, ITEM 5 ONTO THE BOLT BETWEEN THE STRUT AND SEAT BACK SUPPORT TO PREVENT SQUEAKING.
- 5. INSERT THE BOLT WITH THE TWO WASHERS IN PLACE THRU THE REAR STRUT. SECURE HARDWARE WITH WASHER, ITEM 3 AND LOCK NUT, ITEM 6. DO NOT TIGHTEN HARDWARE.
- 6. REPEAT STEPS 4 AND 5 FOR THE OTHER HOLE.
- 7. REPEAT PROCEDURE AT THE OTHER SIDE OF VEHICLE.
- 8. INSERT TUBE CAPS, ITEM 18 INTO THE TOP OF THE REAR STRUTS.

### B. FRONT STRUT

- 1. REMOVE AND DISCARD THE FOUR ALLEN HEAD BOLTS FROM THE FRONT COWL USING A 7/32" ALLEN WRENCH.
- 2. AT THE TOP HOLE, INSTALL THE FRONT STRUT, ITEM 7 WITH BOLT, ITEM 8 AND BLACK LOCK WASHER, ITEM 9, ON THE OUTSIDE OF STRUT, AND A SPACER, ITEM 10 AND A WASHER, ITEM 11 BETWEEN THE FRONT COWL AND STRUT. **DO NOT TIGHTEN HARDWARE**.
- 3. AT THE BOTTOM HOLE, SECURE THE FRONT STRUT, ITEM 7 WITH BOLT, ITEM 8 AND BLACK LOCK WASHER, ITEM 9, ON THE OUTSIDE OF STRUT, AND TWO BLACK WASHERS, ITEM 11 BETWEEN THE FRONT COWL AND STRUT. DO NOT TIGHTEN HARDWARE.

### C. SUNTOP

- 1. PLACE SUN TOP, ITEM 1 ONTO STRUTS
- 2. SECURE SUN TOP LOOSELY WITH BOLTS, ITEM 17 AT FRONT AND ITEM 12 AT REAR, PLASTIC SPACER, ITEM 14, WASHER, ITEM 15, AND LOCK NUT, ITEM 16. SEE ILLUSTRATIONS FOR INSTALLATION SEQUENCE.
- 3. TIGHTEN ALL SUN TOP HARDWARE TO 3 · 5 FT. LBS. TORQUE.
- 4. TIGHTEN ALL REAR STRUT HARDWARE TO 13 15 FT. LBS. TORQUE.
- 5. TIGHTEN ALL FRONT STRUT HARDWARE TO 17 19 FT. LBS, TORQUE.

ITEM	ΩT	PART NO.	DESCRIPTION
-	-	27069-G01	TOP, SUN
8	8	75046-G01	STRUT, REAR
က	۵	00571-G2	WASHER, 5/16"
4	4	00439-G6	BOLT, 5/16-18 X 1 3/4"
ις	4	17255-G1	WASHER, TEFLON, 5/16"
9	4	11098-G6	NUT, LOCK, 5/16-18
7	-	75045-G01	STRUT, FRONT
æ	4	71056-G02	BOLT, 5/16-18 X 2 5/8"
თ	4	95- <del>5</del> 0600	WASHER, LOCK, 5/16"
2	Ø	75048-G01	SPACER
Ξ	9	00570-G2	WASHER, 5/16"
72	2	00753-G6	BOLT, STAINLESS STEEL, 1/4-20 X2 1/4"
5			
4	4	75051-G01	SPACER, PLASTIC
15	8	00559-G7	WASHER, 1/4"
16	4	00891-G2	NUT, LOCK, 1/4-20
4	a	00753-G5	BOLT, STAINLESS STEEL, 1/4-20 X 2"
18	7	19853-G1	CAP, TUBE, 1"

TITLE	EZE	E-Z-GO
THE SYMBOL A REFERS TO A NOTE CORRESPONDING TO TITLE THE LETTER FINCE OSED WITHIN IT.	SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF	HEPLACEMENT PARTS.

	J. Brand 05/25/9\$	
į	REV BY REV DATE	
LATION	L WEBB 12/20/93	
NSTALI	DRN BY ORIG DATE	
SUN TOP INSTALLATION	F L TEXTRON	
TITLE	123	

PG. 3 OF 3


DRAWING NO. 75055

٩

83

REV D


	ij
	Ť
į	Ñ
	-800-241-5
	1-800-241-5F
	~
	ğ
	ন্
	띂
	婜
	٣,
	ð
	ă
	녌
	ij
	≌
	₹
	88
	õ
	õ
	a
	Q
	α.
	Ö
	롣
	ź
	ဝှ
	E
	ω
	<u>-</u>
	ō
	DIVISION OF TEXTRON, INC., P.O. BOX 388. AUGUSTA GA. 30913-2699. 1
	봈
	š
	ō
	_



NOTE: TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO. 75013-G02

# READ ALL INSTRUCTIONS BEFORE PROCEEDING.

- 1. REMOVE THE RIVETS ON THE SIDE OF THE BAGWELL.
- 2. ALIGN THE MUD FLAP, ITEMS 1 AND 2 WITH THE HOLE IN THE RIB OF THE FENDER CAP AS SHOWN AND INSERT RATCHET TYPE FASTENER, ITEM 4.
- 3. SECURE THE MUD FLAP TO THE BAGWELL WITH NEW RIVETS, ITEM 3.



ITEM	QTY	PART NO.	DESCRIPTION
-	1	75010-G01	MUD FLAP, L.H.
0	-	75010-G02	MUD FLAP, R.H.
က	4	71055-G01	RIVET, 3/16
4	8	16816-G2	FASTENER, RATCHET TYPE

TITLE	23	09·Z-3
THE SYMBOL   REFERS TO A NOTE CORRESPONDING TO TITLE THE LETTER END OSFD WITHIN IT.	SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF	REPLACEMENT PARTS.

ORIG DATE OF	DAN BY ORIG DATE	L WEBB REV BY 01/24/94 REV DATE	REV BY REV DATE	A	DRAM NO.	A DRAWING NO. 75014
E-Z-GO DIVISION OF TEXT	XTRON, INC., P.	P.O. BOX 3	E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA, GA, 30913-2699, 1-800-241-5855	906	241-58	55

**MUD FLAP INSTALLATION** 


PG. 1 OF 1

REV

NOTE: TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO. 75109-G02

# READ ALL INSTRUCTIONS BEFORE PROCEEDING.

- 1. INSERT THE ASH TRAY, ITEM 1 INTO THE GASKET, ITEM 2 UNTIL THE GAS-KET HOOKS OVER THE FLANGES ON THE TOP AND BOTTOM OF THE ASH TRAY.
- 2. USING BRACKET, ITEM 3 AS A TEMPLATE, INSERT THE (4) SELF DRILLING SCREWS, ITEM 4. LOCATE BRACKET APPROXIMATELY AS SHOWN IN ILLUSTRATION.
- 3. SNAP THE ASH TRAY INTO THE BRACKET.



	ITEM	ату	PART NO.	DESCRIPTION
	1	1	27731-G01	ASH TRAY
	Ø	-	27736-G01	GASKET, ASH TRAY
	ო	-	75108-G01	BRACKET, ASH TRAY
	4	4	00100-G4	SCREW, 10-16 X 1/2" LG.
Ī				


TITLE	123
THE SYMBOL A REFERS TO A NOTE CORRESPONDING TO TITLE	SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF REPLACEMENT PARTS.

STS		DAN BY	L WEBB REV BY	REV BY	ŀ	DRAWING
RING OF	OF EZECTIVIZED ORIGIDATE 01/21	ORIG DATE	01/21/94 REV DATE	REV DATE	4	A NO. 75110
	LX31 40 NOISIAID O5-Z-3	TRON, INC., F	.O. BOX 38	E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA,GA. 30913-2699, 1-800-241-5855	8	241-5855

**ASH TRAY INSTALLATION** 


PG. 1 OF 1

REV



6" CHROME HUBCAP





GOLD / SILVER SPOKE HUBCAP

ITEM	QΤΥ	PART NO.	DESCRIPTION
1	-	14913-G1	8" CHROME HUBCAP
Q	4	14913-G2	8" CHROME HUBCAP SET
ო		16042-G1	6" CHROME HUBCAP
4	4	16042-G2	6" CHROME HUBCAP SET
သ	-	19241-G2	GOLD SPOKE HUBCAP
9	4	19241-G4	GOLD SPOKE HUBCAP SET
7	-	19241-G1	SILVER SPOKE HUBCAP
ω	4	19241-G3	SILVER SPOKE HUBCAP SET

THE SYMBOL A REFERS TO A NOTE CORRESPONDING TO
THE LETTER ENCLOSED WITHIN IT.
SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS.
RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF
REPLACEMENT PARTS.

TS. NG OF	NOVIXEI CSZE	DHN BY ORIG DATE	CGT 02/07/95	REV BY REV DATE	<	A DRAWING NO. 28	WING 28244


WHEEL COVER INSTALLATION

TITLE

REV .

PG. 1 OF 1

. 1-800-241-5855
30913-2699
-
., P.O. BOX 388,
S Z
E-Z-GO DIVISION OF





DING TO	TITLE MEDALIST R	EAR VIE	EW MIRI	DING TO TITLE MEDALIST REAR VIEW MIRROR INSTALLATION INSTRUCTIONS	SN	TRUCTIONS
0		DAN BY	CGT REVBY		ľ	DRAWING
200	CALCAL TANKS ONG DATE OSTEON REV DATE	ORIG DATE	05/16/94		4	NO. 75169

PG. 1 OF 2

REV

THE SYMBOL THE LETTER ENCLOSED WITHIN IT.

SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS.

RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF TEXTRO!

REPLACEMENT PARTS.

TITLE MEDALIST REA

PRINTLE MEDALIST REALIST REA

PRINTLE MEDALIST REA

PRINTLE MEDALIST REALIST REAL

E-2-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA, GA. 30903-0388, 1-800-241-5855

NOTE: TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO. 19528-G2

## READ ALL INSTRUCTIONS BEFORE PROCEEDING.

- 1. DISCARD PLASTIC MOUNTING BRACKETS AND ADHESIVE SUPPLIED WITH KIT. THESE ITEMS ARE USED IN OTHER APPLICATIONS.
- REMOVE THE FRONT TOP HARDWARE FROM THE FRONT TOP STRUT. IT IS NOT NECESSARY TO REMOVE TOP.
- 3. LOCATE AND DRILL A .147 DIA. HOLE (#26 DRILL) THROUGH CENTER OF FRONT TOP STRUT (INSIDE SURFACE ONLY). SEE DETAIL A.
- USING SCREW, ITEM 3 FASTEN SUPPORT BRACKET, ITEM 5 TO FRONT TOP STRUTAS SHOWN IN DETAIL A.


4


- 5. LOOSEN SETSCREW SUPPLIED WITH MIRROR.
- SLIDE MIRROR, ITEM 1 ONTO BRACKET AND TIGHTEN SETSCREW, DO NOTOVERTIGHTEN. DAMAGE TO MIRROR WILL OCCUR.
- . REINSTALL THE TOP ONTO THE FRONT TOP STRUT, TIGHTEN HARDWARE TO 3 5 FT, LBS. TORQUE.

ITEM	αту	PART NO.	DESCRIPTION
-	-	19496-G1	MIRROR, REAR VIEW
2			
9	-	19527-G1	SCREW, STAINLESS STEEL, SELF TAP.
4			MNG, #8 - 32 x 5/8 LG.
2	-	19502-G2	BRACKET, SUPPORT

THE SYMBOL REFERS TO A NOTE CORRESPONDING TO THE LETTER ENCLOSED WITHIN IT.
SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS.
RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF REPLACEMENT PARTS.

ք	III LE MEDALIST R	EAR VIE	W MIR	TO WILL MEDALIST REAR VIEW MIRROR INSTALLATION INSTRUCTIONS   REV	<u>S</u>	RUCTIONS	REV .
9.	PAN BY ORIGINAL ORIGINATE	DRIN BY ORIG DATE	CGT REV BY OS/16/94 REV DATE	REV BY REV DATE	٧	A DRAWING NO. 75162	PG. 2 OF 2
;	E-Z-GO DIVISION OF TEXT	THON, INC.,	P.O. BOX 3	E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA, GA. 30903-0388, 1-800-241-5855	-900	241-5855	





NOTE: TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO. 75040-G01

# READ ALL INSTRUCTIONS BEFORE PROCEEDING.

### A. REAR STRUTS

- At driver's side, align the holes in the rear strut (item 1) with the holes in the seat back support bracket, being sure that the open end of the strut faces the rear of the vehicle as shown in Details A and D.
- 2. Insert the bolt (item 3) and washer (item 4) through the seat back support bracket. Place nylon washer (item 5) between the seat back support bracket and rear strut. Secure with washer (item 4) and lock nut (item 6) at outer side of rear strut as shown in Detail A. DO NOT TIGHTEN HARDWARE.
- 3. Repeat procedure with rear strut (item 2) at passenger side of vehicle.
- 4. Insert end caps (item 7) into the top of the rear struts as shown in Detail D.

### B. FRONT STRUTS

- Remove and discard the four allen head bolts from the front cowl using a 7/32" allen wrench.
- At the upper hole (both sides of vehicle), install the front strut (item 9) with bolt (item 10) and black lock washer (item 11) on the outside of strut, and a spacer (item 12) between the front cowl and strut. DO NOT TIGHTEN HARDINARE. See Detail B.
- At the lower hole, secure the strut with bolt (item 10) and black lock washer (item 11) on the outside of strut, and two black washers (item 13) between the front cowl and strut. DO NOT TIGHTEN HARDWARE. See Detail B.

### C. SUN TOP

- 1. Place sun top (item 1) onto struts.
- 2. AT FRONT END OF VEHICLE: Secure sun top loosely with bolts (item 16), washers (item 4), spacers (item 17), washers (item 18) and lock nuts (item 6). See Detail C for hardware sequence. DO NOT TIGHTEN HARDWARE.
- AT REAR END OF VEHICLE: At the hole closest to rear of vehicle, insert bolt (item 20) and washer (item 4) and secure with washer (item 4) and lock nut (item 6). See Detail D.
- Insert bolt (item 19) and washer (item 4) through the other hole. Place spacer (item 21) between sun top and strut. Secure with washer (item 4 and lock nut (item 6). See Detail D.
- 5. Tighten all hardware to 13 15 ft. lbs. torque.

ITE	ITEM	QΤΥ	PART NO.	DESCRIPTION
_	_	-	75074-G01	STRUT, REAR, DRIVER'S SIDE
.,	~	-	75074-G02	STRUT, REAR, PASSENGER SIDE
(7)	<u>و</u>	4	00665-G5	BOLT, 3/8-16 X 1 3/4" LG.
4	4	18	00679-G1	WASHER, 3/8
4)	10	4	00771-G5	WASHER, NYLON, 3/8
J	9	10	00891-G5	NUT, LOCK, 3/8-16
-		2	19853-G1	CAP, END
w	<u> </u>			
Ų,	0	_	75125-G01	STRUT, FRONT
¥	0	4	71056-G02	BOLT, 5/16-18 X 2 5/8" LG.
=	_	4	00905-G8	WASHER, LOCK, BLACK, 5/16
72	OI.	2	75048-G01	SPACER, 1/2" THICK
=	<u>е</u>	4	00879-G1	WASHER, BLACK, 3/8
7	4			
#	10	-	27604-G01	TOP, SUN
¥	60	8	00674-G8	BOLT, 3/8-16 X 5" LG.
7	_	2	18716-G1	SPACER
¥	8	α	00653-G1	WASHER, 3/8
¥	0	2	00665-G3	BOLT, 3/8-16 X 2 1/2" LG.
ଷ	0	Ø	00665-G6	BOLT, 3/8-16 X 2" LG.
2	_	7	24647-G1	SPACER, 1/4" THICK

TITLE	EZC	E-Z-GO
THE SYMBOL THE STATE OF THE STATE TO THE STATE TO THE THE STATE BANG OSED WITHIN IT	SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF	REPLACEMENT PARTS.

	1100000	DRN BY	LWEBB	REV BY	•	DRAWING	MING
u,		PATE OFFICE DATE	07/14/94 REV DATE	AEV DATE	∢	<u>양</u>	75158
					1		

4-CADDY CONVERSION TOP INSTALLATION

PG. 3 OF 3

罷

	z
4	P
	•
-	ŧ
٠,	ú
-	Ĺ
4 000	ζ
7	K
۰	۲
	-
	ŀ
9090 01000	þ
- 9	ŋ
g	Q
c	y
•	'n
	_
- è	h
~	5
ð	b
•	٠.
•	r
ď	1
•	4
4	Ľ
F	-
A IOTA O.	n
×	1
	2
2	7
_	כ
- 2	ζ
_	٠
•	'n
ä	ĭ
ō	3
200	2
- 2	Ş
S	)
ã	ń
_	_
•	١
•	٠.
O	Ĺ
_	•
	į
->	5
ž	2
ž	2
¥	
141	֡֜֝֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜
140	֭֭֓֞֝֝֜֜֜֜֜֜֜֓֓֓֓֜֜֜֜֓֓֓֓֓֓֜֜֜֜֜֓֓֓֓֓֜֜֜֡֓֓֓֡֜֜֡֡֓֜֜֡֓֡֓֡֡֡֓֡֓֜֡֡֡֡֡֡
781 1400	֓֞֜֜֜֜֜֜֜֜֜֜֜֜֜֓֓֓֓֜֜֜֜֜֜֜֜֓֓֓֓֓֜֜֜֜֜֜֜֓֓֓֓
TOOK INC	֓֞֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜
VIDOR INC	֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֡֓֓֓֓֓֡֓֓֡֓֡
TYTOON INC	֓֞֝֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓֓
TEXTOON IN	֡֜֜֜֜֜֜֜֜֜֜֜֜֜֜֓֓֓֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜
TEXTOON IN	5
C TEVTOON IN	
TENTOON IN	5
NA MOGTVET SO	5
A DE TEXTOOR IN	5
NO DE TEXTOON	5
AN INCOTVET SO NOT	5
NO MOSTAST SO NOIS	5
NAME OF TEXTOOR	5
NAI MOGTVET BO MOISIVE	5
NATION OF TEXTOOR	5
ON MOSTAGE TEXT DO MOISIVIO	5


83

NOTE: TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO. 75041-G03 (CLEAR) 75041-G04 (TINTED)


READ ALL INSTRUCTIONS BEFORE PROCEEDING.

Insert the rubber grommets (item 3) into the top and bottom holes on both sides of the windshield (item 1 or item 2).

- Insert the spacers (item 4) into the rubber grommets. αí
- From the rear of the windshield, insert the plug bumpers (item 5) into the center holes of the windshield. See Detail A. က
- Place the windshield (item 1 or item 2) against the front strut with the small tapered end at the top. 4,
- Insert the bolts (item 6) through the windshield and front strut and secure with washers (item 7) and lock nuts (item 8). က်
- Tighten enough to ensure that spacer (item 4) does not rattle. ø




**DETAIL A** 



ITEM	ΩTY	PART NO.	DESCRIPTION
-	ŀ	75160-G01	WINDSHIELD, CLEAR
2	-	75160-G02	WINDSHIELD, TINTED
က	4	72147-G01	GROMMET, RUBBER
4	4	23726-G7	SPACER
2	Q	75124-G01	BUMPER, PLUG
9	4	16705-G6	SCREW, 1/4-20 X 1 3/4 LG.
7	4	00660-G7	WASHER, 1/4"
8	4	00891-G2	NUT, LOCK, 1/4-20

REV A	PG. 1 OF 1
ON	A DRAWING NO. 75161
TO TITLE 4-CADDY CONVERSION WINDSHIELD INSTALLATION	
SION WIN	L WEBB REV BY 07/14/94 REV DATE
NVER	DRIN BY ORIG DATE
TITLE 4-CADDY CC	OF EZEDIEXIKON ORIG DATE
2	9

E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA, GA. 30913-2699, 1-800-241-5855



NOTE: TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO. 75093-G01

## READ ALL INSTRUCTIONS BEFORE PROCEEDING

### A. FOUR BAG ATTACHMENT ASSEMBLY

1. Install the top assembly, item 1 to the bottom assembly, item 2 with clevis pin, item 3 and cap nut, item 4. See Detail A.

### B. INSTALLING FOUR BAG ATTACHMENT TO VEHICLE

4. Let the bottom part of the four bag attachment angle downward to disengage

the retaining brackets at the top.

Lift upward and forward simultaneously to remove accessory from vehicle.

LIFTING UP ON THE BOTTOM OF THE FOUR BAG ATTACHMENT TOO FAR WILL BEND THE RETAINING BRACKETS AT THE TOP, MAKING THE ACCESSORY UNUSABLE.

CAUTION

### NOTE

It is necessary that the bottom part of the four bag attachment be disengeged from the bumper and at a level below the bumper (approx. 6-8 inches above the ground) before attemping Step 1. Note the approximate angle of the top assembly and retaining brackets shown in Detail B.

- Place the top retaining brackets over the vehicle bag rack. See Detail B.
- 2. Press down on the top retaining bracket while slightly raising the bottom part of the four bag attachment engaging the brackets with the underside of the vehicle bag rack. See Detail B.
- 3. Raise the bottom of the four bag attachment just enough to clear the bumper on the bagwell and place on top of bumper as shown in Detail C.

### Caution

LIFTING UP ON THE BOTTOM OF THE FOUR BAG ATTACHMENT TOO FAR WILL BEND THE RETAINING BRACKETS AT THE TOP, MAKING THE ACCESSORY UNUSABLE.

- Tighten the bumper clamp by turning clockwise until the bottom is secure.
- 5. Locate the retainer near the center of the four bag attachment. Slide upward to release the bagwell.

### C. REMOVING FOUR BAG ATTACHMENT FROM VEHICLE

- 1. Fold the bagwell up toward the vertical support and secure with retainer.
- Loosen the bumper clamp by turning counterclockwise.
- 3. Lift up on the bottom part of the four bag attachment just enough to clear the bumper and pull down and away from vehicle.

ITEM	ату	PART NO.	DESCRIPTION
-	1	75121-G01	TOP ASSEMBLY
01	-	75122-G01	BOTTOM ASSEMBLY
ო	-	17651-G2	PIN, CLEVIS, 5/16 x 1 1/4
4	-	28129-G01	NUT, CAP, 5/16
2	-	75130-G01	LABEL, WARNING (REPLACEMENT)


THE SYMBOL A REFERS TO A NOTE CORRESPONDING TO TITLE MEDALIST FOUR BAG ATTACHMENT INST'L INSTRUCTIONS	TITLE MEDALIST F	OUR BAG A'	ITACHMENT INST'L INS	<b>STR</b>	UCTIONS
THE LETTER ENCLOSED WITHIN IT.  SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS.  RETAIN THIS DOCIMENT TO EACH ITATE THE ORDERING OF	TESSET DEN BY THE STATE OF STA	DRN BY LWEB	L WEBB REV BY 04/29/94 REV DATE	⋖_	A DRAWING NO. 75129
REPLACEMENT PARTS.	E-Z-GO DIVISION OF TEXT	TRON, INC., P.O. BC	E-Z-GO DIVISION OF TEXTRON, INC. P.O. BOX 388, AUGUSTA GA, 30903-0398, 1-800-241-5855	90	241-5855

Ē

_		Y8 MAO	L WEBB REV BY	AEV BY		•	DHAWING	⊢
	F CONG DATE 042	ORIG DATE	04/29/94 REV DATE	REV DATE		⋖ .	A NO. 75129	
_	E-7-GO DIVISION OF TEXTBON INC. P.O. BOX 388 ALIGHSTA GA 30003-0309 1-900-341-5055	ONI NOO	P O BOX 38	A ATRIBUSTA GA	8650-50605	8	OA4.KOKK	ı

PG. 2 OF 2

REV



NOTE: TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO. 75113-G02

# READ ALL INSTRUCTIONS BEFORE PROCEEDING.

## A. ASSEMBLE HOUR METER

- 1. Insert Hour Meter (item 1) through Bracket (item 2), positioned as shown.
- 2. Using hardware supplied with the Hour Meter, secure Hour Meter to Bracket.
- 3. Attach Harness (item 5) to Hour Meter as shown, Yellow wire to Positive (+) terminal and Black wire to Negative (-) terminal of Hour Meter.

## B. ATTACH HOUR METER ASSEMBLY

- 1. Locate the four (4) predrilled holes in the passenger side seat support.
- 2. Secure the Hour Meter Assembly to the TOP two (2) holes using Bolts (Item 3) and Nuts (item 4) as shown.

## C. CONNECT TO ELECTRONIC SPEED CONTROL

- 1. Locate the cables from the Electronic Speed Control to the batteries. Disconnect both of these cables from the batteries.
- 2. Remove the four (4) bolts securing the cover on the Electronic Speed Control, and remove the cover from the Electronic Speed Control.
- 3. Remove the nut and lock washer from the left solenoid terminal and install Yellow wire from Harness to terminal and reinstall lock washer and nut.
- 4. Repeat procedure on right terminal for Black wire.
- 5. Replace cover and reinstall bolts.
- 6. Reconnect Electronic Speed Control cables to batteries as connected earlier,

ITEM	αTY	PART NO.	DESCRIPTION
1	1	21573-G1	METER, HOUR
7	-	74019-G01	BRACKET, HOUR METER
ო	8	00150-G4	BOLT, #10-24 - 1/2 LG.
4	8	11098-G7	NUT, #10-24
S	-	75117-G02	HARNESS, HOUR METER

TO TITLE		6.7.90
SPONDING	ARTS LISTS.	
THE SYMBOL THE SYMBOL THE SYMBOL TO A NOTE CORRESPONDING TO	THE LETTER ENCLOSED WITHIN IT.  SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS.  RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF	
ERS TO A N	THE LETTER ENCLOSED WITHIN IT. SEE FOLLOWING PAGE(S) FOR NOT RETAIN THIS DOCUMENT TO FACIL	
	ENCLOSE DWING PAGE IIS DOCUME	REPLACEMENT PARTS.
THE SYMB	SEE FOLL(	REPLACER


		ORN BY	. HCE	REVBY		DRAWING	_
Ä	ORIG BATE OF	ORIG DATE	2/21/95	REV DATE	4	NO. 75118	푸
<u> </u>	E-Z-GO DIVISION OF TEXT	FRON, INC., F	2.0. BOX 3	E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA,GA. 30903-0388, 1-800-241-5855	8	241-5855	

**HOUR METER INSTALLATION** 

PG. 20F2

75118

쭚



E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA, GA. 30903-0388, 1-800-241-5855

NOTE: TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO. 75114-G02

# READ ALL INSTRUCTIONS BEFORE PROCEEDING.

## A. ASSEMBLE HOUR METER

- 1. Insert Hour Meter (item 1) through Bracket (item 2), positioned as shown.
- 2. Using hardware supplied with the Hour Meter, secure Hour Meter to Bracket.
- 3. Attach Harness (item 5) to Hour Meter as shown, Yellow wire to Positive (+) terminal and Black wire to Negative (-) terminal of Hour Meter.

## B. ATTACH HOUR METER ASSEMBLY

 Locate predrilled holes in the driver's side seat support and secure the Hour Meter Assembly using Bolts (Item 3) and Nuts (Item 4) as shown.

## C. CONNECT TO ELECTRONIC SPEED CONTROL

- Locate the cables from the Electrical Control Panel to the batteries. Disconnect both of these cables from the batteries.
- Remove the nut securing the cover on the Electrical Control Panel, and remove the cover from the Electrical Control Panel.
- Remove the nut and lock washer from the left solenoid terminal and install Yellow wire from Harness to terminal and reinstall lock washer and nut,
- 4. Repeat procedure on right terminal for Black wire.
- 5. Replace cover and reinstall nut.
- 6. Reconnect Electrical Control Panel cabels to batteries as connected earlier.

ITEM	QTY	PART NO.	DESCRIPTION
-	L	21573-G1	METER, HOUR
2	-	74019-G01	BRACKET, HOUR METER
က	7	00150-G4	BOLT, #10-24 - 1/2 LG.
4	8	11098-G7	NUT, #10-24
2	-	75117-G01	HARNESS, HOUR METER

Ξ	Ü	EZ
THE SYMBOL A REFERS TO A NOTE CORRESPONDING TO	THE LETTER ENCLOSED WITHIN IT.  SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS.  BETAIN THE POSITION OF SACILITATE THE ODDERNO OF	REPLACEMENT PARTS.

	DAN BY	J.RICE	REV BY	•	DRAWING
ORIG DATE	ORIG DATE	02/21/95 REV DATE	REV DATE	<	A NO. 75119
E-Z-GO DIVISION OF TEXT	RON, INC., I	P.O. BOX 3	E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA,GA. 30903-0388, 1-800-241-5855	800	241-5855

**HOUR METER INSTALLATION** 


PG. 2 OF 2

REV

# NOTE: TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO. 75183-G01

# READ ALL INSTRUCTIONS BEFORE PROCEEDING.

- A. Place the bag attachment assembly (item 1) on the foot rest.
- B. With the bag attachment assembly centered on the foot rest, push forward until the keeper brackets lock over the edge of the foot rest tubing.
- C. Place the support bracket (item 4) against the vertical railing as shown at right. Note that the bag attachment assembly must be centered to allow the hole to align with the hole in the support bracket.
- D. Secure the support bracket to the bag attachment assembly with the knob (item 2) and plastic washer (item 3) as shown in illustration at right. Hand tighten firmly by turning knob clockwise.



ITEM	QTY	ITEM QTY PART NO.	DESCRIPTION
+	Ļ	75188-G01	BAG ATTACHMENT ASSEMBLY
7	-	22238-G2	KNOB (3/8-16 X 1 1/2 LG.)
ო	-	17255-G1	WASHER, PLASTIC
4	-	75187-G01	BRACKET, SUPPORT

THE SYMBOL SEFERS TO A NOTE CORRESPONDING TO	
THE LETTER ENCLOSED WITHIN IT.	_
SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS.	
RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF	
REPLACEMENT PARTS.	

TITLE TWO BAG	ATTACH	<b>IMENT</b>	TWO BAG ATTACHMENT INSTALLATION INSTRUCTIONS	<b>SNOLLONS</b>	 REV .
ORIGINAL ORI		L WEBB REV BY 12/27/94 REV DATE	REV BY REV DATE	A DRAWING NO. 75184	PG. 10F1
E-Z-GO DIVISION OF TEXT	TRON, INC., F	.O. BOX 3	E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA,GA. 30903-0388, 1-800-241-5855	800-241-5855	

**NOTE:** TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO.75192-G\* G\* IS DETERMINED BY COLOR OF SEAT

### READ ALL INSTRUCTIONS BEFORE PROCEEDING.

TOOL LIST	QTY. REQUIRED	TOOL LIST	QTY. REQUIRED
Jack, floor	1	Hammer, plastic faced	
Safety stands	4	Drill, 1/2"	
Chocks	4	Drill bit, 3/16"	
Ratchet, 3/8" drive		Drill bit, 1/2"	
Extension, 3/8", 3"		Wrench, 7/16"	
Socket, 7/16*		Wrench, 1/2"	
Socket, 1/2"	1	Wrench, 9/16"	
Socket, 9/16"		Screwdriver, Phillips	
Hammer, ball peen	1	Torque wrench, ft. lbs., 3/8" dri	
Center punch	1	Tape measure	

### A. INSTALLING HEAVY DUTY SPRINGS



BE SURE THE VEHICLE IS ON A FIRM AND LEVEL SURFACE. NEVER GET UNDER A VEHICLE WHILE IT IS SUPPORTED BY A JACK. USE SAFETY STANDS AND TEST THE STABLITY OF THE VEHICLES ON THE STANDS. ALWAYS PLACE CHOCKS IN FRONT AND BEHIND THE WHEELS THAT ARE NOT TO BE RAISED. USE CAUTION SINCE THE VEHICLE IS EXTREMELY UNSTABLE DURING THE LIFTING PROCESS.

1. Place chocks in front and behind each front wheel. Center the jack under the rear bumper. (See Fig. 1)




Fig. 1

TITLE CONVERTIBLE	CARRIER INSTAL	LATION INSTRU	ICTIONS		REV -
EZE TEXTRON	DRN BY J.RICE ORIG DATE 05/04/95	REV BY REV DATE	DRAWING NO.	75269	PG. 1 OF 12
E-Z-GO DIVIS	SION OF TEXTRON, INC., P.O.	D. BOX 388, AUGUSTA GA	A 30903-0388 1-800-449	8-7476	_

- 2. Raise the vehicle and place a safety stand under the outer ends of the rear bumper. (See Fig. 1)
- Lower the jack and test the stability of the vehicle on the two safety stands.
- 4. At the passenger side, remove the bottom shock absorber nut. (See Fig. 2)

### CAUTION

NEVER LIFT OR SUPPORT THE VEHICLE ON THE REAR AXLE DIFFERENTIAL CASTING. BE CAREFUL NOT TO POSTITION THE JACK IN AN AREA THAT COULD DAMAGE THE BRAKE CABLES OR HANGERS.

- 5. Place the jack near the center section of the rear axle and raise just enough to place a second set of safety stands at each end of the axle tubes as close to the wheel as possible. (See Fig. 1)
- 6. Remove the 'U' bolts and securing hardware. The nuts and 'U' bolts may be discarded but the washers should be retained for later use. (See Fig. 2)




Fig. 2

- Remove the shackles and hardware securing the spring to the frame. Remove the spring.
- 8. Installation of heavy duty spring is the reverse order of disassembly.

TITLE CONVERTIBLE	CARRIER INSTAL	LATION INSTRU	CTIONS	REV -
E₹₹ ■ TEXTRON	DRN BY J.RICE ORIG DATE 05/04/95	REV BY REV DATE	DRAWING 75269	PG. 2 OF 12
E-Z-GO DIVIS	SION OF TEXTRON, INC., P.O	D. BOX 388, AUGUSTA,GA	A: 30903-0388, 1-800-448-7476	

9. Install the heavy duty spring (item 1) with 'U' bolts (item 2), washers (removed from old spring), and nuts (item 3). Tighten hardware to 18-22 ft. lbs. torque.


### NOTE

When installing rear spring shackles, be sure that the cupped side of the shackle plate faces the spring.

- 10. Replace the hardware to secure the front end of the spring to the frame. Tighten to 21 25 ft. lbs. torque.
- 11. Replace the hardware and shackles to secure the rear end of the spring to frame. Tighten to 18 22 ft. lbs. torque.
- 12. Replace the shock absorber nut. It must be tightened until the shock absorber bushing expands to the diameter of the shock absorber washer.
- Repeat procedure at driver's side of vehicle.

### B. INSTALLING SEAT BACK SUPPORT (Refer to Fig. 3)

- 1. Remove the existing seat back from the seat back support and retain hardware. Remove the seat back support and bag rack assembly from the frame of the vehicle.
- 2. Install the new seat back supports (item 4) to the frame using washers (item 5) and screws (item 6). Finger tighten hardware to allow for adjustment.



- 3. Using existing hardware, secure the existing seat back to the new seat back support. Tighten to 5 7 ft. lbs. torque.
- 4. Install rubber bumpers (item 10) on vertical part of seat support bracket using one lock nut (item 11) (per bumper) as shown in Fig. 3. Tighten to dimension specified.

TITLE CONVERTIBLE	CARRIER INSTAL	LATION INSTRU	CTIONS	REV -
=≠≥ □ TEXTRON	DRN BY J.RICE ORIG DATE 05/04/95	REV BY REV DATE	DRAWING 75269	PG. 3 OF 12
E-7-GO DIVISION OF TEXTRON INC. P.O. BOX 388, ALIGUISTA GA. 30003-0398, 1-200-449-7476				

### C. INSTALLING VERTICAL FRAME SUPPORT

### MOTE

Some later model vehicles may have pre-drilled holes in the frame under the bagwell. If so, proceed to step 1. If the vehicle has no pre-drilled holes, go to step 2.

- Using the pre-drilled holes in the frame under the bagwell as a guide, drill one 1/2" hole at each side of the bagwell.
- 2. Drill two 1/2" holes through the bottom of the bagwell and through the frame below the bagwell. See Fig. 4 for location of holes.




Fig. 4

- 3. Place vertical frame support (items 12 and 13) between the seat back support and bagwell as shown, Insert screw (item 14) and washer (item 5) on top side bagwell and place washer (item 5) and nut (item 3) underneath frame (See Fig. 4). Finger tighten the hardware since the bottom washer and nut will be removed later for further installation.
- 4. Secure the top of the vertical frame support to the seat back support using bolt (item 15), washers (item 5) and nut (item 3) (See Fig. 4). Do not tighten hardware.

### NOTE

At this point, before tightening any hardware, it is critical the exact dimension is achieved to accommodate the fitting of the seat assembly into the channels of the seat back support.

- 5. As a 'test fit', place the support frame (item 26) into the channels of the seat back support and tighten the hardware securing the seat back support to the vehicle frame and vertical frame support to 21-25 ft. lbs. torque. (See Fig. 7)
- Remove the support frame.

TITLE CONVERTIBLE	CARRIER INSTAL	LATION INSTRU	CTIONS	REV -
EZ TEXTRON	DRN BY J.RICE ORIG DATE 05/04/95	REV BY REV DATE	DRAWING 75269 NO.	PG. 4 OF 12
E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, ALIGUISTA GA. 30003-0388, 1.800-449-7476				

### D. INSTALLING THE VALANCE PANEL AND FLOORBOARD ASSEMBLY

- 1. Place the valance panel (item 16) as shown in Fig. 5 with the side flaps under the fender end caps.
- 2. Secure the side flaps to the fender end caps using two plastic rivets (item 17) as shown.




Fig. 5

- 3. Before attaching foot rest (item 19), mark hole centers as dimensioned and attach support tube (item 29) to foot rest assembly with self drilling and tapping screws (item 41). Insert hole plugs (item 43) and end plugs (item 42) in support tube. (See Fig. 5 Detail A)
- 4. Install the end plugs (item 18) into the tubing ends of the foot rest (item 19).
- 5. Remove the nut (item 3) and washer (item 5) (previously installed) from the underside of the frame. (See Fig. 5 Detail B)

TITLE CONVERTIBLE	CARRIER INSTAL	LATION INSTRU	стомѕ	REV -	
EZG TEXTRON	DRN BY J.RICE ORIG DATE 05/04/95	REV BY REV DATE	DRAWING 75269	PG. 5 OF 12	
E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA,GA. 30903-0388, 1-800-448-7476					

### MOTE

Hint: To perform step 6, it may require the assistance of another person or it may be necessary to use a jack to raise and hold the foot rest while installing hardware.

- 6. Place the foot rest assembly (item 19) up against the bottom of the valance panel aligning the bolts that were previously installed in the bagwell with the holes in the horizontal part of the welded bracket. Be sure the vertical part of the welded bracket is inserted between the valance panel and the vertical frame supports. See Detail in Fig. 5
- 7. Reinstall the washer and nut under the bagwell. Finger tighten to allow adjustment.
- Align holes in welded bracket with holes in valance panel and vertical frame support.
- Place carriage bolt (item 20) through the large holes in valance panel and secure with washer (item 5) and nut (item 3). (See Fig. 5 - Detail B)
- 10. Finish securing the valance panel to the vehicle using two rivets (item 17) at each side.
- 11. Firmly tighten the nut (item 3) on the underside of the frame. (See Fig. 5 Detail B)
- 12. Attach reflectors (item 24) using adhesive backing, covering bolt access holes completely. Drill four 3/16" diameter holes in valance using the holes in reflectors as guides. (See Fig. 6)
- 13. Secure the reflectors with plastic rivets (item 25), (See Fig. 6)




Fig. 6

### E. INSTALLING SUPPORT FRAME (Refer to Fig. 7)

- Insert the nylon bushings (item 21) into the pivot brackets in the support frame (item 26) (4 places).
- Place the support frame into the channels of the seat back support aligning pivot brackets with existing holes.
- 3. Insert the bolt (item 23) through the pivot from the center of vehicle (2 places) and secure with washer (item 36) and nut (item 34).
- Secure front of support frame to seat back support using bolt (item 38), washer (item 36) and nut (item 11).

### F. INSTALLING FIXED BED (Refer to Fig. 7)

1. Attach front bed (item 30) to support frame (item 26) using bolt (item 45) and washer (item 36). (Two places on each end of front bed. Tighten to 5 - 7 ft. lbs. torque.

TITLE CONVERTIBLE	CARRIER INSTAL	LATION INSTRU	CTIONS	REV -	
EZE TEXTRON	DRN BY J.RICE ORIG DATE 05/04/95	REV BY REV DATE	DRAWING 75	5269 PG. 6 OF 12	
E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA.GA, 30903-0388, 1-800-448-7476					




Fig. 7


### G. INSTALLING HANDRAIL (Refer to Fig. 8)

- 1. Attach handrail (item 27) at forward end of support frame (item 26) using bolt (item 23), lock washer (item 37) and acorn nut (item 35). Do not tighten hardware at this time.
- 2. Repeat procedure on other side of support frame.

### H. INSTALLING LOAD BED AND SEAT BOTTOM (Refer to Fig. 8)

- Position load bed (item 28) in support frame as shown.
- 2. Position seat bottom (item 47) in support frame as shown.
- 3. Insert teflon washer (item 32) between support frame and load bed and again between load bed and seat bottom as shown.
- 4. Secure all components by inserting bolt (item 23) through handrail, support frame, washer, bed assembly, washer and seat bottom and secure with lock nut (item 34). (See Detail in Fig. 8) Tighten all handrail hardware to 12 14 ft. lbs. torque.


TITLE CONVERTIBLE	CARRIER INSTAL	LATION INSTRUCTIO	NS	REV -	
EZGE TEXTRON	DRN BY J.RICE ORIG DATE 05/04/95	REV BY REV DATE	DRAWING 75269	PG. 7 OF 12	
E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA,GA. 30903-0388, 1-800-448-7476					



### Fig. 8


### I. INSTALLING SEAT BACK (Refer to Fig. 9)

- 1. Attach seat back (item 46) to seat back support (item 22) using bolt (item 7), lock washer (item 8) and washer (item 9). Tighten to 5 7 ft. lbs. torque.
- 2. Secure seat back to handrail using bolt (item 39) and acorn nut (item 40). Tighten to 5 7 ft. lbs torque.



TITLE CONVERTIBLE	CARRIER INSTAL	LATION INSTRU	CTIONS	REV -	
EZGE TEXTRON	DRN BY J.RICE ORIG DATE 05/04/95	REV BY REV DATE	DRAWING 75	269 PG. 8 OF 12	
E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA,GA. 30903-0388, 1-800-448-7476					

### NOTE: HARDWARE SHOWN ACTUAL SIZE



Item 3 3/8-16 Lock Nut Qty. 14




item 5 3/8 Washer Qty. 14



Item 6

Item 6 3/8-16 x 1 1/4" Bolt Qty. 4




Item 7 1/4-20 x 1" Bolt Qty. 4




Item 8 1/4 Lock Washer Qty. 4



Item 9 1/4 Washer Qty. 4



Item 10 \_\_\_\_\_ Adjustable Rubber Bumper Qty. 4



item 11 5/16-18 Lock Nut Qty. 6



Item 14 3/8-16 x 1 1/2" Bolt Qty. 2






item 15 3/8-16 x 1" Bolt Qty. 2



Item 17 Plastic Rivet Qty. 6



Item 18, 44 End Plug, 1\*

Qty. 2



Item 20 3/8-16 x 1 1/4" Carriage Bolt Qty. 14



Item 21 Bushing, Nylon

Qty. 4





Item 23 5/16-18 x 1 1/2" Bolt Qty. 4



Item 25 Plastic Rivet Qty. 4

TITLE CONVERTIBLE CARRIER INSTALLATION INSTRUCTIONS

REV -


=>≥ | TEXTRON

ORN BY ORIGIDATE J.RICE 05/04/95 REV BY REV DATE DRAWING NO.

75269

PG. 9 OF 12


### NOTE: HARDWARE SHOWN ACTUAL SIZE



Item 31 5/16-18 x 2 1/2" Bolt Qty. 2



Item 32 5/8" Washer, Teflon Qty. 4



Item 33, 42 End Plug, 3/4" Qty. 2, 6



Item 34 5/16-18 Lock Nut Qty. 4



Item 35 5/16-18 Acorn Nut Qty. 2



Item 36 5/16" Washer Qty. 4



Item 37 5/16" Lock Washer Qty. 2





Item 38 5/16-18 x 1" Bolt Qty. 2





Item 39 1/4-20 x 1 3/4\* Bolt Qty. 2






Qty. 2







Qty. 2



item 43 Hole Plug, 1/2\* Qty. 2



Item 45 1/4-20 x 3/4" Bolt Qty. 4



Item 48 5/16-18 x 1 1/4\* Bolt Qty. 2

### NOTE:

Items 18 and 44 are the same in appearance. However, item 18 is for 14 gauge tubing and 44 is for 11 gauge tubing.

Items 33 and 42 are the same in appearance. However, item 33 is for 11 gauge tubing and 42 is for 14 gauge tubing.

Check fit each end plug for tightest fit for correct application.

TITLE CONVERTIBLE	CARRIER INSTAL	LATION INSTRU	CTIONS		REV -
EZE ■ TEXTRON	DRN BY J.RICE ORIG DATE 05/04/95	REV BY REV DATE	DRAWING NO.	75269	PG. 10 OF 12
F 7 00 DUMON OF TEXTRON MAD TO TEXTR					

E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA, GA. 30903-0388, 1-800-448-7476

DESCRIPTION
SPRING, HEAVY DUTY
'U' BOLT, 3/8-16 x 2 1/2" LG.
NUT, LOCK, 3/8-16
SUPPORT, SEAT BACK
WASHER, 3/8
BOŁT, 3/8-16 X 1 1/2" LG.
BOLT, 1/4-20 X 1* LG.
WASHER, LOCK, 1/4
WASHER, 1/4
BUMPER, ADJUSTABLE RUBBER
NUT, LOCK, 5/16-18
SUPPORT, VERTICAL FRAME, DRIVER'S SIDE
SUPPORT, VERTICAL FRAME, PASSENGER SIDE
BOLT, 3/8-16 X 1 1/2" LG.
BOLT, 3/8-16 X 1" LG.
PANEL, VALANCE
RIVET, PLASTIC
END PLUG, 1"
FOOT REST (INCLUDES WARNING LABEL (74132-G01)
BOLT, CARRIAGE, 3/8-16 X 1 1/4" LG.
BUSHING, NYLON
SUPPORT, SEAT BACK
BOLT, 5/16-18 X 1 1/2"
REFLECTOR
RIVET, PLASTIC
FRAME, SUPPORT
HANÐRAIL
BED

TITLE CONVERTIBLE	CARRIE	R INSTALL	ATION INSTRUCTIO	NS		REV -
EZG TEXTRON	DAN BY ORIG DATE	J.RICE 05/04/95	REV BY REV DATE	DRAWING NO.	75269	PG. 11 OF 12

### **KIT CONTENTS**

ITEM	QTY	PART NO.	DESCRIPTION	
30	1	75273-G01	BED, FRONT	<u></u>
31	2	00440-G4	BOLT, 5/16-18 X 2 1/2" LG.	
32	4	17255-G1	WASHER, TEFLON	
33	2	75261-G01	PLUG, END, 3/4*	
34	4	00654-G3	NUT, LOCK, 5/16-18	
35	2	00520-G3	NUT, ACORN, 5/16-18	
36	4	00559-G8	WASHER, 5/16	
37	2	00664-G8	WASHER, LOCK, 5/16	
38	2	00438-G8	BOLT, 5/16-18 X 1* LG.	
39	2	16705-G6	BOLT, 1/4-20 X 1 3/4" LG.	
40	2	00520-G1	NUT, ACORN, 1/4-20	
41	2	00106-G6	SCREW, #12-24 X 3/4" LG.	
42	6	19859-G1	END PLUG, 3/4"	
43	2	20271-G2	HOLE PLUG, 1/2*	
44	4	75261-G02	END PLUG, 1*	
45	4	00661-G6	BOLT, 1/4-20 X 3/4* LG.	
46	1	71751-G*	SEAT BACK	
47	1	75263-G*	SEAT BOTTOM	
(G	* is determined	by the color of seat ha	ck or seat hottom)	

(G\* is determined by the color of seat back or seat bottom)

					T I
EZED TEXTRON DANSY ORIGIDATE	J.RICE 05/04/95	REV BY REV DATE	DRAWING NO.	75269	PG. 12 OF 12

NOTE: TO ORDER THIS ENTIRE FIELD KIT, REQUEST PART NO. 74100-G01

### READ ALL INSTRUCTIONS BEFORE PROCEEDING.

TOOL LIST	QTY. REQUIRED	TOOL LIST	QTY. REQUIRED
Jack	1	Hammer, plastic faced	1
Safety stands	4	Hammer, ball pein	1
Chocks	4	Rivet gun	1
Ratchet, 3/8"		Extension, 3/8, 3"	1
Socket, 9/16"	1	Socket, 7/16*	1
Wrench, 9/16"	1	Wrench, 7/16"	1
Wrench, 1/2"		Torque wrench, 9/16"	1
Drill, 1/2"		Drill bit, 1/2"	1
Drill bit, 1/8"		Drill bit, 3/8"	
Center punch	1	Tape measure	1

### A. INSTALLING HEAVY DUTY SPRINGS



BE SURE THE VEHICLE IS ON A FIRM AND LEVEL SURFACE. NEVER GET UNDER A VEHICLE WHILE IT IS SUPPORTED BY A JACK. USE SAFETY STANDS AND TEST THE STABLITY OF THE VEHICLES ON THE STANDS. ALWAYS PLACE CHOCKS IN FRONT AND BEHIND THE WHEELS THAT ARE NOT TO BE RAISED. USE CAUTION SINCE THE VEHICLE IS EXTREMELY UNSTABLE DURING THE LIFTING PROCESS.

1. Place chocks in front and behind each front wheel. Center the jack under the rear bumper. (See Fig. 1)




Fig. 1

TITLE 4-CADDY CON	VERSION	INSTA	LLATION INSTRUCTIONS	3		REV A
EZE TEXTRON	DRN BY ORIG DATE	L WEB8 07/12/94	REV BY REV DATE	DRAWING NO.	74133	PG. 1 OF 8
5 7 00 00 00			B			

E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA,GA. 30903-0388, 1-800-448-7476

- 2. Raise the vehicle and place a safety stand under the outer ends of the rear bumper. (See Fig. 1)
- 3. Lower the jack and test the stability of the vehicle on the two safety stands.
- 4. At the passenger side, remove the bottom shock absorber nut. (See Fig. 2)

### CAUTION

NEVER LIFT OR SUPPORT THE VEHICLE ON THE REAR AXLE DIFFERENTIAL CASTING. BE CAREFUL NOT TO POSTITION THE JACK IN AN AREA THAT COULD DAMAGE THE BRAKE CABLES OR HANGERS.

- 5. Place the jack near the center section of the rear axie and raise just enough to place a second set of safety stands at each end of the axie tubes as close to the wheel as possible. (See Fig. 1)
- 6. Remove the 'U' bolts and securing hardware. The nuts and 'U' bolts may be discarded but the washers should be retained for later use. (See Fig. 2)




Fig. 2

- 7. Remove the shackles and hardware securing the spring to the frame. Remove the spring.
- 8. Installation of heavy duty spring is the reverse order of disassembly.

TITLE 4-CADDY CON	/ERSION	INSTALL	ATION INSTRUC	TIONS	REV A		
EZG ■ TEXTRON	DRN 8Y ORIG DATE	L WE8B 07/12/94	REV BY REV DATE	DRAWING 74133	PG. 2 OF 8		
E-Z-GO DIVIS	E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA,GA, 30903-0388, 1-800-448-7476						

9. Install the heavy duty spring (item 1) with 'U' bolts (item 2), washers (removed from old spring), and nuts (item 3). Tighten hardware to 18-22 ft. lbs. torque.


### MOTE

When installing rear spring shackles, be sure that the cupped side of the shackle plate faces the spring.

- 10. Replace the hardware to secure the front end of the spring to the frame. Tighten to 21 25 ft. lbs. torque.
- 11. Replace the hardware and shackles to secure the rear end of the spring to frame. Tighten to 18 22 ft. lbs. torque.
- 12. Replace the shock absorber nut. It must be tightened until the shock absorber bushing expands to the diameter of the shock absorber washer.
- Repeat procedure at driver's side of vehicle.

### **B. INSTALLING SEAT BACK SUPPORT**

- 1. Remove the existing seat back from the seat back support. Remove the seat back support and bag rack assembly from the frame of the vehicle.
- 2. Install the new seat back supports (item 4) to the frame using washers (item 5) and screws (item 6). Finger tighten hardware to allow for adjustment. (See Fig. 3)



4-CADDY CONVERSION INSTALLATION INSTRUCTIONS
REV A

DRN BY ORIG DATE 07/12/94 REV DATE
DRAWING NO. 74133 PG. 3 OF 8

E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA, GA. 30903-0388, 1-800-448-7476

- Using screws (item 7), lock washers (item 8) and flat washers (item 9), secure the existing seat back to the new seat back support. (See Fig. 3)
- 4. Install rubber bumpers (item 10) on vertical part of seat support bracket using one lock nut (item 11) (per bumper) as shown in Fig. 3. Tighten to dimension specified.
- 5. Install rubber bumpers (item 10) on horizontal part of seat support bracket using two lock nuts (item 11) (per bumper) as shown in Fig. 3. Tighten to dimension specified.

### C. INSTALLING VERTICAL FRAME SUPPORT

### MOJE

Some later model vehicles may have pre-drilled holes in the frame under the bagwell. If so, proceed to step 1, If the vehicle has no pre-drilled holes, go to step 2.

- Using the pre-drilled holes in the frame under the bagwell as a guide, drill one 1/2" hole at each side of the bagwell.
- 2. Drill two 1/2" holes through the bottom of the bagwell and through the frame below the bagwell. See Fig. 4 for location of holes.




Fig. 4

- 3. Place vertical frame support (items 12 and 13) between the seat back support and bagwell as shown. Insert screw (item 14) and washer (item 5) on top side bagwell and place washer (item 5) and nut (item 3) underneath frame (See Fig. 4). Finger tighten the hardware since the bottom washer and nut will be removed later for further installation.
- 4. Secure the top of the vertical frame support to the seat back support using bolt (item 15), washers (item 5) and nut (item 3) (See Fig. 4). Do not tighten hardware.

TITLE 4-CADDY CON	ERSION INS	STALLATION INSTRU	CTIONS	REV A
EZET TEXTRON	ORN BY L WE ORIG DATE 07/12		DRAWING 74133	PG. 4 OF 8
E-Z-GO DIVIS	ION OF TEXTRON,	INC., P.O. BOX 388, AUGUSTA,	GA. 30903-0388, 1-800-448-7476	


### MOTE

At this point, before tightening any hardware, it is critical the exact dimension is achieved to accommodate the fitting of the seat assembly into the channels of the seat back support.

- 5. As a 'test fit', place the seat assembly (item 22) into the channels of the seat back support and tighten the hardware securing the seat back support to the vehicle frame to 21-25 ft. lbs. torque.
- Tighten the hardware securing the seat back support to the vertical frame support to 21-25 ft. lbs. torque.
   Remove the seat assembly.

### D. INSTALLING THE VALANCE PANEL AND FLOORBOARD ASSEMBLY

- 1. Place the valance panel (item 16) as shown in Fig. 5 with the side flaps under the fender end caps.
- 2. Secure the side flaps to the fender end caps using two plastic rivets (item 17) as shown.
- 3. Install the end plugs (item 18) into the tubing ends of the foot rest assembly (item 19).



4-CADDY CONVERSION INSTALLATION INSTRUCTIONS REV A

DRIN BY ORIG DATE 07/12/94 REV DATE DRAWING 74133 PG. 5 OF 8

- 4. Remove the nut (item 3) and washer (item 5) (previously installed) from the underside of the frame. See Detail in Fig. 5.
- 5. Place the foot rest assembly (item 19) up against the bottom of the valance panel aligning the bolts that were previously installed in the bagwell with the holes in the horizontal part of the welded bracket. Be sure the vertical part of the welded bracket is inserted between the valance panel and the vertical frame supports. See Detail in Fig. 5.

### MOTE

Hint: To perform step 6, it may require the assistance of another person or it be necessary to use a jack to raise and hold the floorboard assembly while installing hardware.

- Reinstall the washer and nut under the bagwell. Finger tighten to allow adjustment.
- Align holes in welded bracket with holes in valance panel and vertical frame support.
- 8. Place carriage bolt (item 20) through the large holes in valance panel and secure with washer (item 5) and nut (item 3).
- 9. Finish securing the valance panel to the vehicle using two rivets (item 17) at each side.
- 10. Firmly tighten the nut (item 3) on the underside of the frame.

### E. INSTALLING SEAT ASSEMBLY

Insert the nylon bushings (item 21) into the pivot brackets on the seat assembly (item 22) (4 places). (See Fig. 6)




Fig. 6

- Place the seat assembly into the channels of the seat back support aligning pivot brackets with existing holes.
- 3. Insert the hitch pin (item 23) through the pivot from the center of vehicle (2 places). (See Fig. 6)
- Clean the reflector mounting surface with alcohol and wipe dry.

TITLE 4-CADDY CON	VERSION INSTALL	ATION INSTRUC	TIONS	REV A		
EZE TEXTRON	ORN BY L WEBS ORIG DATE 07/12/94	REV BY REV DATE	DRAWING 74133	PG. 6 OF 8		
E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA,GA, 30903-0388, 1-800-448-7476						

5. Peel backing from reflector (item 24). Firmly stick onto reflector mounting surface located on valance panel. (See Fig. 7)





Fig. 7




ERSION	INSTALLATIO	ON INSTRUCTIONS	3		REV A
DRN BY ORIG DATE	L WE88 07/12/94	REV BY REV DATE	DRAWING NO.	74133	PG. 7 OF 8
	DRN BY	DRN BY L WEBB	DRN BY L WEBB REV BY	146	DRN BY L WEBB REV BY DRAWING 74133


### KIT CONTENTS

ITEM	QTY	PART NO.	DESCRIPTION
1	2	74135-G01	SPRING, HEAVY DUTY
2	4	74124-G01	
3	14	11098-G5	NUT, LOCK, 3/8-16
4	2	74111-G01	SUPPORT, SEAT BACK
5	14	00560-G1	WASHER, 3/8
6	4	00427-G2	BOLT, 3/8-16 X 1 1/4" LG.
7	4	00414-G8	BOLT, 1/4-20 X 1" LG.
8	4	00565-G7	WASHER, LOCK, 1/4
9	4	00559-G7	WASHER, 1/4
10	4	70113-G01	BUMPER, ADJUSTABLE RUBBER
11	6	11027-G1	NUT, LOCK, 5/16-18
12	1	74126-G02	SUPPORT, VERTICAL FRAME, RH
13	1	74126-G01	SUPPORT, VERTICAL FRAME, LH
14	2	00427-G4	BOLT, 3/8-16 X 1 1/2" LG.
15	2	00426-G8	BOLT, 3/8-16 X 1" LG.
16	1	74127-G01	PANEL, VALANCE
17	6	16816-G2	RIVET, PLASTIC
18	22	19853-G1	PLUG, END
19	1	74105-G01	FOOT REST ASSEMBLY (INCLUDES WARNING LABEL (74132-G01) AND REFLECTOR (74129-G01)
20	2	00769-G2	BOLT, CARRIAGE, 3/8-16 X 1 1/4" LG.
21	4	17838-G1	BUSHING, NYLON
22	1	74131-G*	SEAT ASSEMBLY
23	2	74134-G01	PIN, HITCH
24	2	74128-G01	REFLECTOR

<sup>\*</sup> Contact Service Parts Department for appropriate color.

TITLE 4-CADDY CON	VERSION	INSTALL	ATION INSTRUC	TIONS	•	REV A
EZGD TEXTRON	DRN BY ORIG DATE	L WE98 07/12/94	REV DATE	DRAWING NO.	74133	PG. 8 OF 8





E-2-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA,GA. 30913-2699, 1-800-241-5855

NOTE: TO ORDER THIS ENTIRE FIELD KIT, REQUEST 75135-G01

# READ ALL INSTRUCTIONS BEFORE PROCEEDING.

### A. REAR STRUTS

- 1. ALIGN THE HOLES IN THE REAR STRUT WITH THE HOLES IN THE SEAT BACK SUPPORT BRACKET. PUSH THE STRUT AWAY FROM THE CENTER OF THE CAR TO GIVE CLEARANCE BETWEEN THE STRUT AND THE SEAT BACK SUPPORT.
- 2. PLACE WASHER, ITEM 3 ONTO BOLT, ITEM 4 AND INSERT BOLT JUST THRU SEAT BACK SUPPORT (2 3 THREADS). PLACE THE SMALL WHITE TEFLON WASHER, ITEM 5 ONTO THE BOLT BETWEEN THE STRUT AND SEAT BACK SUPPORT TO PREVENT SQUEAKING.
- 3. INSERT THE BOLT WITH THE TWO WASHERS IN PLACE THRU THE REAR STRUT. SECURE HARDWARE WITH WASHER, ITEM 3 AND LOCK NUT, ITEM 6. DO NOT TIGHTEN HARDWARE.
- 4. REPEAT STEPS 2 AND 3 FOR THE OTHER HOLE.
- 5. REPEAT PROCEDURE AT THE OTHER SIDE OF VEHICLE.
- 6. INSERT TUBE CAPS, ITEM 18 INTO THE TOP OF THE REAR STRUTS.

### B. FRONT STRUT

- 1. REMOVE AND DISCARD THE FOUR ALLEN HEAD BOLTS FROM THE FRONT COWL USING A 7/32\* ALLEN WRENCH.
- 2. AT THE TOP HOLE, INSTALL THE FRONT STRUT, ITEM 7 WITH BOLT, ITEM 8 AND BLACK LOCK WASHER, ITEM 9, ON THE OUTSIDE OF STRUT, AND A SPACER, ITEM 10 BETWEEN THE FRONT COWL AND STRUT. **DO NOT TIGHTEN HARDWARE**.
- 3. AT THE BOTTOM HOLE, SECURE THE FRONT STRUT, ITEM 7 WITH BOLT, ITEM 8 AND BLACK LOCK WASHER, ITEM 9, ON THE OUTSIDE OF STRUT, AND TWO BLACK WASHERS, ITEM 11 BETWEEN THE FRONT COWL AND STRUT. DO NOT TIGHTEN HARDWARE.

### C. SUNTOP

- 1. PLACE SUN TOP, ITEM 1 ONTO STRUTS
- 2. SECURE SUN TOP LOOSELY WITH BOLTS, ITEM 17 AT FRONT AND ITEM 12 AT REAR, PLASTIC SPACER, ITEM 14, WASHER, ITEM 15, AND LOCK NUT, ITEM 16. SEE ILLUSTRATIONS FOR INSTALLATION SEQUENCE.
- 3. TIGHTEN ALL SUN TOP HARDWARE TO 3 5 FT. LBS. TORQUE.
- 4. TIGHTEN ALL REAR STRUT HARDWARE TO 13 15 FT. LBS. TORQUE.
- 5. TIGHTEN ALL FRONT STRUT HARDWARE TO 13 15 FT. LBS. TORQUE.

ITEM	QTY	PART NO.	DESCRIPTION
ı	-	27069-G01	TOP, SUN
Q	Ø	75136-G01	STRUT, REAR
ო	Φ	00571-G2	WASHER, 5/16"
4	4	00439-G6	BOLT, 5/16-18 X 1 3/4"
Ŋ	4	17255-G1	WASHER, TEFLON, 5/16"
9	4	11098-G6	NUT, LOCK, 5/16-18
7	-	75045-G01	STRUT, FRONT
8	4	71056-G02	BOLT, 5/16-18 X 2 5/8"
თ	4	00905-G8	WASHER, LOCK, BLACK, 5/16"
9	Ŋ	75048-G01	SPACER
=	မ	00570-G2	WASHER, BLACK, 5/16"
12	N	00753-G6	BOLT, STAINLESS STEEL, 1/4-20 X2 1/4"
13			
14	4	75051-G01	SPACER, PLASTIC
15	8	00559-G7	WASHER, PLATED, 1/4"
91	4	00891-G2	NUT, LOCK, 1/4-20
17	ય	00753-G5	BOLT, STAINLESS STEEL,1/4-20 X 2"
18	2	19853-G1	CAP, TUBE, 1"

THE SYMBOL (REFERS TO A NOTE CORRESPONDING TO THE LETTER ENCLOSED WITHIN IT. SEE FOLLOWING PAGE(S) FOR NOTES AND PARTS LISTS. RETAIN THIS DOCUMENT TO FACILITATE THE ORDERING OF REPLACEMENT PARTS.

₹	٧
SUN TOP INSTALLATION (WITHOUT BAG RACK)	J. Brand 05/25/95
(WITHO	REV BY REV DATE
ATION	L WEBB 08/16/94
NSTALI	DRN 8Y ORIG DATE
SUN TOP I	ZECTEXTRON
TTLE	

PG.30F3

75137

DRAWING NO. 751

REV A

E-Z-GO DIVISION OF TEXTRON, INC., P.O. BOX 388, AUGUSTA,GA. 30913-2699, 1-800-241-5855

### **DIAGRAMS AND SCHEMATICS**

### **WIRING DIAGRAMS AND SCHEMATICS**

REFER TO TECHNICIANS REPAIR AND SERVICE MANUAL FOR NOTES, CAUTIONS AND WARNINGS.


ELECTRIC MEDALIST TECHNICIANS REPAIR AND SERVICE MANUAL

MANUAL P/N: 28124-G01

GASOLINE MEDALIST TECHNICIANS REPAIR AND SERVICE MANUAL

MANUAL P/N: 28125-G01


### **ELECTRIC VEHICLE ACCESSORY WIRING**



FOR VEHICLES WITHOUT TURN SIGNALS REMOVE WHT WIRE FROM LEFT TURN SIGNAL REMOVE YEL WIRE FROM RIGHT TURN SIGNAL CONNECT BRN WIRE TO RED

• INDICATES BUTT CONNECTION WITHIN WIRING HARNESS

### **GASOLINE VEHICLE ACCESSORY WIRING**




FOR VEHICLES WITHOUT TURN SIGNALS REMOVE WHT WIRE FROM LEFT TURN SIGNAL REMOVE YEL WIRE FROM RIGHT TURN SIGNAL CONNECT BRN WIRE TO RED

\_\_ \_ \_ \_ INDICATES WIRE NOT INCLUDED IN HARNESS


INDICATES BUTT CONNECTION WITHIN WIRING HARNESS

### **ELECTRIC VEHICLE WIRING DIAGRAM / SCHEMATIC**



WIRES INDICATED ———— ARE CONTAINED IN POWER HARNESS ALL OTHER WIRES ARE CONTROL WIRING MS2 IS CLOSED WHEN DIRECTION SELECTOR SWITCH IS IN FWD OR REVERSE MS3 IS ACTIVATED BY ACCELERATOR PEDAL MS4 IS CLOSED BY DIRECTION SELECTOR SWITCH IN REVERSE ONLY

### GASOLINE VEHICLE WIRING DIAGRAM / SCHEMATIC



NOTES	
	ž.
	_
	_
······	_
	_
	_
	_
	_
	_
·	
	_
	_
	_
· · · · · · · · · · · · · · · · · · ·	_
	_
	_
· · · · · · · · · · · · · · · · · · ·	_
	_

Appendix - D

=>= TEXTRON

### CALIFORNIA EMISSION CONTROL WARRANTY STATEMENT

### YOUR WARRANTY RIGHTS AND OBLIGATIONS

The California Air Resources Board and Fuji Heavy Industries Ltd. (herein "FUJi") are pleased to explain the emission control system warranty on your 1995 and later specialty vehicle engine (herein "engine"). In California, the engine must be designed, built and equipped to meet the State's stringent anti-smog standards. FUJI must warrant the emission control system on your engine for the period of time described below, provided there has been no abuse, neglect or improper maintenance of your engine.

Your emission control system may include parts such as the carburetor and the ignition system. Also included may be hoses, connectors and other emission-related assemblies.

Where a warrantable condition exists, FUJI will repair your engine at no cost to you including diagnosis, parts and labor.

### MANUFACTURER'S WARRANTY COVERAGE:

The 1995 and later engines are warranted for two (2) years. If any emission related part on your engine is defective, the part will be repaired or replaced by FUJI.

### **OWNER'S WARRANTY RESPONSIBILITIES:**

As the engine owner, you are responsible for the performance of the required maintenance listed in your Owner's Manual. FUJI recommends that you retain all receipts covering maintenance on your engine, but FUJI cannot deny warranty solely for the lack of receipts or for your failure to ensure the performance of all scheduled maintenance.

As the engine owner, you should, however, be aware that FUJI may deny you warranty coverage if your engine or a part has failed due to abuse, neglect, improper maintenance or unapproved modifications. You are responsible for presenting your engine to a dealer, distributor or warranty station authorized by E-Z-GO DIVISION OF TEXTRON, INC. Augusta, Georgia, (herein "E-Z-GO") to which FUJI supplies the engine as soon as a problem exists. The warranty repairs should be completed in a reasonable amount of time, not to exceed 30 days.

If you have any questions regarding your warranty rights and responsibilities, you should contact the E-Z-GO Warranty Department at 1-800-241-5855.

### LIMITED WARRANTY

### on Emission Control Systems

### California Only -

FUJI, Tokyo, Japan, warrants to the owner of the 1995 and later engine that the engine (1) has been designed, built and equipped so as to conform at the time of manufacture with the applicable regulations of the California Air Resources Board, and (2) is free from defects in materials and workmanship which could cause it to fail to conform with those regulations as may be applicable in the terms and conditions stated below.

### A. WARRANTY COMMENCEMENT DATE

The warranty period begins on the date the engine is delivered to a first retail purchaser.

### **B. LENGTH OF COVERAGE**

FUJI warrants to a first retail purchaser and each subsequent purchaser that the engine is free from defects in materials and workmanship which could cause the failure of a warranted emission-related part for a period of two (2) years after the date of delivery to the first retail purchaser.

### C. WHAT IS COVERED:

### 1. REPAIR OR REPLACEMENT PARTS

Repairs and replacement of any warranted part will be performed at no charge to you by an authorized dealer, distributor or a warranty station. You may contact the E-Z-GO Warranty Department at 1-800-241-5855 to get the nearest appropriate location where your warranty repairs are performed.

### 2. WARRANTY PERIOD

This warranty continues for a period of two (2) years and shall apply only to the repair, replacement or adjustment of the component parts which are not scheduled for replacement as required maintenance. Further, component parts which are scheduled only for regular inspection to the effect of "repair or replace as necessary" shall be warranted for the warranty period. Any warranted part which is scheduled for replacement as required maintenance shall be warranted for the period of time up to the first scheduled replacement point for that part.

### 3. DIAGNOSIS

You shall not be charged for diagnostic labor which leads to the determination that a warranted part is defective, if the diagnostic work is performed at an authorized dealer, distributor or warranty station.

### 4. CONSEQUENTIAL DAMAGES

If a warranted part failed causing damages to other engine components, consult a warranty sta-

### D. WHAT IS NOT COVERED

- 1. This limited warranty does not cover any part which malfunctions, fails or is damaged due to failure to follow the maintenance and operating instructions set forth in the 1995 and later Owner's Manual in-
  - (1) improper or inadequate scheduled engine inspection and maintenance
  - (2) improper or inadequate maintenance of any warranted parts
  - (3) improper installation, adjustment or repair of the engine or of any warranted part unless performed by an authorized dealer
  - (4) failure to follow recommendations on fuel use contained in the 1995 and later Owner's Manual
  - (5) repairs performed outside of the authorized warranty service facilities
  - (6) use of parts which are not authorized by FUJI.
- 2. Add-on or modified parts

This warranty does not cover any part which malfunctions, fails or is damaged due to alterations by changing, adding to or removing parts from the engine.

Expenses incurred by processing warranty claims.

FUJI, any authorized dealer, distributors and warranty station shall not be liable for any loss of use of the engine, for any alternative usage, for any damage to goods, loss of time or inconvenience.

### E. HOW TO FILE A CLAIM

All repairs qualifying under this Limited Warranty must be performed by a dealer who sold you the engine or distributors or warranty stations authorized by E-Z-GO. In the event that any emission-related part is found to be defective during the warranty period, you should notify E-Z-GO Warranty Department at 1-800-241-5855 and you will be given the appropriate warranty service facilities where the warranty repair is performed.

### F. WHERE TO GET WARRANTY SERVICE

It is recommended that warranty service be performed by the authorized dealer who sold you the engine, although warranty service will be performed by any authorized dealers, distributors and warranty stations anywhere in the United States. When warranty repair is needed, the engine must be brought to an authorized dealer, distributorship or warranty station's place of business during normal business hours. In all cases, a reasonable time, not to exceed 30 days, must be allowed for the warranty repair to be completed after the engine is received by the authorized dealer, distributor or service station.

### G. MAINTENANCE, REPLACEMENT AND REPAIR OF EMISSION-RELATED PARTS

Only warranted engine replacement parts approved by FUJI should be used in the performance of any warranty maintenance or repairs on emission-related parts. If other than authorized parts are used for maintenance, replacement or repair of components affecting emission control, you should assure yourself that such parts are warranted by their manufacturer to be equivalent to authorized parts in performance and durability. FUJI, however, assumes no liability under this warranty with respect to parts other than authorized parts. The use of non-authorized replacement parts does not invalidate the warranty on other components unless the non-authorized parts cause damage to warranted parts.

### H. PARTS COVERED UNDER THE CALIFORNIA EMISSIONS WARRANTY

- (1) Fuel Metering System
  - i) Carburetor and internal parts
  - (ii) Choke System
  - (iii) Fuel filter (annual maintenance item)
- (2) Air Induction System
  (i) Air filter element (annual maintenance item)
- (3) Ignition System
  - (i) Spark plug (annual maintenance item)
  - (ii) Ignition Coil
  - (iii) Ignitor Complete (iv) Pulser Coil
- (4) Exhaust Manifold
- (5) Miscellaneous Items Used in Above Systems
  - (i) Fuel hoses, clamps and sealing gaskets

### I. MAINTENANCE STATEMENTS

It is your responsibility to have all scheduled inspection and maintenance services performed at the times recommended in the 1995 and later Owner's Manual and to retain proof that inspection and maintenance services are performed at the times when recommended. FUJI will not deny a warranty claim solely be-

cause you have no record of maintenance; however, FUJI may deny a warranty claim if your failure to perform required maintenance resulted in the failure of warranted part. The proof which you maintain should be given to each subsequent owner of the engine. You are responsible for performing the scheduled maintenance described below based on the procedures specified in the 1995 and later Owner's Manual. The scheduled maintenance below is based on the normal engine operating schedule.

PROCEDURE	INTERVAL
a) Check for sealing of fuel cap and proper operation of fuel gauge (at each fueling). Check that fuel cap vent is free of dirt	WEEKLY
b) Check engine for unusual noise, vibration acceleration.	MONTH (20 HOURS)
c) Check engine electrical system for coil/spark plug wire for cracks/loose connections.	3 MONTH (50 HOURS)
d) Check fuel system for leaks at tank cap, lines, filters, pump, carburetor. Check lines for cracks/deterioration.	3 MONTH (50 HOURS)
e) Check air cleaner filter element.	SEMIANNUAL (125 HOURS)
f) Replace engine oil, DO NOT OVERFILL. SAE 10W-30/10W-40 SF,SG,CC Oil	SEMIANNUAL (125-150 HOURS)
g) Clean oil filter in solvent (at oil change). Replace O- Rings if required.	SEMIANNUAL (125-150 HOURS)
h) Replace air cleaner filter element if required.	ANNUAL (250-300 HOURS)
i) Check fuel filter for dirt build up. (Replace as required)	ANNUAL (250-300 HOURS)
j) Check the spark plugs for gap 0.030. (Replace if required)	ANNUAL (250-300 HOURS)
k) Check timing belt tension, signs of wear/damage. Replace only if wom or damaged.	ANNUAL (250-300 HOURS)

Notes:						
<del></del>						
						<del>-,</del>
	•					
						<del></del> -,
					·	
				<del> </del>		
						<del> </del>
			<del></del>	· · · · · · · · · · · · · · · · · · ·		
-						
		<del> </del>				



a TEXTRON Company

E-Z-GO Division of Textron Inc.

P.O. Box 388 Augusta, Georgia 30903-0388 USA

Inside USA Phone: 1-800-241-5855, FAX: 1-800-448-8124

Outside USA Phone: 010-1-706-798-4311, FAX: 010-1-706-771-4609

Copyrighted Material
This manual may not be reproduced in whole or
in part without the express permission of
E-Z-GO Division of Textron Inc.
Technical Communications Department